- Authorise sponsored links in applications: Authorises apps to launch browser windows from within an app after a click
- Protect the User Profile with a Password: Prevents another
- user from accessing the profile, such as a sibling.

  Auto-authorise Applications after Install: Applications downloaded from Parental Area will automatically appear
- the child's profile (not recommended).
   Clickable Notifications: Turn this setting on to make notifications sent by apps live & clickable in the profile.



8

### Time Management

You can set the time limits for play each day or every day of the week with a few simple clicks. Define times your child can play with Kurio during the day, or define the maximum play time per day to be used throughout the day.

# TIME CONTROL

ine the time slots when the handheld will be "usable" by

- Activate Time Control by switching "on" the button at the
- top of the screen.

  Set the time control for each day: tap the icon to set the desired time slots in the day. You can make several time slots and set different time slots for each day of the week.

  Apply the same settings to the entire week: Click on the box at the top of the screen to make the time control settings



DAILY PLAYTIME
Activate this control to set the maximum play time for your child throughout the day. With this setting is turned on, the child can use the handheld during any of the time slots, but cannot exceed the max time for the day

The playtime is displayed below each day. Press on the day you want to manage and a pop up menu will allow you to set-up the max play time for the selected day.

#### App Management

- From the master list of apps shown, check the box next to the app to use it in the profile.
- All unchecked apps will not appear on this profile's interface. • It is also possible to import the settings from another profile or from the predefined 'easy setup' profiles.
- · All allowed apps will appear on the main screens of the child's profile interface.



# Switching profile



From the Lock Screen (press Power button twice)

From Parental Account



#### **Exposure to Radio Frequency Energy**

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

- Increase the separation between the equipment and receiver.

  Connect the equipment into an outlet on a circuit different from that to which
- he receiver is connected. Consult the dealer or experienced radio/TV technician for help.

## Restricted Use of Electronic Devices

- The use of electronic/electric devices may interfere with safe operation of some aircraft and can be restricted with some airline companies. Please check with
- your airtime company before traveling.

  Kurio has an Airplane Mode. Please go into the Settings of the Android Interfact to switch the tablet into Airplane Mode. All wireless connections will be turned off

# **Declaration of Conformity**

KD Interactive Viladecans Business Park, Edificio Brasil, C/ Catalunya, 83-85 Pl.1 B1, 08840 VILADECANS - BARCELONA, SPAIN

Product: Kurio 4S Model: C13200

**Privacy Policy** 

"We declare that the product above complies with the basic requirements and the other relevant provisions required by R&TTE Directive (1999/5/EC), the Low Voltage Directive (2004/6/5/EC), the CDIrective (2004/6/5/EC) and is in conformity with the following standards:
EN300328: 2006, EN301499-1: 2008, EN301489-17: 2009, EN62209: 2006, EN5022: 2006, EN5024: 2010, EN61000-3-3: 2008, EN60950-1: 2006, EN50332-2: 2000.

The undersigned does hereby declare that the product complies with the above

Issue date: July, 15th 2013



We need you to provide us with your email address when activating your Kurio handheld and keep your email address up to date via the Parental Area to be informed of important updates and information.

Your email address will never be shared with any third parties and you can unsubscribe at any time by clicking on the link provided at the bottom of every Kurio email. To read our Privacy Policy at any time, please go to www.kuriow-

#### Tips and Recommendations

- I ps and Recommendations

   While using some applications that use a lot of the device's processing capacity, the device may become warm. If this occurs, take a short break from using the device to let it cold down.

   Keep the unit clean by wiping it with a slightly damp cloth.

   If you encounter any charging issues, such as not fully charging or shutting off when it has a charge above 5%, you may need to reset the battery level indicator. Plug the unit into the power adapter, and then press and hold the PDWER button until the handheld turns off. Continue to hold down the PDWER button until the battery icon shows up again. Once it appears, release the PDWER button and press it again to start the unit normally.

   Due to Android 4.2's system management, it is no longer possible to move applications to an external SD card. We advise you to store all media files on an external SD card to keep free memory on the device's internal storage for apps and games.



and not by pulling the cord.

The power adapter & cord should be plugged in near the unit, so it is easily accessible and does not strain the cord. Make sure that the correct adaptator is used at all times.

# Warning

- All packing materials such as internal bags, plastic collars, plastic films, screen protector film, and carton inserts are not part of this product and should be removed before handing the device over to a child. Please keep the box and this guide for further reference.

- Un on try to disassemble the unit.

  To charge Kurio, only use the power adapter supplied with Kurio handheld.

  Avoid using the handheld while charging: this may alter the battery charging process and the battery life of the device.

  Keep the unit out of direct sunlight and away from any direct heat source.

  Do not expose the unit to moisture or water.

  To prevent hearing damage, never use earphones at excessive volume levels. Listening to loud sounds for an extended period may cause temporary or permanent hearing loss.

- Estening to two sources for an extensive period may cause temporary or permanent hearing loss.

  Never use Kurin white period in use, take frequent breaks.

  Never use with the period of use, take frequent breaks.

  If you shall pometr to your heads or any pain using Kurin, please stop immediately.

  If you shall pometr coming out of the Kurin, don't try to remove it. Keep it away from small children.
- Make sure that the correct adaptor is used at all times. Never force a connector into the port of Kurio. Ensure that the connector matches and that you have
- ositioned the connector correctly in relation to the port. o clean up the screen, simply use a soft damp cloth. Do not use alcohol, solvent,
- To creat up the schem, simply use a solit camp (colin. Do not use a colon), soveni, aerosol spray or abrasive (leaners to clean your Kurio.
   The product and the adapter should be periodically examined for conditions that may result in the risk of fire, electric shock, or injury to people and that, in an event of such conditions, the adapter should not be used and contact the Kurio support.
   It is advised that adults manage the charging of the product at all times. It is not recommended that children plug in and unplug the mains adaptor.

# B

# Kurio 45 touch

# **SETUP GUIDE**

Interface



Micro USB/Charge

Micro SD card slot

# • The handheld must be set up by an adult to ensure an appropriate level of

- The families I musers of the device.

  To turn off your Kurio handheld correctly, press the Power button until the pop up message appears onscreen, and then select "Power off". Avoid switching off the device by pressing and holding the Power button until the switching of the device by pressing and noting the Power button until the unit stops.

  • Do not fully discharge the battery (keep at 5% or more). Recharge it to full power regularly to preserve the battery.


  • Password Reselt: Tech Support may not be able to retrieve your Parental Area password, so please don't forget to note it in a safe place. In case of a lost password, the handheld may have to be factory reset and all personal
- Please connect your Kurio handheld to Wi-Fi frequently to receive and
- If you encounter any issue with your device, please do not return it to the store. Please review our FAQs & troubleshooting info or contact our tech support

Customer Service Hotline: 0844 324 6828

# Installation

# Kurio Parental Account Set up

- Select your language
   Select a Wi-Fi hotspot and connect to Wi-Fi (not mandatory but highly recommended)
   Set the correct date & time (if not connected to Wi-Fi)
- Select Normal mode
- Enter parental email address
   Enter a password for the Parental Area account. There are
- several password types available, such as text, pattern, of PIN. This is important to make sure the Parental Area is The Parental Area is now set! This primary account will
- use the Android Interface without any restricti
- Create a user profile for a child by following the directions below.



# **× 1** ? +



















# Create a Kurio User Profile: Step 1 of 2 - Profile Information

- · Press on the 'Create child profile' button.
- Name: Enter the user's name.
- Birthdate: Enter the user's birthdate • Gender: Select between boy and girl.

Note: Press the look icon to save the info you entered and move to the next step.

Attention: If you press the icon at any time while creating a profile, the setup of the profile will be cancelled and all information previously entered will be lost!



# Create a Kurio User Profile: Step 2 of 2 - Select a Profile Type

To help you create a user profile quickly, you can choose one of our predetermined 'easy setup' profiles, or customise each parental control yourself. Please note that in our Kurio settings, time management is set to off and we provide a default list of apps. Even when using an 'easy setup' profile type, you can adjust the profile settings at any time.

- Child Profile with Web Access: Allows the user to browse the web safely by using our Kurio Genius™ Internet Content Filtering System to block any inappropriate content. Internet Security Level settings are based upon the age of
- Child Profile without Web Access: No web access is allowed, but the child can use apps, meaning an application is allowed to open specific content from
- Educational profile: No web access is allowed and this profile will only show the educational apps by default.

  I will define the settings myself: If you select to configure the
- settings by yourself, other screens will appear to guide you through adjusting the settings.

The child's user profile is now complete!



# Kurio Parental Area Overview

### On the Parental Area dashboard, you can access: Profiles: Manage all user profiles on Kurio (modify, add, or

or email, and view your Kurio Serial Number.

Parental Area Main Menu

- · Settings: Adjust the main tablet settings (date, list of apps on Kurio, language, etc.)
- · Customer Service: Read our FAQ, report a bug, and contact
- Store: Search, purchase, and download more apps from the Kurio Store or download alternate Android™ app stores Parental Account: Change your Parental Account password



# Profile Main Menu

To modify a profile, use the following settings: · Profile information: Edit the user's birthdate, name, & aender.

- Internet Parameters: Adjust the security level from No Internet Access, Restrict Web Browsing to Specific Sites, Kurio Genius™ Internet Filtering System, Full Internet Access
- Profile Settings: Review and change the profile's general
- Time Management: Adjust the time control settings.
- · App Management: Review and change which applications can be used by the profile.



6

### **Internet Parameters**

- No Internet Access: No Internet access is allowed from the
- No Internet Access: No Internet access is allowed from the handheld. Apps can still access online content if an Internet connection is active.
   Restrict Web Browsing to Specific Sites: Restricts Internet browsing only to websites that appear on the Safe List of this profile. All other sites will be blocked.
   Kurio Genius™ Filtering System: Our advanced filtering system allows users to browse the Internet safely by blocking websites that may contain inappropriate content.
   Full Internet Access: Removes any and all restrictions to web
- Full Internet Access: Removes any and all restrictions to web browsing. Not recommended for a child user profile



7



# Tech Support & Warranty Information

- If you have any questions setting up or using your handheld, please visit www.kurioworld.com to find out more about Kurio, read our related FADs, and for any technical support. All of our products have a 1 Year Limited Warranty. In the unlikely event you experience any problems with your Kurio, please visit www.kurioworld.com/support/ to contact Kurio Customer Service. If the service representative is unable to solve the issue, he or she will provide instructions regarding how to have your Kurio serviced if it is under warranty.
- Please note that this handheld is warranted only to the original purchaser for a period of twelve months from the original purchase date, under normal use and service, against defective workmanship and materials. If the product is service, against celectric workinstans and intereast. In the product is damaged due to accident, improper or unreasonable use or maintenance, such as a broken screen, fall, water damage, etc., this damage is not covered by the warranty. Please still contact Kurio Customer Service for repair & replacement options, especially for a broken screen or other spare parts. Please visit www.kurioworkd.com for the full details of Kurio's 1 Year Limited Warranty.



Recycling
Waste electrical products and batteries should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority for recycling advice.
CAUTION - ELECTRICALLY OPERATED PRODUCT - As with all electric products, precautions should be observed during handling and use to product a product at all times and children shall NOT plug in and unplug the mains adaptator. ptator. nanual for further reference.

# Copyrights



GROUP UNITED KINGDOM

Warning! Permanent hearing loss may occur if earphones or headphones are used at high volume for prolonged periods of lime.

nation about Kurio, please go to www.kuriow tributed by InspirationWorks UK. ubsidiary of KD GROUP.



