

RAZER NABU X



DOWNLOAD THE
"NABU X UTILITY" APP



CONNECT YOUR BAND



LIVE SMARTER

TABLE OF CONTENTS

1. PACKAGE CONTENTS / SYSTEM REQUIREMENTS	3
2. REGISTRATION / TECHNICAL SUPPORT	4
3. SETTING UP YOUR NABU X	5
4. USING YOUR NABU X.....	8
5. CONFIGURING YOUR NABU X VIA THE UTILITY APP	11
6. SAFETY AND MAINTENANCE.....	24
7. LEGALESE.....	26

1. PACKAGE CONTENTS / SYSTEM REQUIREMENTS

PACKAGE CONTENTS

- Razer Nabu X
- USB charging cable
- Important product information guide

MINIMUM SYSTEM REQUIREMENTS


- iOS 7 / Android 4.3 device
- Bluetooth Smart (Bluetooth 4.0 / Bluetooth LE)

2. REGISTRATION / TECHNICAL SUPPORT

REGISTRATION

Sign up now for a Razer ID account to get real-time information on your product's warranty status. To learn more about Razer ID and all its features, visit www.razerzone.com/razer-id. If you are already a Synapse user, register your product by clicking on your email address at the Synapse application and select *Warranty Status* from the dropdown list.

To register your product online, visit www.razerzone.com/registration. Please note that you will not be able to view your warranty status if you register via the website.



Your product's serial number can be found here


TECHNICAL SUPPORT

What you'll get:





- 1 year limited manufacturer's warranty.
- Free online technical support at www.razersupport.com.

3. SETTING UP YOUR NABU X


1. CHARGE






Note: To turn ON your Nabu X you will need to plug it to a power source using the charging cable provided. Do not leave the Nabu X charging overnight. The approximate time to fully charge the Nabu X is 2 hours.

Status Indicator	Battery Level
	Fully Charged
	<100%
	<67%
	<15%

2. CONNECT



Status Indicator	Pairing Status
	Pairing
	Paired
	Failed


3. WEAR



4. USING YOUR NABU X

NOTIFICATIONS

The three LEDs will blink whenever you receive a new notification. Incoming Calls, Alarms, and Messages are represented by different colors.



You can change the color of these LEDs using the Nabu X Utility App.

CANCELLING NOTIFICATIONS

Messages will automatically stop after 3 alerts. Incoming Calls and Alarms will automatically stop after 30 seconds.



You can manually stop an alarm by doing a *Shake-To-Dismiss* gesture.

LOW BATTERY WARNING

When the battery level is below 15%, the Nabu X will vibrate and display a red blinking LED to indicate that it is time to charge your smartband. Once the battery level is below 5%, the Nabu X will vibrate again; this time the red LED will blink faster.



CONNECTIVITY

When the Nabu X displays a blinking red light in-between two blue lights, this means that the Nabu X is no longer within the reach of your device.




To re-establish a connection, simply open the Nabu X Utility App and bring the Nabu X closer to the paired device.

Caution: Sources that emit radio waves such as WiFi and Bluetooth can interfere with the connection process. Please avoid these sources whenever possible.

GOAL INDICATOR

Tap on the Nabu X twice to show your progress based on your set goal.




5. CONFIGURING YOUR NABU X VIA THE UTILITY APP

Disclaimer: The features listed here require you to log in to Razer Nabu X App. These features are also subject to change based on the current software version and your Operating System.

WELCOME SCREEN



The welcome screen highlights some of the features you will find on the Razer Nabu X.



Once you are ready to setup your account, tap *"I'm done. Let's get started"*.

LOGIN SCREEN


To sign up for a Razer ID account, you will need to provide an email or a mobile number, a password, and you will also need to verify the password. Once you have filled out the necessary fields, tap “SIGN UP” to continue.



If you already have a Razer ID account, tap “LOGIN” and input your email and password.

PAIRING SCREEN

The pairing screen will guide you in pairing the Razer Nabu X with your smartphone.





Simply follow the onscreen instructions until you have successfully paired the Razer Nabu X and your smartphone then tap *PERSONALIZE*.




PERSONALIZE SCREEN

The personalize screen allows the Razer Nabu X to become associated with you. The personalize screen also allows you to setup your user profile to be used by fitness apps that support the Razer Nabu X.



HOME SCREEN


The Home Screen offers a wide variety of features and customizability for you, your Razer Nabu X, and the Utility App.



Details


Listed below are the options you can find under Details:

- View your Nabu X's hardware information
- Enable data tracking
- Send a test notification
- Rename your Nabu X
- Update the firmware
- Unlink the Nabu X to your Razer ID



Band Double-Tap


Choose whether to show the battery level or your daily goals when you double-tap on the smartband.



Notifications


Listed below are the options you can find under Notifications:

- Choose the corresponding colors for your incoming calls, alarms and messages
- Enable Do Not Disturb mode
- Enable apps specific notifications
- Adjust the brightness of the LEDs
- Adjust the level of vibration



Alarm


Set the time and at which days the Nabu X will send you a reminder.



Sleep Mode

Listed below are the options you can find under Sleep Mode:


- Enable Sleep Tracking
- Enable Sleep Mode to automatically start and end
- Set the time at which Sleep Mode will start
- Set the time at which Sleep Mode will end



Social Settings


Listed below are the options you can find under Social Settings:

- Enable Handshake gesture for exchanging personal information
- Choose which social networking information you want to share
- Enable Pulse for interacting with friends and other Razer smartband users



DRAWER MENU

The drawer menu offers a wide variety of features and customizability for you, your Razer Nabu X, and the Utility App.



Listed below are the menu options and their corresponding functions:

Setup New Band - Pair a new Nabu X smartband with your mobile device

Connected Apps - Allow third party apps to use the information gathered by Nabu X

Marketplace - Find, download, and install apps for Nabu X

Help - Access the FAQ database to help you troubleshoot your Nabu X

About - View the Utility App's version as well as legal documentations

6. SAFETY AND MAINTENANCE

SAFETY GUIDELINES

In order to achieve maximum safety while using your Nabu X, we suggest that you adopt the following guidelines:

1. Should you have trouble operating the device properly, unplug and/or remove the device and contact the Razer hotline; or go to www.razersupport.com for assistance. Do not attempt to fix the device yourself.
2. Do not take apart the device (doing so will void your warranty) and do not attempt to operate it under abnormal current loads.
3. Charge the Nabu X in accordance with the recommended charging time and do not leave the battery charging overnight. Do not wear the Nabu X while it is charging.
4. Do not expose the Nabu X to liquids while charging. Exposing the Nabu X to these conditions may result in an electric shock.
5. The Nabu X is water resistant however; do not submerge the Nabu X in liquid for more than 30 min at a depth of more than 1 meter.
6. Do not tamper or abuse the Nabu X; including but not limited to dropping, crushing, excessive bending, puncturing, shredding, microwaving, incinerating, or inserting foreign objects into the Nabu X.
7. Do not use abrasive cleaners and/or harsh cleaning agents to clean the Nabu X.
8. Do not expose the Nabu X to extremely high or low temperatures such as leaving the Nabu X in direct sunlight or in snowy weather for extended periods of time.
9. Do not expose the Nabu X to open flames such as stoves, candles, or fireplaces.

10. Do not expose the inner band to organic solvents such as alcohol, acetone, and detergent.
11. Dispose the product in accordance with your local environmental laws and guidelines.

Prolonged contact may contribute to skin irritation or allergies in some users. If you notice any signs of skin redness, swelling, itchiness or other skin irritation, please discontinue use or wear the product clipped over a piece of clothing.

Continued use, even after symptoms subside, may result in renewed or increased irritation. If symptoms persist, consult your doctor.

Please follow these care and wearing tips:

1. Clean and dry your Razer product regularly, particularly in areas in contact with the skin. Use a clean, damp cloth. Do not wash product under a faucet.
2. Wear your Razer product loosely enough to allow air circulation. Review the sizing guide.
3. Use skin care products sparingly on the areas of the skin covered by your Razer product.
4. Take the product off from time to time to clean it and allow for your skin to be uncovered.

BATTERY

The Nabu X contains an internal, lithium-ion polymer rechargeable battery. In general, the life expectancy of this battery depends upon use. If the battery does not charge after several attempts, it may be non-operational and you may need to contact customer support. Do not attempt to replace the Nabu X's battery yourself.

TRACKING

The accuracy of our sensors and associated calculations (i.e. distance traveled and calories burned) will vary with use.

7. LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

© 2014 Razer Inc. All rights reserved. Razer, For Gamers By Gamers, and the triple-headed snake logo are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States or other countries. All other trademarks are the property of their respective owners. Actual product may differ from pictures. Information is correct at time of printing.

iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license. Apple, the Apple logo, and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Android and Google Play are trademarks of Google Inc.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Razer is under license.

Razer Inc. (“Razer”) may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Nabu X (the “Product”) may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit www.razerzone.com/warranty.

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer’s liability exceed the retail purchase price of the Product.

COSTS OF PROCUREMENT

For the avoidance of doubt, in no event will Razer be liable for any costs of procurement unless it has been advised of the possibility of such damages, and in no case shall Razer be liable for any costs of procurement liability exceeding the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.