# partriTEC



TECShow

A division of
AMERICAN

Int. Corp. www.american-pro.com Our partriTEC advantage is obvious, it is equal to 54pcs 1W RGB LEDs, its operation is much easier, moreover, it can make very even color mixing, bright, colorful and dynamic light scenery effects. It is widely applied to entertainment halls, clubs and stages etc. Please read the manuals before operation.

#### A. SPECIFICATION:

1. Weight: 2.6kg

2. Size: 31×23×23cm

3. Power input: AC 220V~, 50Hz

4. Wattage: 65W

5. LEDS: 24pcs tri-3W/18pcs tri-3W

6. Beam angle of LEDs: 40 degrees.

7. 3PIN female XLR socket and 3PIN male XLR socket

8. Built-in microphone

9. Built-in programs, auto run, sound active, DMX mode and M/S mode.

#### **B. OPERATION:**

After power on, Press "MODE" button to activate the main menu: Built-in programs mode, Autorunning mode, DMX mode, Slave mode, Sound active mode.

"SETUP" is to set the relative specification for current mode.

"UP" is to add the value of current specification.

"DOWN" is to decrease the value of current specification.

Built-in programs-- running one of the built-in programs

Auto run—running built-in programs one after another in continuous loop.

DMX mode--controlled by DMX controller

Slave mode—the projectors in this mode will be synchronously run with the projectors in master mode

Sound mode-- running by sound - activated

## 1. Built-in programs mode

With our 3W LED PAR64, you can select 7 different built-in Programs.

Press "MODE" button, when it shows: **Pr.1** (Pr01), it means you can select the 7 built-in programs by pressing "UP" "DOWN".

When it is Pr01 which is for static color, press "SETUP" button for the first time, it shows 7rGb, then select 7 different static colors by pressing "UP" "DOWN". press "SETUP" button for the second/third /fourth time, it shows r255/G255/b255, then you can choose the different color grade by pressing "UP" "DOWN". press "SETUP" button for the fifth time, it shows FS00, then you can set Flash frequency.

Pr02 is for 7 colors fading, Pr03 is for seven colors jumping, Pr04 is for colors dream, Pr05 is only for red color fading, Pr06 is only for green color fading, Pr07 is only for blue color fading. You can set the running speed and flash frequency by pressing "SETUP" "UP" "DOWN".

#### 2. Auto run mode

Press "MODE" button, when it shows: **RUTO**. (AuTo), press "SETUP" button for the first /second/third time, then it shows: SP00/FS00/Fd00, then you set running speed/flash frequency/fading speed by pressing "UP" "DOWN".

#### 3. DMX mode

You can control the devices individually via your DMX-controller.

Press "MODE" button, when it is **d.[]** [] **1**, it is DMX mode. You can set DMX value by pressing "UP" "DOWN". If press "SETUP" button, it shows: **d-P** (d-p1) or **d-P** (d-p2), You can choose different DMX mode by pressing "UP" "DOWN".

DMX mode 1:d-P1

CH1	CH2	СНЗ	CH1	CH2
Red 0-255	Green 0-255	Blue 0-255	Red 0-255	Green 0-255

#### DMX mode 2:d-P2

CH1	CH2	СНЗ	CH4	CH5
Red 0-255	Green 0-255	Blue 0-255	Flash 0-255	Dim 0-255

### 4. Slave mode

--Press "MODE" button to select 51 Au to run the slave mode.

#### 5. Sound active mode

--Press "MODE" button to select sound active(SU31) to be run, press "SETUP" button, then you can press "UP" or "DOWN" buttons to adjust the sensitivity Sensitivity: SO01-SO31



TRUSTING RESULTS

# www.american-pro.com

AMERICAN PRO develops & improves products constantly.

For this reason, the specifications and consigned information in the present user manual can be modified without notice.



A division of

AMERICAN

Int. Corp.

www.american-pro.com