Quick Start User Manual for Mac OS

Overview

Minimum System Requirements for Installation Using Pulse IR Utillity :

- Processor: 233MHz Intel Pentium or higher
- RAM: minimum 128MB
- Mac OS X Leopard 10.5 or higher up to Mavericks 10.9.4
- Java 1.6 or higher

Installing and Using Pulse IR Controller Utility Program

Connecting Pulse IR Touch System

Pulse IR system is a plug and play HID-USB Device which automatically manages device drivers, eliminating any manual installation or upgrading of the drivers.

Connect the Pulse IR unit to a USB connector. Then select |"Applications Utilities|System Information | USB" to verify that the touch-screen is recognized as a USB device.



Launch Pulse IR Controller Utility Program

If you do not have Pulse IR Touch Controller utility for Mac, please download this program from the link, <u>https://www.hightail.com/download/ZUcxanZoZ1BrYUNGa2RVag</u> and Extract the "PulseIRController_Mac-(version #).tgz" tar file by using terminal command,

\$ tar -xvzf PulseIRController_Mac-0.3.0.tgz

, and locate and execute "PulseIRController_mac.jar" application. (Warning: Connect the touch screen to the PC before launching this application.)

000	PulselRUtility		
		Q.	?
▼ 장비	이름	▲ 수정일	크기
Indplus의 MacBook	A PulselRControler(Ver.1.0	오늘, 오후 1:59	385 KB
Macintosh HD	A PulseIRDemo(Ver.1.0)	2011. 6. 7. 오후 6:18	446 KB
🔲 iDisk	TUIODemo(Ver.1.0)	2011. 6. 2. 오후 3:02	754 KB
▼ 공유			
aaa-pc			
asm-pc			
Jang-pc			
honghee-pc			
mvixbox			
rnd-nas01			
rndplus-pc23			
💮 전체			
▼ 위치			
🔜 데스크탑			
🎒 도큐멘트			
🕂 응용 프로그램			
- Dreabau	I I C)) + + (
	3개 항목, 65.65 GB 사용 :	가능	11.

How to Configure the Touch Screen using PulseIR Utility Program

Parameter Setting	g		
Touch ON/OFF	🕑 On	O OFF	
Touch Mode	 Auto 	◯ Stylus	O Mouse
Mouse R-Click	Long Down	🔘 Disable	
Touch Action	Drawing	O Touch Only	
Rotation	• 0 • •	90 🔘 180	0 270
Touch Object Siz	ze(mm) 0 min	~ 0 max (if 0 -	> disable)
Click Point Corre	ection Radius(mm)	0 Use Me	ouse Over Delay
Drawing Spe	eed Up(Ambient Ski	^{p)} C	Default Setting
Calibration/Touc	h Area Setting		
	Touch	100	Porot

First note that your touch screen is listed on top table. Click on the device and the parameter setting will update for the current configuration setting of the touch screen. You must click "Apply" button to apply the change of configuration setting after changing the configuration setting.

Touch On/Off

This function enables and disables the touch detection for special testing and set-up needs.

Touch Mode

Mode	Purpose
Auto	Automatic OS Detection for OS running(Windows, Linux, Mac)
Stylus	Supports <i>stylus</i> operation in Android OS/Multi-touch operation in Linux
Mouse	Single-Point Mouse mode

Mouse R-Click (Apply only in Mouse Mode)

Setting	Effect
Long Down	extended touch triggers the Mouse R-Click
Disable	do not support Mouse R-Click event

Touch Action (Apply only in Mouse Mode)

Setting	Effect	
Drawing	Touch and Drawing support	
Touch	For simple touch detection only – No continuous tracing for	

Touch Rotation

For special mounting configuration relative to display orientation. If the touch screen is attached to the display in normal orientation, the rotation of the display is controlled by "Display Setting" dialog box. However, if the installation requires mounting the touchscreen in different orientation relative to the display, then this *Rotation* setting can be used changed to suit the need. Please click the link, https://www.hightail.com/download/UIRSd0VOWkJwTVhvS3NUQw for "Rotation" setting instructions

Touch Object Size

This function controls the size of object to have the touch detected. The only object the size is between Min. and Max. is able to be detected. If both of Min. and Max. are set to "0", this feature is disabled. The "80" or more value is recommended for the "Max" setting value.

Click Point Correction R

This function compensates the touch error which may be happened by inaccurate touch. The radius of touch point should be set to activate this feature. The radius of touch point should be set to activate this feature. The "3" mm is recommended for touch screens with the 55" or less size and "0" mm for touchscreens over 55".

Use Mouse Over Delay

This function is supported in only Mouse touch mode. Check this to apply "Time Delay" when touching down a menu button.

Drawing Speed Up(Ambient Skip)

This function increases the drawing speed by 1-1.5 times more than the normal speed. This function is recommended to use under the environment of no or weak ambient light.

Calibration button launches a program for manual calibration when an offset is required. To compensate for misalignment between the touch screen and the display, launch this program and touch the 4 points as they are presented.

Launch PulseIR TUIO Interface Utility Program

If you do not have Pulse IR TUIO Interface utility for Mac, please download this program from the link, <u>https://www.hightail.com/download/ZUcxanZoZ1B6NE53SGNUQw</u> and Extract the "PulseIRTuioServer_Mac-(version #).tgz" tar file by using terminal command,

\$ tar -xvzf PulseIRTuioServer_Mac-x.x.x.tgz

, and locate and execute \$ PulseIRTuioServer by using the terminal command. (Warning: Connect the touch screen to the PC before launching this application.)

Usage: PulseIRTuioServer [option] [host] [port]

[host] hostname or ip address. (default: 127.0.0.1)

[port] port number. (default: 3333)

[option]

-d : mouse report disable.

-h : print this message.

In PulseIR Multi-Touch mode, this tool enables the touch screen to work as a TUIO client device.