



MAXPOWER CX612 User's Manual

Importance (Please read carefully before using this product)


- Thank you for purchasing our product.
- To get the most from your CX612, please read this manual thoroughly.

Product Specifications


Model	CX612
Input Voltage	AC100V - 240V (50Hz~60Hz)
Max. Output	5V 2.4A
Total Output Current	12A
Dimensions	103.0mm × 72.0mm × 26.5mm

Operating Instructions

1. CX612 Smart USB Charger



2. To Charge a Digital Device with CX612



Cautions

- Confirm the input voltage of the digital device before charging.
- CX612 and its accessories are not toys for children and infants.
- Do not use CX612 near a fire or in a high temperature condition.
- Do not disassemble or modify any parts of CX612.
- Use CX612 only in dry condition. Keep away from rain, snow or excessive moisture.
- Do not operate a damaged CX612.

Technical Support & Customer Service

For technical questions or inquiries, please contact your local authorized dealers.

Maxpower USA

2033 Gateway Place, Suite 500
San Jose, CA 95110, USA

Customer Service (US / Canada Toll Free) :

1-800-390-0193

www.maxpower.us.com

Version 1.0
Copyright © 2015 Maxpower. All Rights Reserved.

D15985-UM-ENG