

## Precision Weighing Solutions

**Escali**<sup>®</sup>



Model: Pana

User Manual

[www.Escali.com](http://www.Escali.com)

Thank you for purchasing an **Escali** Digital Scale.

Please read the following operation information to ensure the proper function of your new scale.

### How to weigh:

- 1) Press the "On/Tare/Off" key. All display segments will appear for approximately 2 seconds before resetting to zero.
- 2) Press the "g/oz" key to select the units (grams, pounds+ounces or ounces).
- 3) Place item slowly on the platform.
- 4) Press the "On/Tare/Off" key to turn the scale off.

### How to measure by volume:

Your scale will let you measure ingredients by volume. The scale is pre-programmed with 99 codes that correspond with different ingredients. See the list of ingredients in the back of this manual to find the code for the ingredient you are measuring.

- 1) Press the "On/Tare/Off" key.
- 2) Press the "Vol" key to switch the scale to the volume mode. Cups / tbs will now show on the display.
- 3) Enter the 2 digit ingredient code from the list in the back of this manual. The scale will confirm your entry by displaying the code in the left top corner of the display.
- 4) Place item slowly on the platform, your scale will now show your ingredients measured in cups and/or tablespoons.
- 5) Press the clear button to re-enter an ingredient code.

Your Pana scale will display in commonly used increments of cups; 1/8, 1/4, 1/3, 1/2, 2/3 and 3/4, and in 1/2 tablespoons

### How to use the Tare feature:

This feature allows you to obtain the exact weight of an item in a container, by subtracting the weight of the container. It lets you add consecutive ingredients to the container, and weigh each ingredient individually.

- 1) Press the "On/Tare/Off" key.
- 2) Select weighing unit (oz, lb+oz, g) or volume (cups + tbs).

- 3) Place the container, without the item, slowly on the tray.
- 4) Press the "Tare" key. The weight of the container will be removed, and the display value will reset to zero.
- 5) Slowly add the item to the container. The display will show the weight or volume of the item only.
- 6) You may continue to determine the weight or volume of each additional item as they are added by repeating step 4 & 5.

**How to clear the Tare feature:**

Remove all items from the tray. A negative weight will appear on the display. Press the "TARE" key again to reset the scale to zero.

**Battery Replacement:**

This unit comes with a low battery indicator. Please replace the battery when the low battery symbol appears.

**Online product demonstration:**

See [www.escali.com/pana.html](http://www.escali.com/pana.html) for additional information on your Pana Scale. Click on Product demonstration to see and experience an interactive online product demonstration.

**Do not place overweight items on scale:**

Weighing items over the maximum weight capacity will cause an Error code "Err" to display. Immediately remove overweight items to avoid causing damage to your scale.

**Auto Shut Off:**

Your scale will automatically turn off after 10 minutes of non-use. When operating the scale on the optional power adapter it will stay on till it is turned off.

<b>Power Source:</b>	9-volt battery or optional AC/DC adapter (To prevent damage, only use an Escali adapter or the warranty will be void).
<b>Dimensions:</b>	7.5" x 9.75" x 1.25" (19cm x 24cm x 3cm)
<b>Graduation:</b>	1/10th ounce (0.1 oz) or 1 gram (1 g)
<b>Capacity:</b>	13 Lb or 6000 gram
<b>Weight Modes:</b>	gram, ounces, and pounds+ounces

**Important additional information:**

- 1) Your scale is pre-programmed with 99 codes for a variety of ingredients and food items. King Arthur Flour® and Escali® have done extensive research to arrive at the pre-programmed data. Data however are average values, and may differ from the ingredients you are using.
- 2) Make sure your scale is at room temperature and on a stable horizontal surface free of vibration.
- 3) This scale is not waterproof. Do not expose to moisture.
- 4) This scale is a precision instrument, it must be handled with extreme care. Avoid rough treatment, shaking and vibration.
- 5) Do not disassemble this scale or the warranty will be void.
- 6) The display value may be affected by electromagnetic disturbances such as operating near a radio. If this occurs, move the device that is causing the disturbance and turn the scale off and restart.



Manufacturer's lifetime limited warranty.  
See [www.escali.com](http://www.escali.com) for full details.

Escali's liability is limited to two (2) times the cost of the product.

© Copyright Escali Corp, 2012; applies to all content of this manual and all data in the scale.