

CML

Cusack More Louder



LEVEL - This is the overall level of the affected signal. The range is from no boost, to over 25dB of clean boost.



IN - This is the input to the pedal. This jack is on the right side of the pedal.



OUT - This is the output of the pedal. Plug this either into your amp or into any other effects you want after this effect. This jack is on the Left side of the pedal.



Bypass Switch - Kick the switch to change from effect on to effect off.



DC Power Jack - Used to power your pedal from a DC supply. This has the same pin-out as the standard pedal supplies, tip is ground, sleeve is 9V. Use a filtered supply, especially on high gain overdrive and distortion pedals, since they tend to amplify power supply noise.



Bypass Mode Toggle - This toggle switch lets you select between either buffered or true bypass. To the left is buffered, to the right is true bypass. This switch is functional only in bypass mode. When the pedal is engaged, it is automatically buffered.



Status LED (Red/Green) - When the effect is on the LED is Red. By default the LED is Green when bypassed. To have the LED off in bypass HOLD the Bypass Switch for several seconds until the LED Blinks. Hold again for several seconds to turn the LED back on in Bypass.

Power Consumption - ~8mA.

