



Users Manual

Model No. BMR-20

Product Introduction:

The *Bluelink*TM2 Music Receiver simply connects to the Line-In or Aux port on your speaker system or plugs directly into the dock connector on your docking station. You can then stream audio from your Bluetooth enabled cell phone or MP3 player to your speaker system. Enjoy the convenience of having your music source in the palm of your hand and listening to it through your stereo.

Package Contents:

- *Bluelink*2 Music Receiver
- QuickStart Guide
- Audio cable & RCA adapter
- Power supply

Requirements:

A Bluetooth enabled cell phone, PC, Laptop, MP3 player or other music source that supports the **Bluetooth A2DP and AVRCP profiles**.

Receiver Setup:

Note: The term "phone" refers to the Bluetooth enabled MP3 player, PC, cell phone or other device that is being used to stream music to the *Bluelink*2 Receiver.

- 1: **Auto/Manual connection:** Set the switch on the top of the *Bluelink*2 to RX Auto or RX Man.
RX Auto: When the phone comes in range (15-30ft) of the *Bluelink*2 the units will automatically connect and all audio will play through the *Bluelink*2
RX Manual: The user must press the button on the front of the *Bluelink*2 to connect with the phone or make the connection from the phone's menu. The units will stay connected until either: 1) they are separated by more than 50 feet. 2) the *Bluelink*2 is unplugged from power. 3) Bluetooth is turned off on the transmitter.
- 2a: **Docking station** - Plug the *Bluelink*2 receiver directly into the dock. The docking station will also provide power to the *Bluelink*2 so no other connections are required.
- 2b: **Non Docking station** - Plug the audio cable into the "Audio OUT" on the top of the *Bluelink*2 Receiver. Connect the other end of the audio cable to the Aux-in or Line-in on the stereo system. If the stereo has RCA connectors then use the included adapter to convert the audio cable to RCA. Connect the power supply to the bottom of the *Bluelink*2 and plug the power supply into an outlet.
- 3: **Set the Bluetooth name** (optional) - If you are using multiple *Bluelink*2 units you can change the Bluetooth name to provide easy identification of which unit you are connected to.
 - A. Press and hold the button on the front of the *Bluelink*2 for 3 seconds. The LED's will start to sequence through the settings 1, 2, L, B, K, O.
 - B. Press and release the front button when the setting you want to use is lighted.Note: If the phone reports the wrong Bluetooth name then select "Forget this device" (or similar) and repeat step 4.
The settings stand for:
 - 1 - BMR1
 - 2 - BMR2
 - L - Living Room
 - B - Bedroom
 - K - Kitchen
 - O - Office

- 4: Pair your phone to the **Bluelink2** Receiver. Follow your cell phone users guide on how to search and add a Bluetooth device. Generic instructions are: From your cell phone:
- Turn the Bluetooth functionality ON.
 - Make the device visible
 - When the "BMR 1" (or other selected name) appears on your cell phone select and pair with the password "0000".

The **Bluelink2** is in pairing mode when the blue power light is blinking quickly. The **Bluelink2** is connected when the blue power light blinks every 5 seconds.

Transmitter Setup:

The **Bluelink2** can transmit the same audio to 2 devices at once.

- Turn on the Bluetooth receiver and set it to pair (If using another Bluelink2 set to RX and plug in).
- Set the switch on the top of the **Bluelink2** to TX.
- Plug in the Bluelink2
- The power light will quickly flash red/blue. This indicates the unit is in pairing mode. When the connection is made the transmitter will flash red every 5 seconds.

To connect a second Bluetooth receiver:

- Turn on the second Bluetooth receiver and set it to pair (If using another Bluelink2 set to RX and plug in).
- Double click the button on the Bluelink2. The power light will quickly flash red/blue. This indicates the unit is in pairing mode. When the second connection is made the transmitter will flash a double red every 5 seconds.

Other features:

Using **Bluelink2** in the car:

- A) My car has an Apple dock connector.

The **Bluelink2** can be plugged directly into the Apple dock connector on many late model cars. No other connections are required. The **Bluelink2** will use the dock connector for both power and audio. On some car stereo's the play, pause, next track and last track controls will also work through the **Bluelink2** to control the mp3 player.

- B) I'm using the car stereo Aux-In or cassette adapter.

The **Bluelink2** can be powered through its USB port or docking port. Use a USB power supply (not included) that plugs into the cars power plug to power the **Bluelink2**. Then connect the audio cable.

Using **Bluelink2** with a computer:

The **Bluelink2** will work with many computer Bluetooth transmitters. The **Bluelink2** does NOT require its own driver.

Charging an iPad or iPhone:

The **Bluelink2** will charge as iPhone or iPad with the addition of a USB to Apple connector cable (not included). Plug the included power supply in and then plug the Apple cable into the USB port on the **Bluelink2**.

Caution: Only charge an iPhone or iPad using the included power supply. Do not charge an iPhone or iPad when the **Bluelink2** is plugged into a docking station or other power supply.