

English

■ For Unpacking

- Take out the speaker by holding the bands.
- Do not touch the speaker grille or speaker units; otherwise, it will be damaged.

中文

■ 拆開包裝時的注意事項

- 請提拿捆綁帶將揚聲器自包裝箱內取出。
- 請勿碰觸揚聲器的罩網或揚聲器裝置；否則可能將其損壞。

