




### Coat Hanger Hook ▲

### Folding Front Seats ▼



### Manual Seat Adjustment ▼


- Backrest tilt
- Raise/lower front edge of seat cushion
- Raise/lower seat height

### Manual Seat Travel ▶

Lift bar. Slide seat

### Seat Adjustment ▼ Power Driver's Seat

- Lumbar support
- Seat and sideview mirror memory



### Audio System HU-850/HU-650 ▼

#### Radio presets

Tune to desired station using radio scan buttons  
Press and hold a preset button (1-6) to memorize

#### Radio Auto-store

(A useful feature when in an unfamiliar area)

- Press and hold AUTO to temporarily store up to ten strongest stations
- Briefly press AUTO, or use the steering wheel seek buttons to move between auto-stored stations

#### AM/FM

Press to choose AM1/2, or FM1/2/3

#### 6-CD changer (HU-850)

To load CDs:

- Press the CD button
- Choose an empty slot using a button 1-6
- Wait for "LOAD DISC"
- Insert CD

#### Seek

Press briefly to move to next strong station or next CD track.  
Press and hold to tune manually, or to move forward or backward within a CD track.



#### Dolby Surround Pro Logic II (HU-850)

Dolby Surround Pro Logic II is optimized for the driver. With backseat passenger use 3-channel.

#### Source

Turn to select accessory 10-CD changer, iPod adapter, or satellite radio

**Courtesy Lights**  
During daylight, interior lights do not activate when door is opened.

### Steering Wheel Tilt/Telescope Adjustment ▶

WARNING: Never adjust while driving.



### Center Armrest Console and Cup Holders

Press button on right half of cover panel to expose additional cup holders.  
Press button on left half of cover panel to reveal deep storage bin.



### Moonroof ▼

- Auto open — Pull briskly rearward and release. Moonroof opens to comfort position (3/4-open as shown)
- Fully open — Pull rearward and hold
- Auto close — Push briskly forward and release
- Ventilation — With moonroof closed, push upward on switch and hold to open. Pull downward and hold to close.



### HomeLink ▼

Programmable garage door opener



### ▲ Passenger Airbag Off

Weight sensor in seat will disable airbag if front passenger seat is occupied by low weight occupant or object

### Refueling

Filler door on right, rear fender.  
With vehicle stopped and unlocked, press the button below the headlight switch to unlock the filler door. Filler door relocks when vehicle begins moving again.  
Close filler cap tightly after refueling. CHECK ENGINE light may come on if vehicle is fueled with engine running or if cap is not closed tightly afterward. Listen for closing "click."

### Recommended Octane Rating:

Use 91 octane for rated performance and fuel economy. Your vehicle can be safely operated on 87 or higher octane.

## VOLVO

Volvo Cars of North America, LLC  
Customer Service (US): 1-800-458-1552  
Customer Service (CAN): 1-800-663-8255  
www.volvocars.us  
KS60-08A 25.000.12.07 Printed in U.S.A.

**VOLVO S60** KEYS TO ENJOYING YOUR S60



### Key and Remote


- Unlock
- Press twice to unlock all doors
- Lock
- Driver's seat and side-view mirror memory
- Press twice to pop open trunk. Press LOCK to re-lock.
- "Panic" alarm
- Approach lighting

### Instrument Panel

**DSTC**  
 Rotate bezel until DSTC ON appears in driver information display  
 Press RESET to temporarily turn off

**Text window**  
**Trip computer**  
 "Miles to zero" is not a fuel gauge but an approximation of available range based on driving conditions.

**Home Safe Lighting**  
**Headlights**  
 ○ Daytime running lights, no high beams  
**Fuel filler door unlock**  
**Hood release**



The purpose of this guide is to afford a quick and easy orientation to your new Volvo. Please refer to your owner's manual for detailed information. Optional features shown.



- ### Center Console
- Electronic Climate Control AUTO  
Balances airflow. Maintains chosen cabin temperatures.
  - Optimum Defog and Defrost  
Press defrost button to direct airflow to windows
  - Activate rear window/side mirror heater coils
  - Raise temperature settings
  - Active Bi-Xenon Headlights On/Off
  - Automatic transmission  
For faster downshifting when passing, depress the accelerator pedal quickly.
  - Winter mode — On slippery roads, use Winter mode when starting from a standstill.

- Wipers
- Rain Sensor  
Press to turn on  
Adjust sensitivity with thumb wheel  
Turn off before entering a car wash
- Windshield and headlight wash -  
Pull stalk toward steering wheel

- ### Audio Controls on Steering Wheel
- Audio volume
  - Seek preset radio stations or change tracks on a CD



- ### Navigation System
- (see separate user manual)
- Press any button to activate VNS.
  - Enter to select highlighted choice
  - Menu navigation control pad

**Following a cold start —**  
 For a short time, your car will idle at higher engine speeds. This warms your car's systems to minimize average exhaust emissions.



### Automatic Locking - Enable/disable

With the key in position I or II:  
 Press and hold the central locking button in the driver's door control panel. A message will appear in the driver's information display.

When automatic locking is enabled:  
 All doors will automatically lock when vehicle begins to move  
 To unlock a door, pull interior door handle. To unlock all doors, press the central locking button on the driver's door control panel.

- ### Folding 60/40 Rear Seat
- Return head restraints to upright if lowered
  - Pull seat back release handles in trunk
  - Fold seat backs forward

- ### Folding Rear Outboard Head Restraints
- Lower for visibility when backing up.
  - Keep upright when seats are occupied or seat backs are folded down.

**Paint Care**  
 Car washing and waxing is fine. Do not use abrasives or electric buffers for first year.

### Adjustable Rear Center Head Restraint



### Folding Rear Outboard Head Restraints



### Rear Armrest Console with Storage and Cup Holders

- Storage bin
- Dual cup holders



### Trunk Emergency Release Handle (U.S.A.)



### Long Cargo Pass-Through

- Lower center armrest using sliding latch in trunk

