

Tweakers[®] Rock

Introduction

Thank you for purchasing The Tweakers Rock Bluetooth speaker. Its compact design will bring you ultra-portability whilst delivering powerful bass and impressive sound, so enjoy the world of power rhythm and harmony. This manual will assist you to operate your speaker. Please read it through before using the speaker.


Overview

Ontop⁺ speaker works with Bluetooth technology to connect Bluetooth devices, such as mobile phone, music players, notebooks, which enable you to:

- 1) Wirelessly listen music ultra bass and clear sound.
- 2) Handle phone calls securely and safely on driving.

1

User interface of Ontop⁺ Speaker:



Technical specification:

| | |
|-------------------------|-------------------|
| Product Name | Tweakers Rock |
| Bluetooth specification | Version 3.0 class |
| Charging Time | 3 hours |
| Speaker Output | 3W |
| Battery Capacity | 430mah |
| | |

Charging/Pairing/Connecting

Please follow the coming three steps before using Ontop⁺ speaker:

- 1) Charging The Rock

- 2) Plug one end of the USB cord to a 5V USB power adapter or computer/notebook device and the other end to Ontop⁺ speaker.
- 3) While charging, LED is red; when it turned blue, then the speaker is fully charged.

Note:

- ✧ When the LED flashes with beep, it indicates the battery level is low, so please charge it.
- ✧ Charging temperature range -20 to +50℃
- ✧ Charging time: About 1.5 hours.

Pair/connect Ontop⁺ speaker to Bluetooth device

- 1) Power on The Rock, the speaker will automatically reconnect to last “paired” Bluetooth device.
- 2) First time using Ontop⁺ or the last paired Bluetooth device is not existed or not within effective range(10 meter).
 - a) Enable Bluetooth function on your phone or the other device.
 - b) Search for new Bluetooth device until “Tweakers Rock” appears in the searched Bluetooth device list on your phone/device.
 - c) Select “Tweakers Rock”
 - d) Enter pass code “0000” to pair(if required) and connect Ontop⁺ speaker to your device.

Note: Ontop⁺ speaker LED will turn off if no Bluetooth device connected within 5 minutes.

Call handling

- 1) When you receive a call, you hear a ringing tone from the speaker.
- 2) To answer the call, press the answer key lightly.
- 3) To reject an incoming call, press and hold the answer key for 2 to 3 seconds until you hear a beep and let go.
- 4) To end a call, press the answer key lightly, or wait for the other party to hang up.

Volume control

Short press “+” is volume up.

Short press “-” is volume down.

Line in port

If there's no Bluetooth function on your phone or music player devices, you can connect device by audio cable.

Package content

Bluetooth speaker, user manual, USB cable, Audio cable.

Care and maintenance

- 1) Keep all accessories out of the reach of children.
- 2) Keep the device dry. Liquids or moisture can contain minerals that will corrode electronic circuits. If your device does get wet, allow it to dry completely.
- 3) Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components will be damaged.
- 4) Do not store the device in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- 5) Do not store the device in cold areas. Usually, when returns to normal temperature, moisture can damage electronic circuit boards.

- 6) Do not attempt to open the device.
- 7) Do not drop, knock, or shake the device. Rough handling may break circuit boards and its mechanism.
- 8) Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device.
- 9) Do not paint the device. Paint can clog the moving parts and may cause function ineffective.

--- End ---