

User's manual. P1

(PL) Elektroniczny papieros P1.

Zestaw zawiera: Bateria manualna P1, 1100 mAh -1 szt.

Clearomizer P1 -1 szt. Ładowarka USB,

Oryginalna polska instrukcja. Karta gwarancyjna

(D) E-zigarette P1.

Im Set enthalten: P1 Akku 1100 mAh, manueller Taster -1 st.

Clear atomizer P1 -1 st. USB Ladestick

(GB) Electronic cigarette P1.

The set includes: P1 Battery (manual), 1100 mAh -1 item

Clear atomizer P1 -1 item USB charger

P1 was designed for thrifty user looking for savings as compared to regular smoking. P1 stands out with its very attractive price, a modern, strong and reliable battery and easy operation, thanks to the P1 clearomizer. The P1 is yet another P1 series product, known for their renowned P1 liquid series. Before using the product, read the manual.

1. Construction, assembly and use.

The e-cigarette consists of a battery and the P1 clearomizer. Fill the clearomizer with nicotine liquid and attach it to the battery. Fill the clearomizer directly from a bottle or a syringe (unscrew the bottom part of the clearomizer, tilt it and slowly pour in the liquid). CAUTION! After the first refill, wait about 5 minutes, until the liquid evenly penetrates the device. Do not pour the liquid into the central opening, as it will escape the reservoir. When e-smoking, make sure the liquid is at proper level. The heating unit wears out and is a replaceable component. If the taste changes, tilt the clearomizer several times so that the nicotine liquid spreads evenly, or replace the heating unit with a new one. After a few days, the liquid in the tank may become darker. If this happens, pour out the remaining liquid and place the clearomizer upright for a few hours to drain. To begin e-smoking switch the battery on (see description below), assemble the e-cigarette, push the button on the battery (a LED will light up) and inhale slowly and deeply.

2 Batteries and charging

To turn on / block / unblock the battery, quickly press the battery button five times. The battery is charged via a USB cable. Connect the battery to the USB charger and connect it to the mains. The button will blink 5 times and the diode's color will change from green to red. The battery is fully recharged when the diode's color changes from red to green. An empty battery should be completely charged in 3-4 hours (even if the LED turns green sooner, please leave the battery in the charger for about 3 - 4 hours). Store the battery in a dry place. Charge the battery in room temperature. CAUTION! Before you use the e-cigarette for the first time, charge the battery for at least 8 hrs. Do not use other chargers with the battery. Other chargers may use different voltages, which may damage the battery, reduce its life or even make it explode.

3. Safety and warranty

Use tissues or cotton swabs for cleaning the threads. Do not store the battery in direct sunlight, in places with extreme temperatures or in high humidity. Warranty is waived if the method of use does not follow the instructions in the manual or non-original parts are used. Keep the P1 kit parts away from items such as keys, etc., to prevent it from dents or even complete damage. In case of any problems please contact your P1 dealer. Do not attempt to repair any of the parts - only the service is authorized to carry out repairs. Products damaged as the result of attempts to open them are not subject to warranty. If you experience any side effects, immediately stop using the e-cigarette and contact a physician. Remember - use only original parts, accessories and liquids! Recommended brands: P1, Mild, Volish, Provog, LiQueen, drJack, Aromativ.

CHIC Sp. z o.o. Sp.k.
Al. Wojska Polskiego 23c
63-500 Ostrzeszów
Poland, Europe
Ph.: 0048 (62) 738 88 88
NIP: PL9721147850
www.eSmokingWorld.com

Made in P.R.C.

