


For Models: KSBS25INWH01, KSBS25INBT01, KSBS25INBL01, KSBS25INSS01
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


CABINET PARTS

For Models: KSBS25INWH01, KSBS25INBT01, KSBS25INBL01, KSBS25INSS01
(White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	11	3400243	Screw	24	489084	Screw
	2315217	Use & Care Guide	12	2223520	Hinge Assembly, Bottom-RC	25	2223460	Hinge Assembly, Bottom-FC
	2223419	Service & Wiring Sheet	13		Filler, Wrapper	26		Button, Water Filter
	2315150	Energy Guide		2223893W	White		2260503W	White
	628370	Modular Ice maker Service Sheet		2223893T	Biscuit		2260503T	Biscuit
	2223996	Installation Instructions		2223893B	Black		2260503B	Black
2		Front Roller Asm	14		Grille	27	2260526	Housing, Water Filter
	2306950	Left Side		2223514W	White	28	4396711	Water Filter
	2306951	Right Side		2223514T	Biscuit	29	2223387	Pin, Roller(4)
3	2223263	Strap, Roller	15	3400108	Screw	30		Cap, Water Filter
4	2306949	Roller, Rear (2)	16		Hinge, Top FC		2260518W	White
5	2223388	Clip, Retainer (4)		2307007W	White		2260518T	Biscuit
6	2155013	Clip, Grille		2307007T	Biscuit		2260518B	Black
7	489478	Screw	17	489464	Screw	31		Cabinet (Not A Serviceable Part)
8	2223545	Shim	18	940139	Drain Fitting	35	3400858	Screw
9		Hinge Top, RC	19	2199954	Tube, Extension	36	2224020	Tube, Filter Outlet
	2307008W	White	20	1108439	Clip, Drain Tube	37	2305536	Tube, Filter Inlet
	2307008T	Biscuit	21	2223409	Cover, Unit			
	2307008B	Black	22	489483	Screw			
10	3400113	Screw	23	549193	Clamp, Service Cord			

REFRIGERATOR LINER PARTS

For Models: KSBS25INWH01, KSBS25INBT01, KSBS25INBL01, KSBS25INSS01
 (White) (Biscuit) (Black) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2224121	Escutcheon, Meat Pan Control
3	2224123	Slide Meat Pan Control
6	1118894	Switch, Rocker Arm
7	2188820	Thermistor
9	2223456	Ladder, Shelf (2)
10	2301234	Housing, Door Control
11	489084	Screw
13	2301235	Slide, Door Control
14	2171846	Release Valve
15	2209204	Clip, Thermistor
16	2179404K	Rack, Wine & Egg
17	1116793	Cover, Thermistor
18	489478	Screw
19	2304597	Gasket, Air Baffle
20	2223403	Cover, Air Baffle
24	2224076	Air Diffuser Assembly
25	2220377	Air Baffle
29	2162085	Socket
31	2223876	Reservoir
32	2205813	Strap
33	2255743	Light Bulb
34	2223663	Light Lens
37	488280	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Models: KSBS25INWH01, KSBS25INBT01, KSBS25INBL01, KSBS25INSS01
(White) (Biscuit) (Black) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	2224061	Shelf Assembly, Cantilever (2)
2	2301025	Button, Humidity
3	2301026	Slide, Humidity
4	2301117	Gasket, Side (2)
5	2223525	Cover, Meat Pan (Includes Items 13, 14, 15 & 20)
6	2301023	Snack Pan (Includes 30 & 31)
7		Glide Assembly, Crisper Pan
	2301548	Right Side
	2301549	Left Side
8	2301001	Window, Crisper Pan
9	2301567	Cover, Crisper (Includes 2, 3, 4, 11, 12, 13, 14 & 19)
10	2301027	Glass, Cover
11	2301116	Gasket (Front)
12	2301115	Gasket (Rear)
13	2174478	Eyelet, Roller
14	2188212	Roller
15	489211	Screw
16	2301031	Crisper Pan (Includes 8, 13, 14, 19 & 31)
17	2223790	Meat Pan (Includes 13, 14, 19 & 22)
18		Glide Assembly, Snack Pan
	2301550	Right Side
	2301551	Left Side
19	489261	Screw
20	2223487	Deflector
21		Support Assembly
	2301569	Right Side
	2301570	Left Side
22	2203031	Handle
23	2216624	Egg Bin
25	2196485	Stud Assembly
26	2301566	Shelf, Snack Pan
27	3400894	Screw
28	2196483	Stud Assembly
29	8281158	Screw
30	2301006	Window, Snack Pan
31		Cap, Snack Pan
	2301016	Right Side
	2301017	Left Side

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: KSBS25INWH01, KSBS25INBT01, KSBS25INBL01, KSBS25INSS01
 (White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS


For Models: **KSBS25INWH01**, **KSBS25INBT01**, **KSBS25INBL01**, **KSBS25INSS01**
 (White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2223777	Spacer, Slide (2)
6	2223691	Basket, Deep (2)
9	2223500	Shelf Assembly, Cantilever (2)
11	2224053	Front, Basket
13		Shelf Track
	2223787	Right Side
	2223788	Left Side
14	2223681	Shelf, Fixed
15	2223694	Basket, Lower
16	486298	Screw
17	842534	Clip, Air Duct (2)
18		Glide Assembly, Basket (2)
	2301544	Right Side
	2301545	Left Side
19	2259487	Cover, Emitter
20	8534064	Screw
22	2198635	Spring
23	2198634	Pin
24	2198665	Tube, P.C. Board
25	1115373	Switch, Rocker Arm
26	2220398	P.C. Board Emitter
27	2224125	Cover, Ice Maker
28		Slide, Ice Maker Mounting
	2212321	Right Side
	2306900	Left Side
29	489478	Screw
30	489214	Screw
32	2162085	Light Socket
33	2255743	Light Bulb
34	8281185	Screw
35	2198633	Flipper
36	2255561	Cover, Receiver
37	2301340	Slide, Ice Maker Shut Off
38	2255114	P.C. Board, Receiver
39	2198643	Lens
40	2198589	Light Shield
41	2212340	Light Lens
42	2198641	Bracket, Ice Maker Cover
43	2155597	Socket, Light
44	3400893	Screw
45		Ladder
	2223414	Left Side
	2223415	Right Side
46	2306901	Shield, Wiring

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS

For Models: KSBS25INWH01, KSBS25INBT01, KSBS25INBL01, KSBS25INSS01
 (White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


MOTOR AND ICE CONTAINER PARTS

For Models: KSBS25INWH01, KSBS25INBT01, KSBS25INBL01, KSBS25INSS01
 (White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	2223317	Ice Bin
2	2255580	Crusher Bin
3	2258222	Auger
4	2258220	Washer
5	1119007	Spacer, Flat (6)
6	2255460	Cover, Crusher
7	2257024	Blade, Rotary
8	1119005	Spacer, Step (2)
9	2257020	Blade, Fixed
10	2257023	Blade, Rotary
11	2198602	Block, Blade
12	489229	Roll Pin
13	2257022	Blade, Rotary
14	489235	Washer, Plain
15	2198661	Washer, Coupling
16	2220457	Coupling
17	8281164	Screw
18	3400065	Screw
19	2301345	Button, Bin
20	2212371	Latch, Bin
21	2198608	Spring, Latch
22	2198671	Screw
23	8281163	Screw
24	2212369	Holder
25	2220458	Coupling, Bottom
26	2198628	Seal
27	2212370	Washer
29	2198607	Spring
30	999536	Drive Shaft
31	2256154	Enclosure, Motor
32	2188860	Dispenser, Motor
33	2212305	Cover
36	2212365	Sleeve, Coupling
37	2187725	Wire Harness, IDI Motor

REFRIGERATOR DOOR PARTS

For Models: KSBS25INWH01, KSBS25INBT01, KSBS25INBL01, KSBS25INSS01
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS


For Models: KSBS25INWH01, KSBS25INBT01, KSBS25INBL01, KSBS25INSS01
 (White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes #7)
	2223825W	White
	2223825T	Biscuit
	2223825B	Black
2	2203087K	Trim, Shelf
3	2255421	Dairy Door
4	2223883	Caddy, Can
5	2165792K	Butter Dish
6		Trim, Top
	2224096W	White
	2224096T	Biscuit
	2224096B	Black
	2224096S	Stainless Steel
7		Door Gasket, Magnetic
	2223326	Mist Beige
	2223909	Black
8		Handle
	2223821W	White
	2223821T	Biscuit
	2223821B	Black
	2223821S	Stainless Steel
9	3196537	Screw
10	2223879	Dairy Compartment
11	3196180	Screw
12	2182178	Door Closer, Upper Cam
13	2308091	Thimble, Top
14	489420	Screw
15		Bracket, Door Stop
	2306940	Chrome
	2306940B	Black
16	2223860	Door Bin (3)
17	3400012	Screw
18	2224173	Door Bin, Shallow
19		Trim, Hinge Side
	2223824W	White
	2223824T	Biscuit
	2223824B	Black
	2223824S	Stainless Steel
20	2156006K	Plug, Trim
21		Trim, Bottom
	2223823W	White
	2223823T	Biscuit
	2223823B	Black
	2223823S	Stainless Steel

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Models: KSBS25INWH01, KSBS25INBT01, KSBS25INBL01, KSBS25INSS01
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


FREEZER DOOR PARTS

For Models: KSBS25INWH01, KSBS25INBT01, KSBS25INBL01, KSBS25INSS01
 (White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes #8 And Dispenser Front Parts)
	2223921W	White
	2223921T	Biscuit
	2223921B	Black
2		Handle
	2223817W	White
	2223817T	Biscuit
	2223817B	Black
	2223817S	Stainless Steel
3		Trim, Top
	2224095W	White
	2224095T	Biscuit
	2224095B	Black
	2224095S	Stainless Steel
4	3196537	Screw
5	3400012	Screw
6	3196180	Screw
7	2223559K	Shelf Bin (3)
8		Door Gasket, Magnetic
	2223325	Mist Beige
	2223910	Black
10	2219982	Trim, Door Shelf
11	2308091	Thimble, Top
12		Trim, Bottom
	2223819W	White
	2223819T	Biscuit
	2223819B	Black
	2223819S	Stainless Steel
14	2223752	Door Closer, Upper Cam
15		Trim, Hinge Side
	2223820W	White
	2223820T	Biscuit
	2223820B	Black
	2223820S	Stainless Steel
16	489420	Screw
17		Bracket, Door Stop
	2306940	Chrome
	2306940B	Black

DISPENSER FRONT PARTS

For Models: KSBS25INWH01, KSBS25INBT01, KSBS25INBL01, KSBS25INSS01
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER FRONT PARTS


For Models: KSBS25INWH01, KSBS25INBT01, KSBS25INBL01, KSBS25INSS01
 (White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	3196537	Screw
3	2194719	Retainer, Levers
4	2180209	Spring, Torsion
5	2196195	Pin
6	2180353	Door, Ice
7	2304355	Door Mechanism Assembly
8	2205686	Mechanism Delay
9		Grille, Overflow
	2206670W	White
	2206670T	Biscuit
	2206670B	Black
10	2221562	Water Fitting Assembly (Includes Water Tube)
11		Lever, Ice Dispenser
	2259396W	White
	2259396T	Biscuit
	2259396SB	Black
12	2180224	Guide, Ice
13	2305571	Gasket
15	2306938	Bracket, Control
17		Lever, Water Dispenser
	2259395W	White
	2259395T	Biscuit
	2259395SB	Black
19		Overlay, Front Cover (Not Available, Order #23)
20		LED Display (Not Available, Order #23)
21		Front Cover, Housing (Not Available, Order #23)
22	489000	Screw
23		Front Cover Assembly (Includes Items 13, 19, 20 & 21)
	2224063W	White
	2224063T	Biscuit
	2224063B	Black
24	2304673	Bracket, Dispenser
25	2195051	Strain Relief
26	3400065	Screw
27	2252127	Sleeve, Mechanism

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AIR FLOW PARTS

For Models: KSBS25INWH01, KSBS25INBT01, KSBS25INBL01, KSBS25INSS01
(White) (Biscuit) (Black) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	2182120	Fan Scroll
2	2223733	Retainer, Fan Motor
3	2223298	Air Scoop
4	2223303	Air Duct, Upper
5	2223297	Air Duct Freezer
6	2188824	Bi-Metal, Defrost
7	2259385	Fan Motor
8	2169142	Fan Blade
10	2223986	Fan Grommet (2)
12	2310110	Harness, Fan Evaporator (Includes #6)
13	2155789	Gasket Cover
16	2203876	Gasket
17	2223413	Cover, Evaporator
18	8281159	Screw
21	489478	Screw
22	2223395	Support, R.S
23	2203596	Support, L.S

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PARTS

For Models: KSBS25INWH01, KSBS25INBT01, KSBS25INBL01, KSBS25INSS01
 (White) (Biscuit) (Black) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
1	2306989	Control Box (Includes #6)
5	2223882	Heat Shield Asm
6	2307037	Control Board Asm
10	2223506	Light Lens, Control Box
17	2223857	Light Socket
19	2223678	Light Bulb

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: KSBS25INWH01, KSBS25INBT01, KSBS25INBL01, KSBS25INSS01
 (White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: **KSBS25INWH01**, **KSBS25INBT01**, **KSBS25INBL01**, **KSBS25INSS01**
 (White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	777070	Screw
2	2225834	Fan, Blade
3	2223315	Condenser Assembly
4	8281197	Screw
5	3400524	Screw (6)
6	2223703	Housing, Control Board
7	2223351	Tube Suction
8	2161302	Sleeve
10	2301979	Plate, Mounting
11	8281196	Screw
12	2215676	Cover, Terminal
14	2185788	Clamp, Cable
15	488649	Screw
18	2223353	Tube, Condenser to Heat Loop
19	2307028	Electronic Control
20	2306932	Baseplate
21	489478	Screw
22	2188823	Evaporator
23	2161324	Clamp
24	2188729	Fan, Motor
25	2223398	Tray, Evaporator

Illus. No.	Part No.	DESCRIPTION
26	2224022	Heat Shield
27	2199167	Drier
28	2223801	Compressor (Includes Items 12 & 39)
29	2223800	Spacer (5)
31	2187849	Harness, Main Control
32	2224024	Fan, Motor Bracket
33	2210737	Heater, Defrost
34	2304287	Clip
36	2304098	Inverter Box
37	489473	Screw
38	2223352	Tube, Discharge
39		Grommet (4)
	2183042	Production
	4387558	Service
41	2223394	Extension, Air Baffle
42	2155547	Clip, Heat Shield
45	2187737	Unit Harness
63	2209709	Connector, Water Tube


Illus. No.	Part No.	DESCRIPTION
Following Parts Not Illustrated and Optional Parts Not Included		
	978025	Valve, Access (1/4")
	978026	Valve, Access (5/16")
	978027	Valve, Access (3/8")
	978028	Valve, Access (1/2")
	978029	Valve, Access (5/8")
	978030	Valve, Access (3/4")
	876764	Valve, Access (3/16")
REFRIGERANT CHARGE		
		6.00 oz. (R-134A)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: KSBS25INWH01, KSBS25INBT01, KSBS25INBL01, KSBS25INSS01
(White) (Biscuit) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: KSBS25INWH01, KSBS25INBT01, KSBS25INBL01, KSBS25INSS01
 (White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1	489084	Screw
2	2256096	Fitting, Water Tube
5	628379	Clip, Fuse
9	489478	Screw
10	2315533	Water Valve Asm
14	2208136	Tube Clip
18	2174358	Cover
19	488649	Screw
20	628228	Mold & Heater Assembly (Also Order 542638
22	628356	Cup, Water Fill
23	627843	Ejector
24	2198598	Ice Striper
25	2194712	Support
26	627796	Retainer, Thermostat
27	627985	Thermostat (Also Order 542369 Cement Alumilastic)
28	8533917	Screw
30	489276	Screw
32	2187467	Harness, Wiring
33	2212322	Bracket, Icemaker Mounting
35	626678	Module Assembly (Includes Items 37 & 38)
37	626676	Motor
38	489136	Screw
100	2198597	Icemaker Assembly

OPTIONAL PARTS

For Models: KSBS25INWH01, KSBS25INBT01, KSBS25INBL01, KSBS25INSS01
 (White) (Biscuit) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
Parts Not Illustrated and Optional Parts (Not Included)			Miscellaneous			Refinishing Material		
Customer Touch-Up Material								
	*350942	Primer, White (12 Oz. Spray Can)		212643	Sealer, Gum (4 Feet)		799340	Enamel, Black (1 Qt. Uncut)
	*350939	Enamel, Black (12 Oz. Spray Can)		479502	Tape, Vinyl (3/4 x 108")		799344	Enamel, White (1 Qt. Uncut)
	*350930	Enamel, White (12 Oz. Spray Can)		876370	Kit, Insulation (2 Pcs. x 3" x 24" X 48")		4392900	Enamel, Biscuit (1 Qt. Uncut)
	*4392901	Enamel, Biscuit (12 Oz. Spray Can)		876305	Kit, Insulation (14 Pcs. x 3" x 24" x 48")			
	72017	Brush Touch-Up Kit (White)		978941	Insulation, Fiberglass (63-1/2" x 35-1/2" X 2-5/8)			
	72032	Brush Touch-up kit (Black)		876029	Kit, Foam Slab (30" x 32-1/2" x 1-1/2")			
	4392899	Brush Touch-Up Kit (Biscuit)		505587	Sealer, Mastic (1 Qt.)			
				503695	Cork, Sealer (1/4 Pound)			
				511873	Touch-Up, White Porcelain (2 Oz.)			
				542638	Grease, Silicone (1/2 Oz.)			
				542639	Cement, Alumilastic (1-1/4 Oz.)			
				606755	Bag, Insulation (36-5/8" x 46")			
				799833	Kit, Evaporator Repair (Aluminum Epoxy)			
				833938	Kit, Terminal Connector			
				2258250	Ice Container Assembly			
								TORX SCREW WRENCH
							1117510	Torx Key

***Important:** The spray paint is not to be used where the paint may make contact with the door gaskets.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST