



Measuring Mode

STEP 1




First turn adjustment dial **counterclockwise** to open plug gauge.

STEP 2




Now insert rope between contact surfaces and device plug gauge.

STEP 3



Turn adjustment dial **clockwise** to close plug gauge. Keep turning until you hear a beep.




XX.X mm

OR


.XXX INCH

Your **diameter** is now displayed in metric or imperial units.

STEP 4



Continue to turn adjustment dial **clockwise** until you reach 100% and hear another beep.





XX.XX kN

OR

XXXX LBF

Your **tension** is now displayed in metric or imperial units.

STEP 5



Now turn dial **counterclockwise** to remove rope from RPM.

STOP! DO NOT perform repeated measurements at the same rope position.

