

USER'S MANUAL

CHANDELIER ITEM# 7510-9H

WARNING

1. Shut off the power to the area where you will be working.
2. Use 60 watt maximum type B bulb.
3. Do not use polish or cleaner on your lamp, just wipe with soft cloth.

STEP 1 -- UNPACK

1. Carefully unpack your new fixture and lay out all the parts on a clear surface.
2. The bag includes a mounting pack.

STEP 2 --CHANDELIER ASSEMBLY

1. Screw the Poly(1) into the Hex Connector(7).
2. Attach the Harp(3) to the Socket(8) and screw the Bulb, and then put the Shade(4) onto the Harp(3) screwed with the Top Finial(5).
3. Screw the Poly(6) and Bottom Finial(2) to the Fixture.

STEP 3 --FIX WIRE INSTALLATION

✳ **We advise contacting a qualified electrician for this step.**

4. Thread the Nipple-2 into the Top Loop until snug, and attach the Top Nut, Canopy to the Nipple-2.
5. Screw the other side of Nipple-2 to the Connector through the Hex Nut, Key Washer and Cross Bar.
6. Screw the Nipple-1 to the Connector, attach the Washer and Spring Washer to the other side of Nipple-1.
7. Take this crossbar assembly and mount to ceiling Outlet box with Mounting Screw.
8. Lace the fixture wires through the chain. Canopy over the chain.
9. Cut the wire plug off, Feed the fixture wires through the Loop and Nipple-1 and pull until taut.
10. Connect fixture wire to the wire from junction box with wire connectors, See paragraph below.
11. Push Canopy up against ceiling and secure with Top Nut.

✳ WIRE CONNECTION

FOR WIRE CONNECTION, BE SURE TO CONNECT, FIXTURE SMOOTH WIRE TO THE BLACK HOUSE WIRE, RIBBED WIRE TO THE WHITE HOUSE WIRE AND FIXTURE GROUND WIRE TO SUPPLY GROUND WIRE WITH WIRE CONNECTORS OR THE FIXTURE GROUND WIRE FROM THE FIXTURE TO THE GREEN GROUND SCREW ON THE MOUNTING BRACKET.

✳ **Your installation is now complete. Turn power on.**

