

# **The Happy Cig<sup>©</sup>**

## **User Manual**

### **1 – INSTALLATION**

- Fully charge the battery with the included charger
- Fill chamber marked "H" with Dry Herbs chamber marked "C" with your concentrate using the included dabber. The clear e-Liquid atomizer should be filled on the side of the heating element leaving 25% space at the top
- Install the knob cover only onto the chamber with Dry Herbs, installing the knob cover onto the chamber with concentrate will cause it to clog
- Install the mouthpiece onto the chamber
- Connect the mouthpiece and chamber onto fully charged battery

**YOUR CIG IS NOW ☺**

### **2 – USE**

Press and hold down the ☺. The ☺ will turn orange indicating that The Happy Cig<sup>©</sup> is working and you can begin to draw/puff on it. The vapor will become thicker and thicker as the substance inside the chamber gets hotter.

\* The Happy Cig<sup>©</sup> is equipped with a 5 click protection/lockout function. If you have disabled the device and the ☺ does not glow when you hold it down, press it 3 times in rapid succession to unlock and resume use.

### **3 – CHARGING**

After plugging the charger into the bottom of the battery a red light will turn on. Once the light turns off your battery is fully charged

### **4 – CLEANING**

The best way to ensure optimum performance and longevity of The Happy Cig is to perform simple cleaning procedures on a regular basis. The most important process lies in the removal of any excess essential oil residue from the connection point of the battery. Simply take a cotton swab, soak it in isopropyl rubbing alcohol, and gently wipe away any of the excess essential oil residue that may have collected there. With The Happy Cig, it is also

important to remove any excess essential oil residue from around the base of the titanium cylinder, on the outer part of the coil. If you notice this excess essential oil residue collecting anywhere, simply engage in this process as necessary. It will effectively prevent any loose connections between the battery and the coil while keeping the mouthpiece sanitary.

Do not SOAK any of your components (Chamber, Battery, Charger) in any type of cleaning solution or rubbing alcohol.

Do not clean the inside of the Chamber, the area where the heating element lies. The heating element will essentially clean the inside of the chamber by burning away any of the excess essential oil residue.

The Chambers have an estimated life of four weeks for the average user.

**“DON'T WORRY, VAPE HAPPY”**  
**www.TheHappyCig.com**

## **5 – WARNINGS/TIPS**

- Only use included charger, any voltage higher than 5.5v/500mA will cause damage to the unit
- Keep away from flammable items especially acids and combustible materials
- If the ☺ on the battery flashes and the device does not produce vapor, recharge the battery
- To avoid decreasing the life of the battery, wait until all power is discharged before recharging
- When The Happy Cig<sup>©</sup> is not in use, detach the battery from the heating chamber and store properly
- ALWAYS KEEP OUT OF THE REACH OF CHILDREN

## **6 – TROUBLESHOOTING**

**Q – I draw/puff on The Happy Cig<sup>©</sup> and the light turns on when I press it but I do not get any vapor**

**A – Make sure the heating chamber and the battery are well connected**

Q – I draw/puff on The Happy Cig<sup>©</sup> and the light flashes when I press it  
A – The battery is probably low and needs to be recharged

Q – When I draw/puff on The Happy Cig<sup>©</sup> using the “C” chamber I am getting concentrate pulling through the mouthpiece  
A – Concentrates that are too thin or runny at room temperature or poorly processed will leak out of the chamber. It is recommended that a substance is used that will liquify with heat and thicken at room temperature

Q – I know my battery is charged but when I press the ☺ it does not light up  
A – Press the ☺ 3 times in rapid succession, you have probably enabled the lockout function

“DON’T WORRY, VAPE HAPPY”

[www.TheHappyCig.com](http://www.TheHappyCig.com)

The following paragraph details The Happy Cig tm 1 year limited warranty:

OG Distribution, maker of The Happy Cig tm warrants for a period of one year, from the original purchase date, that the pack, chargers & batteries included with The Happy Cig tm are free from material defects & workmanship. If material is found to be defective the sole liability from OG Distribution is to repair or replace with a factory recertified product. If there is dissatisfaction or damage arising from use of our product, you agree the only recourse & maximum liability may be repair or replacement of your product. This warranty is provided in lieu of all express or implied warranties including merchantability & fitness warranties unless these warranties are required by law. If such warranties are required, they will apply only during the warranty period. The warranty does not apply to cartridges or if the product is used with non OG certified or approved products, used for commercial purposes, damaged by wear & tear, acts of God, misuse, abuse, negligence, accident, modified or tampered with or any other cause other than defective material or workmanship.

**“DON'T WORRY, VAPE HAPPY”**  
**www.TheHappyCig.com**