

# Lemön S405 User Manual



@2014. All rights are reserved. No part of this document may be reproduced without permission. All trademarks and brand names mentioned in this publication are property of their respective owners.

While all efforts have been made to ensure the accuracy of all contents in this manual, we assume no liability for errors or omissions or statements of any kind in this manual, whether such errors or omissions or statements resulting from negligence, accidents, or any other cause. The contents of this manual are subject to change without notice.

Protect our environment! We strive to produce products in compliance with global environmental standards. Please consult your local authorities for proper disposal.

*Note: User's Manual is Just to guide the user about the functionality of the phone. This does not seem any certificate of technology. Some functions may vary due to modifications and up gradations of software or due to print mistake.*

**SAFETY PRECAUTIONS**

Before using your phone, please read the following important information to eliminate or reduce any possibility of causing damage and personal injury

	Do not use wireless phones while driving.
	Switch off wireless devices in aircraft. The signal may cause interference. Using them on aircraft is illegal.
	Do not use mobile phones where blasting is in progress. Follow regulations and rules strictly.
	Do not use mobile phones at a refueling point. Don't use near fuel or chemicals
	Follow regulations or rules in hospital and health care facilities. Switch phone off near medical equipment.
	All wireless devices may get interference that could affect performance.
	Only qualified service personnel can install or repair this device.
	Use only approved accessories and batteries.
	Use only in normal conditions. Do not expose your phone to extreme high temperatures above $+60^{\circ}$ ( $+140^{\circ}\text{F}$ ) . Do not use anything static to clean your

	phone.
	Ensure the phone is turned on and in service. Enter the emergency number, then press Pick Up key. Give your location. Do not end the call until told to do so.

Improper use will invalidate the warranty! These safety instructions also apply to original accessories.

a) Use a wireless hands-free system (headphone, headset) with a low power Blue tooth emitter.

b) Make sure the cell phone has a low SAR.

c) Keep your calls short or send a text message (SMS) instead.

This advice applies especially to children, adolescents and pregnant women.

d) Use cell-phone when the signal quality is good.

e) People having active medical implants should preferably keep the cell phone at least 15 cm away from the implant.

## Table of Contents

<b>Chapter1 General Information .....</b>	<b>6</b>
1.1 General notices .....	6
1.2 Notice for phone operation .....	7
1.3 Notice for use of battery .....	9
<b>Chapter2 Before Use .....</b>	<b>11</b>
2.1 SIM card .....	11
2.1.1 Insert and pull out the SIM card.....	11
2.2 Battery .....	12
2.3 Install and pull out T-flash card.....	12
<b>Chapter3 Basic Description .....</b>	<b>14</b>
3.1 Call functions.....	14
3.1.1 Make a call .....	14
3.1.2 Answer a call .....	16
3.1.3 Reject a call .....	16
<b>Chapter4 Menu Introduction .....</b>	<b>17</b>
4.1 Contacts .....	17
4.2 Messages.....	17
4.3Call logs .....	17
4.4 Profiles .....	17
4.5 Camera.....	18
4.6 Game.....	18

4.7 Settings .....	18
4.8 Multimedia .....	18
4.8.1 Image viewer .....	18
4.8.2 Video recorder .....	19
4.8.3 Video player .....	19
4.8.4 Audio player .....	19
4.8.5 FM radio .....	19
4.9 File Manager .....	20
4.10 Organizer .....	20
4.11 Internet .....	20
4.12 Lemon Twist .....	20
<b>Chapter5 Common problems and solutions .....</b>	<b>21</b>
5.1 When the mobile phone displays “Insert SIM”? .....	21
5.2 Checking and precautions of PIN, PIN2, PUK, PUK2 and password .....	21
5.3 Network connection fails .....	21
5.4 You can't be heard .....	22
5.5 Can't charge the battery .....	22
5.6 Weak signal .....	22
5.7 Can't make a call .....	22
INFO REGARDING SERVICE CENTERS .....	23

## Chapter1 General Information

### 1.1 General notices

You have to use battery and charger appointed by the firm, otherwise the liquid leak of battery, superheat, detonation and fire may be caused.

Please don't bump, shake or chuck your mobile phone violently to prevent it from fault and fire.

Please don't place battery, mobile phone and charger near the microwave-oven or high-voltage equipment.

Please don't use phone at the flammability and explosive place, or else the malfunction and fire may be caused.

Please don't place phone at the place of high temperature, abundant humidity or mass dust, or else the malfunction may be caused.

Please place mobile phone out of kid's reach to protect them from hurt by playing it as toys by mistake.

Please don't place mobile phone at on-even or flabby table-board to prevent it from malfunction or break attributing to dropping.

## 1.2 Notice for phone operation

Please power off your mobile phone in some places such as: in the plane, hospital, etc, where the mobile phone may affect the electronic equipment and medical instrument, so please conform to the relative regulations. To make sure your phone won't turn on automatically, please check your alarm clock function in your alarm setup.

For radio wave interference may cause electronic equipment malfunction and some other problems, please don't use phone near the equipment of feeble signal or high precision. Especially when next to the following ones: acoustic on, pacemaker, other medical electronic equipment, fire detector, automatic gate and some other automatic servomechanism. Please consult local equipment manufacturer or distributor for mobile phone's effect to pacemaker and other medical electronic equipment.

Please hold LCD softly and don't use phone to beat other things, or else it will cause LCD's dilapidation and liquid leak, which may cause the blindness when the liquid enters one's eyes, If so, please rinse(don't massage your eyes)them with clean water, then promptly sees the doctor.

Please don't disassemble or refit mobile phone, or else the break, creepage, and fault may be caused.

Some type of mobile phones may accidentally affect the

electronic equipment in car, if so, please stop for your security.

- Please don't press the key with needle, writing skill and some other speculate things, otherwise, it will cause mobile phone's damage or malfunction.
- Please don't use phone if the antenna has been broken, or else it will hurt you.
- The radiation wave of phone may eliminate the information stored in the soft disk, bank card and credit card when the phone is so near magnetic substances.
- Keep stud and some other small metal far away from the headphone, for the speaker will pull them because of its magnetism, thus hurt you or damage your mobile phone.
- Keep your phone from damp, water or other liquid, if not, superheat, creepage and fault may be caused.

### 1.3 Notice for use of battery

- Don't throw battery into fire; otherwise it will induce fire and explosion.
- Don't press in force when installing battery, Or else it will induce liquid leak, superheat and fire.
- Please neither cause battery to be short by wire, needle and some other metal, nor blend the battery with necklace, Or else it will induce liquid leak, superheat and fire.
- Don't seal battery end, Or else it will induce liquid leak, superheat and fire.
- Blindness will be caused when the liquid from battery enters one's eyes. If so, please rinse (don't massage your eyes) them with clean water, then promptly sees the doctor.
- Please don't dismantle or refit battery, or else it will lead to liquid leak, superheat explosion or fire.
- Please don't use or place batteries near fire or heater, or else it will lead to liquid leak, superheat, explosion or fire.
- Please replace new battery if temperature rising, color changing or distortion occur during the process of operation, charging or conservation.
- Burn will be caused when the liquid from battery enters one's skin or clothes. If so, please rinse them with clean water, then promptly sees the doctor.

- Please promptly move the battery away from fire if liquid leakage or oddball odor occurs to prevent from explosion or fire.
- Please don't keep the battery away from damp. or else it will lead to superheat, fume and erosion.
- Please don't use or place battery when exposure to direct sunlight or high temperature, or else it will induce liquid leakage, superheat, thus decreasing performance and shortening longevity.
- Please don't charge more than 24 hours continually.

## Chapter2 Before Use

### 2.1 SIM card

- In order to use the mobile phone, you should insert the valid SIM card, which is the key to enter the GSM network.
- All the information related to the creation of the connection to the network and initial call records will be recorded in the metal plane area of the SIM card as well as the names, telephone numbers and SMS stored in the phone book on the SIM card. The SIM card can be taken out from your mobile phone and can be placed in any one of the GSM mobile phones for use (the new mobile phone will read the SIM card automatically).

***\*Note: Please do power off your mobile phone before pulling out the SIM card. It is forbidden to insert or pull out the SIM card with the mobile phone connected to the external power supply; otherwise, the SIM card is most likely to be damaged.***

#### 2.1.1 Insert and pull out the SIM card

- Power off your mobile phone and then remove the battery and other external power supply.
- Insert the SIM card into the SIM card slot, make sure the SIM is fixed accurately.

- When you need to pull out your SIM card, please power off your mobile phone firstly, then remove the battery, open the SIM card slot and then pull out your SIM card

***\*NOTICE: The card slot on the Left is SIM2 card, the one on the right is SIM 1 card.***

## **2.2 Battery**

- The battery can run immediately after taken apart for it has charged for about 50% volume; In order to reach the optimum operation, please make use under the situation of fully charging after complete consumption. The new battery should be charged at least for 14 hours. Only when the initial battery is exhausted thoroughly (the electricity quantity runs out and the mobile phone can not power on) can the battery be fully recharged for use, so does the second time charging. Only when recycled for three times in this way, the battery works in the best condition easily.

## **2.3 Install and pull out T-flash card**

This mobile phone supports T-flash card, which is a kind of multimedia memory card used to increase memory of the mobile phone. It is so small that you should take cautions to

install or pull it out in order to avoid damage. The method to install/ pull out T-flash card as the follows:

1. Install the T-flash card: Power off the mobile phone, ,and set T-flash card with the metal face downward to the T-flash card slot.
2. Pull out the T-flash card, power off the mobile phone, take out the T-flash.

***Note: The mobile phone does not support hot-plug function of T-FLASH in “power on” mode. Only when the mobile phone is powered off can T-FLASH be pulled out.***

## Chapter3 Basic Description

### 3.1 Call functions

You can dial or receive call if the symbol of network supplier is displayed on the screen (intensity of network signal shown at left up corner). Move in small region may improve calling effect, which is has too much with the barrier.

#### 3.1.1 Make a call

➤ Dial call:

Input telephone numbers, and then press the dial key to make call. Use right soft key to delete number if modification is needed. The picture of dialing will appears on the screen during dialing, then call status information will appears after the pick up of phone ,additionally together with a alert sound(network support needed) if it is opened. If you want to end the call, please press the end key. If the number does not belong to the Phone Book List, the screen of your device only displays the number. Otherwise, the name would be displayed.

➤ Dial fixed branch phone:

You should firstly dial telephone exchange, then branch

for some branch phones which can't be got through directly. The phone will press \* key (now "p" displaying on screen) for you if pulse character "p" is entered between host and branch number when dialing.

**Region no. Host no. p Branch no. Dial key**

Dial international call:

Please press \* key twice until prefix "+" of international call appears on the screen, which will allow you to dial to any country without knowing of the local international call prefix (for instance, 0091 for India).

Firstly enter prefix, then enter the country area number and complete phone numbers. The country area number is in accordance with general routine, such as 49 for Germany, 44 for UK, 46 for Sweden and so on.

Please delete "0" before city number, which is the same as dialing international call.

For example, please dial service phone of other countries as: +91 21 114

**+ Country code integrated no. dialing key**

Emergency call:

You are able to make emergency call in the range covered by network (please refer to signal intensity displayed in left up corner). Emergency call will be shown on the screen if your

network supplier doesn't provide ramble function. Emergency call can be made without SIM card if you are in the network range

### **3.1.2 Answer a call**

You can Press the call key to receive the call when call coming. Display "SIM1 incoming call" with the phone number or name if SIM 1 has been called. Display "SIM2 incoming call" with the phone number or name if SIM 2 has been called.

If you set any key to receive the call, you may use the any key to receive call besides the end key and the right soft key.

You also can press the key in the earphone to receive calls if it has been connected.

### **3.1.3 Reject a call**

- When you do not want to answer a call, you can press the end key to end the call.

## Chapter4 Menu Introduction

### 4.1 Contacts

You may save the information of contacts including names and telephone numbers in the Contact. The storable entries of SIM card depend on the type of the card.

You may select to edit, delete, copy, copy all contacts etc.

### 4.2 Messages

Messages can be write message\ inbox\ outbox\ drafts\ sentbox\ security inbox\templates  
Operation.

### 4.3 Call logs

SIM card 1 and SIM card 2 Call history include all calls, call logs ,missed calls, dialed calls, received calls, rejected calls, delete all, call timer, GPRS counter etc

-- Rejected calls: The incoming call of the contact is in the group blacklist. And the call has not call interface. You can view the detail of the call log in rejected calls.

--Call timer: View the time of the last call, received calls, dialed calls and all calls.

### 4.4 Profiles

Profiles:

Normal\Silent\Meeting\Indoor\Outdoor\Earphone\Bluetooth  
\Fight mode operation

## **4.5 Camera**

In the options of camera interface, You may set shutter, shoot mode, size, Brightness, contrast, effect settings, storage and etc. you may enter the photos to view the photos. Press the middle (OK) key to take photos

## **4.6 Game**

Enter game menu for: Link game \ Gobang \Snake\ Tetris \ Gold Miner

## **4.7 Settings**

Enter settings menu for: call setting\phone setting\display setting\security setting\  
connections operation. Password for reset would be 0000.  
Auto call recorder would be used to record all incoming and outgoing calls.

## **4.8 Multimedia**

### **4.8.1 Image viewer**

View the pictures in the memory card.

### **4.8.2 Video recorder**

In the options of the video recorder interface, you may set shoot mode, size, Brightness, effect settings, you may enter the video list to play the video. Press the middle (OK) key to begin video , Your phone can recorder 3GP formats file.

### **4.8.3 Video player**

Enter the video player to playing the video file.

Note: You phone supports 3GP formats file.

### **4.8.4 Audio player**

The music player is used to play music files in supported formats in the current player's list. You may view details of the music files and set the current music file as the ring signal for incoming call. You may connect the Bluetooth earphone to enjoy the music.

### **4.8.5 FM radio**

Right keys on the function keys can turn off FM radio, Press the left and right key to change the channel.

### **4.8.6 Sound recorder**

You can record file and play it.

## 4.9 File Manager

For the memory card, you may establish a data file folder, change the folder name, delete a folder, sequence the files and etc.

Use as: For the music use as incoming tone, For the picture use as wallpaper, For the video use as screen saver, power on/off.

Rename: Change the name of a file/file folder.

Copy a file: To copy any file in the memory card.

Mark: To mark the picture or music you selected, or mark all.

## 4.10 Organizer

Enter organizer can be Torch light \Calendar\Calculator\  
World clock\ Alarm\ Ebook\  
Bluetooth operation.

## 4.11 Internet

Enter Internet menu for You can Input website, browse the web etc

## 4.12 Lemon Twist

Enter Lemon twist menu for: Lemon zone\Lemon live\Whatsapp operation.

## **Chapter5 Common problems and solutions**

### **5.1 When the mobile phone displays “Insert SIM”?**

1. Contact between SIM card and mobile phone is bad or the SIM card is not inserted.
2. Change the SIM card and try again. The SIM card may have fault if the mobile phone operates normally. Please contact your network operator.
3. If there is oxidation on the surface of SIM card or SIM card slot of the mobile phone, please wipe with alcohol or clean cloth.
4. Please contact Sales Service Center or Maintenance Department if the above methods are invalid.

### **5.2 Checking and precautions of PIN, PIN2, PUK, PUK2 and password**

1. Please consult local network operator.
2. The SIM card is locked if you input invalid PIN code for three times continuously.
3. Please consult SIM card operator for PUK code.

### **5.3 Network connection fails**

1. The signals in your local place are weak or have shielding. Please move to other places and try again.
2. Please contact Sales Service Center or Maintenance

Department to do phone test.

#### **5.4 You can't be heard**

1. Make sure whether it is network problem and try again.
2. The communication lines in some places are bad. Please move to other places and try again.
3. The trunk line of network operator is bad.
4. Please contact Sales Service Center or Maintenance Department if the above methods are invalid.

#### **5.5 Can't charge the battery**

1. The contact between charger and mobile phone is bad. Make sure whether the installation is proper.
2. Check whether the battery is valid. The battery performance drops after several years.

#### **5.6 Weak signal**

1. If the local network signals are unstable, the signals of the mobile phone receives won't be stable. Please move to other places and try again.
2. Please contact Sales Service Center or Maintenance Department if the above method is invalid.

#### **5.7 Can't make a call**

1. The local network signals are weak and please move to

places with strong signals and try again.

2. Local network operator is busy. Please try again later.

3. Check whether Hide ID is enabled. You can't make a call if the local network operator doesn't support this function and you have enabled it.

4. Please contact Sales Service Center or Maintenance Department if the above methods are invalid.

### **INFO REGARDING SERVICE CENTERS**

Service Center No: 09611124269

To know your nearest Lemon service center please send SMS to 09611124269 with below mentioned format.

Format to send SMS: LEMON SER <YOUR AREA PIN CODE>

In return to it you will receive SMS containing address for LEMON SERVICE CENTER nearest to you.

For example: If you want to know service center for Noida, Sector -2, 201301.

Write SMS as: LEMON SER 201301 & Send it to 09611124269.

Note : Kindly give one space each between keywords & Area Pin No while sending SMS.