

# IMPORTANT INFORMATION

Care instructions:

- ✦ Keep the unit clean by wiping it with a slightly damp cloth.
- ✦ Keep the unit out of direct sunlight and away from any direct heat source.
- ✦ Do not expose the unit to moisture or water.

This product complies with the essential requirements of the European Toy safety directive

## Warranty:

Should you in the unlikely event experience any problems with this products have a six month guarantee. In the first instance, return the product back to place of purchase where a replacement will be issued.



Inspiration Works UK Ltd

Charlotte Court  
Proctor Way  
LUTON  
Bedfordshire  
LU2 9PE  
UK

[www.inspirationworks.co.uk](http://www.inspirationworks.co.uk)

twitter



@inspirationwrks

facebook



Facebook



© 2011 - CIDE Toys

[www.cidetoys.com](http://www.cidetoys.com)



TM & © DC Comics



WB SHIELD: TM & © Warner Bros. Entertainment, Inc.  
(s12)




# 3+

# DC SUPER HERO POWER TABLET

## Instruction manual

### THE UNIT



### Important information

- ✦ This toy is suitable for children aged 3 years & over.
- ✦ Please retain this manual for further reference.
- ✦ WARNING: All packing materials such as internal bags, plastic collars, plastic films, carton inserts are not part of this product and should be discarded for your child's safety.
- ✦ IMPORTANT: for additional safety, check toys regularly for signs of damage during use.

### Contents

- ✦ DC Super Hero Power Tablet
- ✦ User Manual

V00  
May 2012  
Printed in China  
Made in China



WASTE ELECTRICAL PRODUCTS AND BATTERIES SHOULD NOT BE DISPOSED OF WITH HOUSEHOLD WASTE. PLEASE RECYCLE WHERE FACILITIES EXIST. CHECK WITH YOUR LOCAL AUTHORITY FOR RECYCLING ADVICE.

S1144


## HOW TO PLAY



Press anytime during the game on the DC Super Friends picture to hear some tunes!


During a game the DC Super Friends picture lights up when you answer correctly!

**Games selector:** Choose one of the 4 games by pressing on one of these pictures



**Game 1    Game 2    Game 3    Game 4**

Discovery / Answer pictures: to discover / answer a question; press on one of the 15 pictures or the true or false pictures.



### Game 1: Discovery

Press on any of the 15 pictures to find out who is behind it.

Press a second time and you will find out something about that Super Hero.

### Game 2: Colours...

Find one of the Super Heroes by answering questions on colours...

Batman's suit is green and grey – True or False?



You have 3 chances!

### Game 3: Find...

So how well do you know your Super Heroes?

Let's find out by answering a great quiz!

You have 3 chances!



### Game 4: Catch me when you hear my name!!


How fast are you??

Let's find out with this rapidity game!

Press on the picture of the Super Hero as soon as you hear his name!

## HOW TO CHANGE BATTERIES

1. This product requires 2 x AA-LR6-AM3 batteries
2. When required, using a suitable screwdriver, undo and remove the battery cover located under the unit.
3. Insert 2 x AA-LR6-AM3 batteries into the compartment ensuring they are installed the correct way around.
4. The polarities are marked inside the battery compartment.
5. Should the batteries have no polarity markings, the flat end of the battery should always be inserted against the spring.
6. Reassemble the battery cover and tighten the screw to secure.
7. Do not over tighten.



Please note the important points below when using batteries to power this product:

- \* Batteries should be inserted and removed by an adult.
- \* Only use the type of batteries specified in this user manual, or equivalent type. We recommend the use of alkaline batteries.
- \* Follow the polarity diagram inside the battery compartment and the polarity markings on the batteries.
- \* An incorrect location may either damage the toy, or cause battery leakage, or, to an extreme degree, lead to battery explosion.
- \* Do not try to charge non-rechargeable batteries, as they may leak or explode.
- \* Replace all batteries at the same time.
- \* Do not mix new with old batteries
- \* Do not mix different types of batteries (i. e. alkaline and zinc carbon).
- \* Remove the batteries during long periods of non-use. Always remove exhausted batteries from the product. Battery leakage and corrosion can damage the product.
- \* Do not short-circuit the supply terminals. Store batteries away from metal objects.
- \* Do not dispose of batteries in fire, as they may leak or explode. Never disassemble batteries.
- \* Rechargeable batteries should not be used.
- \* When rechargeable batteries are used anyway :
  - Rechargeable batteries shall be charged only under the supervision of an adult.
  - Rechargeable batteries shall be removed from the toy before being charged (if they can be removed).
- \* If a battery is swallowed, consult a Doctor or Medical Facility. Don't forget to take the product with you.
- \* If battery leakage occurs and comes in contact with the skin or eyes, wash immediately with lots of water.
- \* Batteries are included for demonstration purposes only and may need replacing after purchase.
- \* Strong Electro Magnetic Interference may disturb the normal function of the product. If so, simply reset the product to resume normal operation by following the instruction manual. In case the function does not resume, please use the product in another location.



## TROUBLESHOOTING

If the unit doesn't operate...	Check that the batteries are installed correctly. or Install new batteries.
If the volume is too low...	Install new batteries.
If the voice/music begins playing at a very high or low rate of speed...	Install new batteries.
If there is a continuous buzzing sound and the unit doesn't operate...	Install new batteries.
If the light becomes dim...	Install new batteries.
If the unit malfunctions...	Install new batteries.