

**ORION<sup>®</sup>**

# **INSTRUCTION MANUAL**

**RECHARGEABLE HAIR CLIPPER**

**Model: OR-HC05**

**ENGLISH GB**



Dear customers! Thank you for purchasing ORION products. Before operation, please read this instruction manual.  
Save it for future reference.

**DETAILS**



- 1. Blade
- 2. On/Off switch
- 3. Plug line
- 4. Scissors
- 5. Comb

- 6. Cleaning brush
- 7. Comb attachment
- 8. Oil
- 9. Charge stand

## FUNCTION

This hair clipper is designed for professional use to cut hairs and beards. Because the operation of the clipper is very easy and dexterous, it is more suitable for family use. With special designed shape, it has refined appearance and very soft hand feeling. Adopting one meticulous blades unit and one 600 mA battery, it has strong cutting strength.

This hair clipper uses only one special designed comb attachment. It is easy to use.

The clipper uses rechargeable battery. Take advantage of the cord design, you can work with it at any place and never worry about the use.

The blade is separable. It is convenient for cleanup and adding oil.

Please read the direction carefully before use.

## OPERATION

### *Using rechargeable battery*

#### Recharging the battery

Make sure that the switch is at OFF, plug the adaptor into clipper, and then into a household wall socket, and it begins to recharge the battery. The clipper can work for about 45 minutes after being recharged for 8-12 hours.



#### *To use*

Simply push the switch to ON, and the clipper works. Use universal comb of 7 positions (cutting length from 3 to 21 mm): 3, 6, 9, 12, 15, 18, 21 mm.

#### *Blade care*

Hold the clipper with the obverse side facing downwards. Push the blade to make it apart from the housing. Clean the blade with the cleaning brush.



## CAUTIONS

- Never recharge the battery when the temperatures are below 0°C or above 40°C.
- Avoid recharging the battery in direct sunlight or near a radiating heat source.
- Never recharge the battery continuously over 24 hours.
- Never put the clipper into water. To clean the housing, use only a cloth slightly dampened with water or mild soap solution. It is normal if the clipper becomes warm in using or recharging.
- Keep the clipper out of reach of children.
- Do not attempt to repair or move any part of the clipper by yourself. If there is anything irregular about the clipper, please have it inspected at an authorized service center.

## TECHNICAL DATA

- Input: AC230V~50Hz 3W
- Output: DC3V=200mA 3W
- 45 minutes continual
- Operating 8-12 hours charge

## REMOVING THE BATTERY

- The built-in battery contains substances which may be harmful to the environment
- When you discard your clipper in due course, please remove the battery and hand it in separately at an officially assigned collection point.
- You may also remove the battery from the clipper yourself.
- Make sure that the battery is empty before you remove it. If it is not empty, run the clipper until the motor stops.
- Remove the battery.
- The shaver must never be connected to the mains after the battery has been removed.

## PACKAGE CONTENTS

Rechargeable hair clipper	1 pc	Oil	1 pc
Outside adapter	1 pc	Brush	1 pc
Stand	1 pc	User Manual	1 pc
Trimmer guide	1 pc	Guarantee card	1 pc
Comb	1 pc	Information card ORION	1 pc
Scissors	1 pc		

**Note:** DOES NOT CONTAIN HAZARDOUS SUBSTANCES

Subject to change without notice

Extra information on ORION company web-site [www.orion.ua](http://www.orion.ua)

We take your opinion and offers by E-mail [support@orion.ua](mailto:support@orion.ua)

DEVELOPED BY ORION ELECTRONICS LTD

(29 Jászberényi út, Budapest 1106, HUNGARY, EUROPE)

ASSEMBLED IN P.R.C. UNDER STRICT CONTROL OF ORION ELECTRONICS LTD  
(HUNGARY, EUROPE)

CERTIFIED AND APPROVED BY ORION ELECTRONICS LTD (HUNGARY, EUROPE)

