




1 INSTALLATION & CONNECTION

Place the unit in horizontal position on a table or on a proper work surface and set it in a comfortably reachable way.




2A Turn the main switch to “I” (ON) position.
At power-on, the display will show in sequence the wordings “CoLibri SYSTEM”, “V. x.xx” and “Ready”.
The latter indicates that the unit is correctly powered and ready for use.



Switch-on the book covering machine through the main switch while keeping both the cycle start levers pressed for at least 5 seconds.


As soon as the display shows the identification of the currently set language, release the cycle start levers.



Briefly and repeatedly press the cycle start levers to scroll through the selectable languages:

```


graph TD
    Italiano --> English
    English --> Français
    Français --> Deutsch
    Deutsch --> Español
    Italiano --> Español
  
```



To confirm the chosen language and leave the programming mode:

keep the cycle start
levers pressed for
more than 5
seconds, and
release them as
soon as the
message “**Ready**”

NOTE: If you do not press the cycle start levers for 30 seconds, the unit automatically leaves the programming mode, saving the last selection made.





3A Warnings:

- The **CoLibri Leonardo** book covering machine may only be used to cover/wrap books, magazines, documents, projects, photos, objects, etc.
- Only adults are permitted to use the book covering machine. Children are not permitted to use the unit.
- The **CoLibri Leonardo book covering machine** may be used to trim and weld only covers and envelopes bearing the original **CoLibri** marking, or other material approved by the manufacturer.
- Never use the book covering machine near flammable surfaces or liquids.
- Avoid spilling liquids (*such as water, coffee, other drinks, etc.*) on the unit. Keep corrosive liquids and/or solvents far away from the unit.
- Prior to starting a cycle, make sure that there are no clips, staples or other objects (*except the cover/envelopes*) between the welding bar and the lower contrast surface.
- During the welding cycle do not turn the unit off by either disconnecting the power cable or switching off the main switch.

2 To obtain a correct welding/trimming:

- Ensure that the recommendations on the installation site have been followed, especially for what concerns the easy access to the unit, height and leveling of the support surface. If necessary, move sideways the book covering machine by 5-10 cm until obtaining a perfect leveling.




- Do not operate the unit remaining seated and do not exert pressure on the cycle start levers moving the arms, but rather keep the arms stiff and bend your bust. This allow you to apply a uniform and optimum pressure on both levers, thus limiting the effort.

- Keep the covers/envelopes in the same room where the covering machine is installed, to avoid sudden changes in material temperature.

CNTD...

3c After switching the power on and/or after a prolonged stop, run a control/pre-heating cycle (*idle cycle*), prior to starting a document/object covering cycle:



- Without inserting a cover/envelope in the trimming/welding slot, hold both cycle start levers and press them down firmly, applying the same pressure on both of them, to start the trimming/welding cycle.

- A **“Wait”** message shown on display indicates a cycle in progress.

- Keep the levers pressed until the flashing message “Finish” appears (cycle end signaling).

- Now the book covering machine is ready to be used.



Always wait until the LCD display shows the “FINISH” message, prior to release the cycle start levers.

4 *USER MANUAL*

Please consult the User Manual supplied with the unit for a detailed description of the **CoLibri Leonardo Book Covering Machine**, for information about its technical characteristics and for details about:

- The correct use of the unit.
- The procedure for wrapping softcover and hardcover books, putting documents into envelopes and packing objects/gifts
- The unit's maintenance.
- The troubleshooting.

leonardo
CoLibri System Covering Machine

It's a product:

CoLibri System S.p.A.
Viale Ortles, 54/a
I - 20139 Milano - ITALY
Telefono: (+39) 02 5220 181
Telefax: (+39) 02 5220 1820

