

You can read the recommendations in the user guide, the technical guide or the installation guide for DELONGHI DEHUMIDIFIER DEM10. You'll find the answers to all your questions on the DELONGHI DEHUMIDIFIER DEM10 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

> User manual DELONGHI DEHUMIDIFIER DEM10 User guide DELONGHI DEHUMIDIFIER DEM10 Operating instructions DELONGHI DEHUMIDIFIER DEM10 Instructions for use DELONGHI DEHUMIDIFIER DEM10 Instruction manual DELONGHI DEHUMIDIFIER DEM10



Your user manual DELONGHI DEHUMIDIFIER DEM10

## Manual abstract:

• Do not install the appliance in rooms containing gas, oil or sulphur. Do not install near sources of heat. • Do not use the appliance on sloping surfaces. • Keep the appliance at least 50 cm away from flammable substances (alcohol etc) or pressurised containers (e.g. aerosol cans). • Do not rest heavy or hot objects on top of the appliance. • Clean the air filter regularly. • Always transport the appliance upright or resting on one side. Remember to drain the condensate tank before moving the appliance.

Wait at least 1 hour after transporting the appliance before starting it · R134a refrigerant complies with EEC environmental standards. However, you should avoid perforating the refrigerant circuit. At the end of its working life, consign the appliance to a specialist collection centre. · The materials used for packaging can be recycled. You are therefore recommended to dispose of them in special differentiated waste collection containers.

• Do not use the appliance outdoors. • Do not obstruct the air intake or outlet. Assi El stance Keep the list of Service Centres and identify the Centre nearest you. ectrical connections Before using for the first time, the dehumidifier should be stood upright for 24 hours. Failure to respect this safety rule absolves the manufacturer from all liability.

This appliance is manufactured in compliance with ECC standard EN55014 on the suppression of radio interference. The cable must be replaced by approved service personnel only. After moving the appliance, wait at least an hour before turning it on again. Before plugging the appliance into the mains socket, check that: • The mains power supply corresponds to the power supply indicated on the rating plate. • The power socket and electrical circuit are adequate for the appliance. • The power socket matches the plug. If this is not the case, have the plug replaced by a qualified electrician; • The power socket is adequately earthed. 13 ENGLISH Installation tion the appliance in the room to be dehumidified: A free space of at least 50 cm must be left at the front and back of the dehumidifier, so as not to block the air intake or outlet. Do not place the dehumidifier next to a radiator or other heat source as this will reduce its performance. For ongoing usage we suggest positioning in a hallway or on a landing.

Please remember to keep internal door ajar to allow circulation. The water collected (condensate) can be drained in one of the two ways: A) Draining into the tank The condensate can be drained directly into the tank (fig.1). The tank can be easily removed (fig.1). Posi fig. 1 B) Continuous external draining If the appliance is to be operated for long periods but you are unable to empty the tank regularly, you are recommended to use the continuous drain facility. 1) Remove the continuous drain cap (8) and the rubber bung (see figure 2). 2) Fasten the rubber hose to the spout. For models supplied without drain hose, we suggest you purchase a rubber hose around 2m long, with an internal diameter of 13.

5 mm. 3) Make sure the end of the hose is no higher than the spout or water could remain in the tank. Check there are no kinks in the hose (Fig. 3). N. B.: Keep the rubber bung. You will need it to plug the hose or close the spout if you revert to draining into the tank. (see point A) fig. 3 NO YES fig.
2 14 How to dehumidify to dehumidify 1) Plug the appliance into a mains socket. 2) Make sure the "tank full/tank missing" light is off. If it is on, position the tank correctly or empty it. 3) Turn the humidistat dial to one of the positions between OFF and CONTINUOUS. The ON light indicates that the appliance is dehumidifying. With the humidistat turned to "CONTINUOUS", the appliance is on all the time. Tank full/tank missing light Dehumidifying/low-temperature standby light ON light Humidistat dial To easily select the right humidity level, we suggest you operate as follows: Turn the humidistat dial clockwise as far as it wil go to the continuous position. Leave the unit on this seting until signs of excess moisture (e.g. condensation on windows) decreases.

This can take several weeks at this point slowly turn the humidistat knob anticlockwise until the appliance switches off.



## <u>Your user manual</u> DELONGHI DEHUMIDIFIER DEM10