

TROUBLESHOOTING FREQUENTLY ASKED QUESTIONS

TROUBLE	PROBABLE CAUSE	SOLUTION
Unit does not turn on	Not plugged in	Plug in unit
Mist output minimal to none	Filter has not absorbed water	Wait 15 minutes for filter to absorb water
Filter turns brown	The filter has absorbed minerals	Replace your filter (HWF62) by calling 1-800-546-5637, or visit www.holmesproducts.com

FREQUENTLY ASKED QUESTIONS

QUESTIONS	ANSWER
What are the variables that affect run time?	The estimated run time for this humidifier is based on average room conditions. The actual run time of your humidifier is dependent on numerous variables such as: - Air exchange in the room where the humidifier is placed. - Room construction where the humidifier is placed. - Temperature of the room where the humidifier is placed. - Humidity levels in the room where the humidifier is placed. - Movement of occupants and the opening and closing of doors in the room where the humidifier is placed. - Home furnishings in the room where the humidifier is placed.
How do I remove film on water tank?	See Daily Maintenance instructions. Regular cleaning is recommended.
How can I extend the run time?	- Run your unit on the lowest setting. - If your unit has electronics, set it to your desired humidity level. The unit will turn on and off, which will extend the run time. - Fill the tank all the way full, place it on the base, let the water empty into the base until it stops bubbling, then refill the tank full again. This ensures maximum water capacity and will extend run time.

DÉPANNAGE QUESTIONS FRÉQUEMMENT DEMANDÉES

PROBLÈME	CAUSE PROBABLE	SOLUTION
L'appareil ne s'allume pas.	L'appareil n'est pas branché.	Branchez l'appareil.
Jet de vapeur minime ou inexistant	Le filtre n'a pas absorbé l'eau.	Attendez 15 minutes, le temps que le filtre absorbe l'eau.
Le filtre brunit.	Le filtre a absorbé des minéraux.	Remplacez votre filtre (HWF62). Téléphonez au 1-800-546-5637 ou visitez www.holmesproducts.com

QUESTIONS FRÉQUEMMENT DEMANDÉES

QUESTIONS	RÉPONSE
Quelles sont les variables affectant la durée de fonctionnement?	La durée de fonctionnement de cet humidificateur se base sur des conditions d'environnement moyennes. La durée de fonctionnement réelle de votre humidificateur dépend de plusieurs variables, telles : - L'échange d'air dans la pièce où est installé l'humidificateur. - L'aménagement de la pièce où est installé l'humidificateur. - La température de la pièce où est installé l'humidificateur. - Le niveau d'humidité de la pièce où est installé l'humidificateur. - Le déplacement des habitants et l'ouverture ou la fermeture de portes de la pièce où est installé l'humidificateur. - Les meubles dans la pièce où est installé l'humidificateur.
Comment puis-je retirer la pellicule du réservoir?	Référez-vous aux instructions d'entretien quotidien. Un nettoyage régulier est recommandé.
Comment puis-je prolonger la durée de fonctionnement?	- Faites fonctionner votre appareil au réglage le plus bas. - Si votre appareil est doté d'une commande électronique, réglez-le au niveau d'humidité désiré. L'appareil s'allumera et s'éteindra, ce qui prolongera sa durée de fonctionnement. - Remplissez complètement le réservoir, placez-le sur la base, laissez l'eau se verser dans la base jusqu'à ce que les bulles cessent, et remplissez à nouveau le réservoir. Ceci garantit une capacité d'eau maximale et prolonge la durée de fonctionnement.

REPLACEMENT ACCESSORIES

REPLACEMENT ACCESSORIES

To order the replacement accessories you can do any of the following:

- Fill out the accessories card found with the product
- Visit your local retailer
- Go to www.holmesproducts.com

SERVICE INSTRUCTIONS

- DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void the Warranty.
- If you need to exchange the unit, please return it in its original carton, with a sales receipt, to the store where you purchased it. If you are returning the unit more than 30 days after the date of purchase, please see the enclosed Warranty.
- If you have any questions or comments regarding this unit's operation or believe any repair is necessary, please write to our Consumer Service Department or visit our website at www.holmesproducts.com.
SUNBEAM PRODUCTS, INC., DOING BUSINESS AS JARDEN CONSUMER SOLUTIONS
303 NELSON AVENUE
NEOSHO, MO 64850

For your own records, staple or attach your sales receipt to this manual. Also, please take a moment to write the store name/location and date purchased below.

STORE NAME:	
LOCATION:	
DATE PURCHASED:	(STAPLE RECEIPT HERE)

© 2007 Sunbeam Products, Inc., doing business as Jarden Consumer Solutions. All Rights Reserved.

INSTRUCTIONS D'ENTREPOSAGE

INSTRUCTIONS D'ENTREPOSAGE

Si vous n'avez pas l'intention d'utiliser l'humidificateur pour une période prolongée :

- Jetez le filtre. NE le laissez PAS dans l'appareil.
- Nettoyez et séchez bien l'humidificateur selon les directives de la section « Entretien hebdomadaire ». NE laissez PAS de l'eau dans l'appareil lors de l'entreposage. Le fait de laisser de l'eau dans l'appareil pourrait rendre l'appareil inutilisable pour la prochaine saison.
- Placez l'humidificateur dans la boîte originale et rangez-la à un endroit frais et sec.
- Commandez un filtre de rechange Holmes pour la prochaine saison d'utilisation.

ACCESSOIRES DE RECHANGE

Pour commander des accessoires de rechange, procédez d'une des façons suivantes :

- Remplissez la carte d'accessoire fournie avec le produit
- Visitez votre détaillant local
- Rendez vous au www.holmesproducts.com

INSTRUCTIONS RELATIVES AU SERVICE

- Ne tentez PAS de réparer ou d'ajuster les fonctions électriques ou mécaniques de cet appareil. Cette action entraînera l'annulation de la Garantie.
- Si vous avez des questions au sujet du fonctionnement de cet appareil, ou si vous croyez que des réparations sont nécessaires, veuillez écrire à notre service à la clientèle.
- Si vous devez échanger l'appareil, veuillez le retourner dans sa boîte d'origine, accompagné d'un reçu de vente, au magasin où vous en avez fait l'achat. Si vous retournez l'appareil plus de 30 jours après la date d'achat, veuillez consulter la Garantie ci-incluse.
- Pour toute question ou commentaire au sujet du fonctionnement de cet appareil, ou si vous croyez que des réparations sont nécessaires, veuillez écrire à notre service à la clientèle ou visitez notre site web au www.holmesproducts.com.
SUNBEAM PRODUCTS, INC., FAISANT AFFAIRES SOUS LE NOM DE JARDEN CONSUMER SOLUTIONS
303 NELSON AVENUE
NEOSHO, MO 64850

Pour vos dossiers, agrafez ou fixez votre reçu de vente à ce guide. Prenez également quelques secondes pour noter ci-dessous le nom et l'adresse du magasin ainsi que la date d'achat.

NOM DU MAGASIN :	
ENDROIT :	
DATE D'ACHAT :	(AGRAFEZ LE REÇU ICI)

© 2007 Sunbeam Products, Inc., exerçant ses activités sous le nom de Jarden Consumer Solutions. Tous droits réservés.

WARRANTY INFORMATION

3 YEAR LIMITED WARRANTY

Sunbeam Products, Inc., doing business as Jarden Consumer Solutions or if in Canada, Sunbeam Corporation (Canada) Limited doing business as Jarden Consumer Solutions (collectively "JCS") warrants that for a period of three years from the date of purchase, this product will be free from defects in material and workmanship. JCS, at its option, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty. Do NOT attempt to repair or adjust any electrical or mechanical functions on this product. Doing so will void this warranty.

This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. JCS dealers, service centers, or retail stores selling JCS products do not have the right to alter, modify or any way change the terms and conditions of this warranty.

This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, use on improper voltage or current, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than JCS or an authorized JCS service center. Further, the warranty does not cover: Acts of God, such as fire, flood, hurricanes and tornadoes.

What are the limits on JCS's Liability?

JCS shall not be liable for any incidental or consequential damages caused by the breach of any express, implied or statutory warranty or condition.

Except to the extent prohibited by applicable law, any implied warranty or condition of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty.

JCS disclaims all other warranties, conditions or representations, express, implied, statutory or otherwise.

JCS shall not be liable for any damages of any kind resulting from the purchase, use or misuse of, or inability to use the product including incidental, special, consequential or similar damages or loss of profits, or for any breach of contract, fundamental or otherwise, or for any claim brought against purchaser by any other party.

Some provinces, states or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights that vary from province to province, state to state or jurisdiction to jurisdiction.

How to Obtain Warranty Service

In the U.S.A.

If you have any question regarding this warranty or would like to obtain warranty service, please call 1-800-546-5637 and a convenient service center address will be provided to you.

In Canada

If you have any question regarding this warranty or would like to obtain warranty service, please call 1-800-546-5637 and a convenient service center address will be provided to you.

In the U.S.A., this warranty is offered by Sunbeam Products, Inc., doing business as Jarden Consumer Solutions located in Boca Raton, Florida 33431. In Canada, this warranty is offered by Sunbeam Corporation (Canada) Limited doing business as Jarden Consumer Solutions, located at 5975 Falbourn Street, Mississauga, Ontario L5R 3V8. If you have any other problem or claim in connection with this product, please write our Consumer Service Department. **PLEASE DO NOT RETURN THIS PRODUCT TO ANY OF THESE ADDRESSES OR TO THE PLACE OF PURCHASE.**

Printed in China

RENSEIGNEMENTS SUR LA GARANTIE

GARANTIE LIMITÉE DE 3 AN

Sunbeam Products, Inc., faisant affaires sous le nom de Jarden Consumer Solutions ou, si au Canada, Sunbeam Corporation (Canada), faisant affaires sous le nom de Jarden Consumer Solutions (collectivement, « JCS »), garantit que, pendant trois ans à compter de la date d'achat, ce produit sera exempt de toute defectuosité matérielle ou de main-d'œuvre. JCS se réserve le droit de choisir entre réparer ou remplacer cet article ou toute pièce de celui-ci dont la defectuosité a été constatée au cours de la période de garantie. Le remplacement se fera au moyen d'un produit neuf ou remanufacturé ou bien d'une pièce neuve ou remanufacturée. Si l'article n'est plus disponible, il sera remplacé par un article semblable, de valeur égale ou supérieure. La présente constitue votre garantie exclusive. NE TENTEZ PAS de réparer ou de régler une fonction électrique ou mécanique de ce produit. Ce faisant, vous annulerez cette garantie.

Cette garantie n'est valable que pour l'acheteur au détail original à partir de la date de l'achat au détail initial et elle n'est pas transférable. Veuillez conserver le reçu d'achat original. La preuve d'achat est exigée pour tout service couvert par la garantie. Les concessionnaires JCS, les centres de service et les détaillants qui vendent des articles JCS n'ont pas le droit d'altérer, de modifier ou de changer d'une manière quelconque les modalités de cette garantie.

Cette garantie ne couvre pas l'usure normale des pièces ou l'endommagement attribuable à la négligence, à l'utilisation abusive du produit, au branchement sur un circuit de tension ou courant inapproprié, au non-respect du mode d'emploi, au démontage et à la réparation ou à l'altération par quiconque, sauf JCS ou un centre de service agréé JCS. Cette garantie ne couvre pas non plus les cas de force majeure comme incendies, inondations, ouragans et tornades.

Quelles sont les limites de la responsabilité de JCS?

JCS n'assume aucune responsabilité pour les dommages accessoires ou indirects résultant du non-respect de toute garantie ou condition explicite, implicite ou générale.

Sauf dans la mesure interdite par la législation pertinente, toute garantie implicite de qualité marchande ou d'application à un usage particulier est limitée à la durée de la garantie ou condition ci-dessus.

JCS décline toutes autres garanties, conditions ou représentations expresses, sous-entendues, générales, ou autres.

JCS n'assume aucune responsabilité pour les dommages, quels qu'ils soient, résultant de l'achat, de l'utilisation normale ou abusive ou de l'incapacité à utiliser le produit, y compris les dommages accessoires, les dommages-intérêts particuliers, les dommages immatériels et les dommages similaires ou pertes de profits; ou bien pour les violations de contrat, fondamentales, ou autres, ou les réclamations contre l'acheteur par un tiers.

Certaines provinces ou juridictions et certains états interdisent d'exclure ou de limiter les dommages accessoires ou indirects, ou ne permettent pas la limitation de la durée d'application de la garantie implicite, de sorte que vous pouvez ne pas être assujéti aux limites ou exclusions énoncées ci-dessus.

Cette garantie vous confère des droits juridiques précis et vous pouvez avoir d'autres droits, ces droits variant d'une province, d'un état ou d'une juridiction à l'autre.

Comment obtenir le service prévu par la garantie

Aux États-Unis

Pour toute question en ce qui concerne la garantie ou pour obtenir le service que prévoit la garantie, composez le 1-800-546-5637 et nous vous fournirons l'adresse d'un centre de service proche.

Au Canada

Pour toute question en ce qui concerne la garantie ou pour obtenir le service que prévoit la garantie, composez le 1-800-546-5637 et nous vous fournirons l'adresse d'un centre de service proche.

Aux États-Unis, cette garantie est offerte par Sunbeam Products Inc., faisant affaires sous le nom de Jarden Consumer Solutions, située à Boca Raton, Floride 33431. Au Canada, cette garantie est offerte par Sunbeam Corporation (Canada), exerçant ses activités sous le nom de Jarden Consumer Solutions, située au 5975, rue Falbourn, Mississauga (Ontario) L5R 3V8. Si vous éprouvez tout autre problème ou si vous désirez effectuer toute autre réclamation quant à ce produit, veuillez écrire à notre service à la clientèle. **NE RETOURNEZ CE PRODUIT NI A L'UNE DES ADRESSES CI-DESSUS NI AU LIEU D'ACHAT.**

9100030004360

HM2408UC07EFM1

Imprimé en Chine

Holmes®

Owner's Guide

HM2408

☎ INFO HOT-LINE: If, after reading this owner's guide you have any questions or comments, please call 1-800-546-5637 and a Customer Service Representative will be happy to assist you.

FILTER#: HWF62
FILTER TYPE: WICK



Cool Mist

Humidifier

PLEASE READ AND SAVE THESE IMPORTANT INSTRUCTIONS

Holmes®

Guide D'utilisation

HM2408

☎ LIGNE DE RENSEIGNEMENTS : Si, après avoir lu ce guide d'utilisation, vous avez des questions ou des commentaires, veuillez nous téléphoner au 1-800-546-5637 et un représentant au service à la clientèle sera heureux de vous aider.

FILTER#: HWF62
TYPE DE FILTRE : À MÈCHE



Brume Froide

Humidificateur

VEUILLEZ LIRE ET CONSERVER CES DIRECTIVES IMPORTANTES


PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

Thank you for purchasing this Holmes® product. We understand the value of quality and are committed to making superior products that stand the test of time. We trust this product will exceed your expectations of quality and reliability. We hope that you enjoy this product and will consider purchasing another Holmes® product in the future.

To see our full product line or if you have any questions or comments about this product, please visit our website at: www.holmesproducts.com.

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Read all instructions before using the appliance.
2. To avoid fire or shock hazard, plug the appliance directly into a 120V AC electrical outlet.
3. Keep the cord out of heavy traffic areas. To avoid fire hazard, NEVER put the cord under rugs or near heat registers.
4. DO NOT place humidifier near heat sources such as stoves, radiators, and heaters. DO locate your humidifier on an inside wall near an electrical outlet. The humidifier should be at least 4" away from the wall for best results.
5. NEVER place humidifier in an area where it is accessible to children. NEVER use humidifier in a closed room, particularly where a child may be sleeping, resting, or playing (a closed room may result in excessive humidity).
6. **WARNING:** Do not attempt to refill humidifier without first unplugging the unit from its electrical outlet. Failure to heed this warning may cause personal injury. Be sure to unplug the unit by pulling on the plug and not the cord.
7. Never place anything over moisture outlet when the unit is running.



THIS APPLIANCE HAS A POLARIZED PLUG (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet.


DO NOT ATTEMPT TO MODIFY THIS PLUG OR DEFEAT THIS SAFETY FEATURE IN ANY WAY.

VEUILLEZ LIRE ET CONSERVER CES CONSIGNES DE SÉCURITÉ IMPORTANTES

Merci d'avoir acheté ce produit Holmes®. Nous connaissons la valeur que vous accordez à la qualité. C'est pourquoi nous nous engageons à fabriquer des produits de qualité supérieure qui résisteront au temps. Nous savons que ce produit rencontrera vos attentes en terme de qualité et de fiabilité. Nous espérons que vous apprécierez ce produit et que vous achèterez à nouveau des produits Holmes®. Si vous avez des questions ou si vous souhaitez découvrir notre gamme de produits, visitez notre site Web : www.holmesproducts.com.

Lors de l'usage de tout appareil électrique, des précautions fondamentales doivent être observées pour réduire le risque d'incendie, de choc électrique, et de blessure, y compris celles-ci:

1. Lisez toutes les directives avant d'utiliser cet appareil.
2. Pour éviter le risque de choc électrique, branchez l'humidificateur directement dans une prise électrique CA 120 V.
3. Tenez le cordon d'alimentation éloigné des aires acheminées. Pour éviter tout risque d'incendie, ÉVITEZ de placer le cordon d'alimentation sous des moquettes, ou près de tout appareil de chauffage.
4. ÉVITEZ de placer l'humidificateur près de sources de chaleur comme des cuisinières, radiateurs ou chaufferettes. PLACEZ-LE plutôt près d'un mur intérieur et d'une prise murale. Pour de meilleurs résultats, l'humidificateur doit être placé à au moins 4 po du mur.
5. NE placez JAMAIS l'humidificateur à un endroit où il serait accessible aux enfants. N'utilisez jamais l'humidificateur dans une pièce fermée, particulièrement où un enfant dort, se repose ou joue (une pièce fermée peut donner lieu à un niveau excessif d'humidité).
6. **AVERTISSEMENT:** ne pas tenter de remplir l'humidificateur sans tout d'abord le débrancher. Le fait de manquer d'observer cette consigne peut causer des blessures. Assurez-vous de débrancher l'appareil en tirant sur la fiche plutôt que sur le cordon.



CET APPAREIL EST DOTÉ D'UN CORDON À FICHE POLARISÉE (une lame est plus large que l'autre). Afin de réduire les risques d'électrocution, cette fiche ne s'insère que d'un seul sens dans la prise électrique. Si la fiche ne s'insère pas dans la prise, retournez la fiche. Si elle ne s'adapte toujours pas, contactez un électricien qualifié afin d'installer la prise appropriée.

NE CONTOURNEZ PAS CE DISPOSITIF DE SÉCURITÉ ET N'ALTÉREZ LA FICHE D'AUCUNE FAÇON.

IMPORTANT SAFETY INSTRUCTIONS FEATURES - OPERATIONS

level is in excess of 50%. Use a hygrometer, available at your local retailer or through the manufacturer, to measure the humidity.

20. DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void your warranty. The inside of the unit contains no user serviceable parts. All servicing should be performed by qualified personnel only.

21. Never place housing under water flow or immerse in liquids.

22. Do not plug in the cord with wet hands: electric shock could result.

23. Do not pour water in any openings other than the water tank.

24. To prevent damage to surfaces, do not place humidifier under overhanging surfaces.

25. NEVER operate unit without water in the tank.

26. Do not move unit after it has been used until unit cools completely.

27. Use both hands when carrying full tank of water.

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

Consumer Safety Information

NOTE: This is an electrical appliance and requires attention when in use.

NOTE: If moisture forms on the walls or windows of the room, turn off the humidifier. The room already has plenty of humidity and additional moisture may cause damage.

NOTE: DO NOT block air inlet or outlet.

Cord and Plug Installation Safety Instructions

The length of cord used on this appliance was selected to reduce the hazards of becoming tangled in, or tripping over a longer cord. If a longer cord is necessary an approved extension cord may be used. The electrical rating of the extension cord must be equal to or greater than the rating of the humidifier. Care must be taken to arrange the extension cord so that it will not drape over the countertop or tabletop where it can be pulled on by children or accidentally tripped over.

HOW COOL MIST WORKS

Your Holmes® Cool Mist humidifier draws dry air through the rear air intake grill area. This air is then passed through a moisture-laden wick filter, which retains the minerals and deposits in the water. The resulting moist air is directed back into the room from the top air grill.

NOTE: This humidification system provides a cool, invisible moisture output. It is normal not to see the mist.


NOTE: A humidity level below 20% can be unhealthy and uncomfortable. The recommended humidity level is between 40%-50%.

PRE-OPERATING INSTRUCTIONS

1. Be sure the humidifier is switched to OFF and the unit is disconnected from the electrical outlet.
2. Select a location for your humidifier, on a flat surface, about 4" away from the wall. DO NOT place the humidifier on a finished floor or near furniture, which can be damaged by moisture or water. Place on a moisture-resistant surface.

OPERATING INSTRUCTIONS

Your humidifier is equipped with a technologically advanced 1Touch® Electronic Humidistat. You can set the humidifier to run continuously in manual mode or set the 1Touch® Electronic Humidistat to your desired humidity setting. The 1Touch® Electronic Humidistat will automatically turn the humidifier ON or OFF depending on the preset comfort level. The comfort level ranges between 35% and 55% relative humidity.



FEATURES - OPERATIONS REPLACING INSTRUCTIONS

Manual Mode Instructions:

1. Plug the humidifier into a 120V AC electrical outlet.
2. To start the unit, push the MODE/OFF button once for the HIGH (HI) manual setting.
3. Press the button again for the LOW (LO) manual setting.
4. To stop the unit, press and hold the button for two seconds, or keep pressing the button until all the humidity indicators are OFF.

NOTE: In Manual Mode, only the LOW or HIGH power light will be lit.

1TOUCH® HUMIDISTAT INSTRUCTIONS

To take advantage of the 1Touch® Electronic Humidistat, press the MODE/OFF button until the speed is set in either the HIGH or LOW setting, and the Desired Humidity is set. When the humidity level rises above the set humidity, the humidifier will stop. When the humidity level drops below the set humidity, the humidifier will turn on automatically.

NOTE: When the 1Touch® Electronic Humidistat is set, either the HIGH or LOW power light and the percent humidity light will remain lit during operation.

NOTE: Allow up to 30 minutes for the filter to fully absorb water and for the unit to produce moisture.

NOTE: The 1Touch® Humidifier has memory. This means that when you turn the unit back on, it will be at the last setting the humidifier was set at.

If you do not plan to use the humidifier for two or more days, make sure any residual water is drained from the water tank, base and wick filter to prevent algae or bacteria growth.

EXTENDED RUN TIME SETTING

By setting your humidifier to a specific humidity level, you are actually also extending the run time. Since the unit will turn on and off to maintain the set humidity level, less water will be used, so you will need to fill the unit less than you would on manual setting.

REPLACING THE FILTERS

Through normal use, waterborne minerals and sediment become trapped in the wick filter. The harder your water,

the greater the amount of minerals in the water, and the more often you will need to change your filter.

You will be able to monitor the life of the filter in your humidifier by checking the FilterCheck® Indicator. After 60 minutes of use, FilterCheck® Indicator will move and indicate your filter condition. A brand new filter will



register in the section reading GOOD filter. After frequent use of your humidifier, the FilterCheck® Indicator will let you know when the filters need to be changed, see Figure 2.

When the needle is in the CHANGE section, this means the proper amount of moisture is not getting into your air due to the excessive minerals and sediment that have become trapped on your filters. At this point, you should replace your filter. It is important to change your filter as indicated to obtain stated performance level.

To replace the filter, follow the steps below:

1. Turn the unit off and disconnect from the electrical outlet.
2. Remove the tank and main housing to access the base tray.
3. Remove wick and discard.
4. Follow the weekly cleaning instructions.
5. Insert new filter.
6. Repeat Operating Instructions steps.

It will take about 30 minutes for the humidifier to reach maximum output.

You can purchase replacement filters (model HWF62) at a local retailer, by calling 1-800-546-5637, filling out the accessory card, or by visiting www.holmesproducts.com. It is recommended that a replacement filter is purchased for uninterrupted use.

CARACTÉRISTIQUES – UTILISATION REMPLACEMENT DU FILTRE

CONSIGNES D'UTILISATION

Votre humidificateur est doté de la technologie évoluée d'humidostat électronique 1Touch®. Vous pouvez régler l'humidificateur en mode de fonctionnement continu ou régler l'humidostat électronique 1Touch® au niveau d'humidité désiré. L'humidostat électronique 1Touch® allume et éteint automatiquement l'humidificateur, selon le niveau de confort sélectionné. Le niveau de confort varie entre 35 % et 55 % d'humidité relative.

REMARQUE: Lorsque l'humidostat électronique 1Touch® est réglé, le témoin ELEVE ou FAIBLE s'allume et le témoin de pourcentage d'humidité demeure allumé pendant le fonctionnement.


REMARQUE: Attendez 30 minutes pour que le filtre absorbe entièrement l'eau et que l'appareil produise de l'humidité.

REMARQUE: L'humidificateur 1Touch® est doté d'une mémoire. Ceci signifie que lorsque vous l'allumez à nouveau, il se rappelle du dernier réglage d'humidité. Si vous n'avez pas l'intention d'utiliser votre humidificateur pendant deux jours ou plus, assurez-vous que le reste d'eau est retiré du réservoir, de la base et du filtre de la mèche afin d'éviter la prolifération de bactéries.

REMARQUE: En mode manuel, seul le bouton d'alimentation LO ou HI sera allumé.

INSTRUCTIONS POUR L'HUMIDOSTAT 1TOUCH®

Lorsque le niveau d'humidité dépasse le niveau préréglé, l'humidificateur s'arrête. Lorsque le niveau d'humidité tombe en deca du niveau préréglé, l'humidificateur se met automatiquement en fonction.



1. Assurez-vous que l'humidificateur est éteint (OFF) et débranché.
2. Choisissez un emplacement pour votre humidificateur: une surface plane à environ 4 po du mur. NE PLACEZ PAS l'humidificateur sur un plancher verni ou près d'un meuble: ils pourraient être endommagés par l'eau ou l'humidité. Placez-le sur une surface résistante à l'humidité.

CLEANING/MAINTENANCE STORAGE INSTRUCTIONS

CLEANING AND MAINTENANCE INSTRUCTIONS

Humidifiers provide comfort by adding moisture to dry, heated indoor air. To benefit most from the humidifier, and avoid product misuse, follow all instructions carefully. Please note that this is an electrical appliance and requires attention when in use.

In addition, if you do not follow the recommended care and maintenance guidelines, micro-organisms may be able to grow in the water within the water tank. You must routinely follow the cleaning procedures that follow in order to ensure proper, efficient operation of your humidifier. Proper maintenance and cleaning is essential to the continued performance of your unit and the avoidance of algae or bacteria build-up.

DAILY MAINTENANCE

1. Be sure the unit is OFF and is disconnected from the electrical outlet.
2. Remove the housing and the tank from the humidifier and place in sink or tub.
3. Carry the base of the unit to the sink, remove the wick, place in sink, drain any remaining water and rinse thoroughly to remove any sediment or dirt. Wipe clean, and dry with a clean cloth or paper towel. The base is dishwasher safe (TOP RACK ONLY) for easy cleaning.
4. Drain the water from the tank into the sink and rinse tank thoroughly. Wipe clean, and dry with a clean cloth or paper towel.
5. Put filter back in, replace the housing, then refill tank with cool tap water as instructed earlier in the Filling Instructions. Do not overfill.
6. Follow Operating Instructions.

WEEKLY MAINTENANCE

To Remove Scale:

1. Repeat steps 1-4 above.
2. Clean the base by partially filling the base with one 8-oz cups of undiluted white vinegar, or by using Cleanse Clean™ (Model S1710) by the manufacturer. Leave this solution in the base for 20 minutes, while cleaning the all interior surfaces with a soft brush. Remove base scale by wiping the base with a cloth dampened with undiluted white vinegar.
3. Rinse with clean warm water to remove the cleaning solution before disinfecting the tank.

To Disinfect Humidifier Base and Tank:

1. Fill humidifier tank 1/2 full with water and 1/2 tablespoon of chlorine bleach.
2. Let the solution stand for 20 minutes, swishing every few minutes. Wet all surfaces.
3. Carefully empty the tank after 20 minutes, and rinse with warm water until you cannot detect any bleach smell. Dry with a clean cloth or paper towel.
4. Place filter back into base and refill tank as directed in Operating Instructions, and turn the unit on.

STORAGE INSTRUCTIONS

When not using your humidifier for an extended period of time:

1. Dispose of the filters. DO NOT leave in unit.
2. Clean, rinse and thoroughly dry the humidifier as directed in weekly maintenance. DO NOT leave any water in the unit when storing. Leaving water in the unit may render the unit inoperable for the following season.
3. Place the humidifier in the original carton and store in a cool, dry place.
4. Order your replacement filter for next year's use.

INSTRUCTIONS DE NETTOYAGE ET D'ENTREREN

d'humidité à cause de la quantité excessive de minéraux et de dépôts qui sont sur le filtre. Dans ce cas, vous devriez remplacer le filtre. Il est essentiel de remplacer le filtre tel qu'indiqué afin d'obtenir le rendement spécifié.

Pour remplacer le filtre, suivez les étapes ci-dessous:

1. Éteignez l'appareil et débranchez-le.
2. Retirez le réservoir et le boîtier principal pour accéder au plateau de base.
3. Retirez la mèche et jetez-la.
4. Suivez les directives de nettoyage hebdomadaire.
5. Insérez le nouveau filtre.
6. Répétez les consignes d'utilisation.

L'humidificateur atteindra son rendement maximum après environ 30 minutes.

Vous pouvez obtenir un filtre de rechange (modèle HWF62) d'un détaillant local, en composant le 1-800-546-5637 (comment remplir la carte des accessoires) ou en visitant www.holmesproducts.com. Veuillez consulter la section sur les accessoires de rechange à la fin de ce guide. Nous vous recommandons d'acheter un filtre de rechange pour permettre un fonctionnement sans interruption.

INSTRUCTIONS DE NETTOYAGE ET D'ENTRETIEN

Les humidificateurs améliorent le niveau de confort en ajoutant de l'humidité à l'air sec d'intérieur. Pour mieux profiter de votre humidificateur et pour éviter un mauvais usage du produit, suivez attentivement toutes les instructions. Cet humidificateur est un appareil électrique et doit être surveillé lorsqu'il est en marche.

De plus, si vous ne suivez pas les instructions recommandées de nettoyage et d'entretien, des micro-organismes peuvent se reproduire dans l'eau du réservoir. Suivez régulièrement les procédures de nettoyage suivantes afin d'assurer le bon fonctionnement et l'efficacité de votre humidificateur. Le nettoyage et l'entretien régulier sont essentiels pour assurer le rendement continu de l'appareil et pour empêcher le développement d'algues ou de bactéries.

ENTRETIEN QUOTIDIEN

1. Assurez-vous que l'appareil est éteint et débranché.
2. Retirez le boîtier et le réservoir de l'humidificateur et placez-les dans l'évier ou la baignoire.