

The Wireless Intercom

Handset

User & Installation Guide



What's in the box?

<p>1x</p>  <p>CONNECTA HANDSET</p>	<p>1x</p>  <p>HANDSET CHARGING DOCK</p>	<p>1x</p>  <p>TRANSFORMER PLUG FOR HANDSET CHARGING DOCK</p>
<p>2x</p>  <p>AAA BATTERIES</p>	<p>1x</p>  <p>USER INSTALLATION GUIDE</p>	

Features



ERA Products Ltd,
Straight Road, Short Heath,
Willenhall, West Midlands WV12 5RA
Tel: 01922 490000
www.era-security.com
E-mail: info@era-security.com



ERA Locca Connecta Handset User Guide

INSTALLING THE HANDSET & CHARGING DOCK

1. Place the charging cradle on flat surface or rotate the base and attach to wall.
2. Plug charger into the base of charging cradle. **Fig.1**
3. Plug in to socket.
4. Open back of handset and insert rechargeable batteries (included in pack). **Fig.2**
5. Place handset on charging cradle. **Fig.3**
6. Your handset is now installed.

PROGRAMMING EXTRA HANDSETS INTO THE ERA LOCCA CONNECTA

(Please note: the handset supplied is already programmed to the speech panel)

1. Please note - rechargeable batteries should be inserted into handset.
2. Hold down the 'call' button on the speech panel (for around 5 seconds) until the button/nameplate backlight flashes once. **Fig.4**
3. Once the call button/nameplate light has flashed, press the 'call' button once, and then a second time. The nameplate light should now begin flashing.

4. Take the first handset and press and hold the open button for five seconds until the handset emits a short beep.

5. Press the open button for a second time. The light on the front of the handset will go red and the handset will begin beeping.

6. The system will now automatically log the handset into the speech panel. This can take up to 60 seconds.

7. To enter further handsets, please repeat the above process with each handset (up to a total of six).

PROGRAMMING HANDSETS TO WORK WITH AN ERA LOCCA ACCESS OR MULTI **To programme handsets into the ERA Locca Access or Multi, take the following simple steps:**

1. Press the 'call' button on the speech panel.

2. The handset will ring. Press the 'talk' button on the handset. The handset and speech panel are now connected.

3. Put the ERA Locca Access or Multi into 'learn key' mode.

[for the ERA Locca Access- press the red programming key twice] **Fig.5**

[for the ERA Locca Multi- press the red programming key once, scroll to 'Add Key' option, then press the red programming key again] **Fig.6**

Refer to the Locca Access or Multi user manual if necessary.

4. Press the 'open' button on the handset twice.

5. The ERA Locca Access or Multi will acknowledge safe learning of the handset.

6. Repeat this process (from step one) for each new handset.

To unlock the door

1. Press 'Talk' on the handset.

2. Then press 'Open'.

(this is a security feature to ensure you do not unlock the door by mistake).

GUARANTEE

Your ERA Locca system comes with a free one-year guarantee (from date of purchase) against mechanical defects.

IMPORTANT

The user should not attempt to service the unit or open the main casing.

TECHNICAL INFORMATION:

Handset:

- Operating range up to 200 metres line of sight in open area
- Ambient temperature range: 0° to 40°
- Environment humidity: 80% RH
- Adaptor Supply: 6Vdc 200mA
- First charging time for rechargeable batteries: 12 hours
- Use Locca adaptor with band Ktec and model number: KA23D060020033K
- Use only GP rechargeable batteries, with model number: GN60AAAHC. [2 X 1.2V 600mAh Ni-MH].

Caution

Risk of explosion if battery is replaced by incorrect type.
Dispose of used batteries according to instructions.

CE

Hereby, Locca Tech Ltd, declare that this Locca Connecta System is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.