

P1


User's Manual for Air Inflator SAI-102 for Cars



CE

Product Details:

1. Digital pressure gauge
2. PSI or Kg /cm2 selection switch
3. Tyre valve connector
4. 12V cigarette lighter connector
5. ON- OFF switch
6. Hose Connectors for other uses



Product Features

1. Suitable for all Cars and SUVs.
2. Fills up air in tyres in just minutes
3. Heavy duty motor for longer life
4. Digital pressure gauge for ease and accuracy
5. High temperature cut off for product safety.
6. Also suitable for balls, water pools and other domestic needs.
7. Handy in emergencies

P2

Operating Instructions Air Inflator SAI-102

Securide Air Inflators are very useful for maintaining the tyre pressures and for emergencies,. It is very easy to use. It will take just minutes to maintain the tyre pressure of all the tyres accurately with the help of Digital gauge.



Unscrew the valve cap for filling the air in the tyre.



Connect the cigarette lighter connector of the Air Inflator to Cigarette lighter socket in your Car. Light in the Digital pressure gauge will turn on.



In case of any problem with cigarette lighter, you can also use crocodile Connector adpoter to connect to vehicle battery (**not supplied with the product**).

P3



Pull the parking brake, keep gear in neutral and start the engine. It is recommended to keep the engine running during use.



Screw the Air Inflator Hose valve connector on the valve. Select PSI or Kg/cm2. Press the air Inflator ON / OFF switch to ON position.

Keep looking at the digital pressure gauge. When the desired pressure is achieved, turn off the Inflator.



Normally after switching off pressure reading will slightly drop, correct the pressure accordingly.

Now disconnect the Inflator hose from the valve and the Cigarette lighter connector.

Note :

1. **Do not use the Air Inflator for more than 10 minutes at a stretch, allow it to cool down for 10 minutes before reuse.**
2. Do not leave the air Inflator unattended.
3. Do not overinflate the tyres
4. Make sure that your cigarette lighter is free from ash or residues. A dirty cigarette lighter can cause Air Inflator and cord to overheat.
5. The Air Inflator is designed to for use only on 12V DC, do not attempt to use on any other source.

P4

Maintenance

Keep the Air inflator's hose valve connector clean so that there is no obstruction to air flow.

Advantages of maintaining the tyre pressure:

1. Improved Tyre life
2. Improved fuel consumption
3. Improved safety during drive.

During emergency of tyre puncture, you can repair your Tubeless Tyres without removing the tyre from the car , most of the time. Use our Tubeless Tyre Repair Kit SRK -101 for repair of the tyre and fill up air immediately using Securide Air Inflator. All within minutes.



Brought to you by:
Motocop

29, Pace City I, NH-8, Gurgaon-122001, India
Ph: +91 8285 888 000 email: customer.care@securide.in
Skype : securide.care www.securide.in