

CEP-30 Mosquito & Midge Trap



User Manual

Please read carefully before using this equipment and retain for future use

Important

This trap does not involve fogging, pesticides, repellents, citronella, coils or candles. It does not use dangerous or toxic chemicals known to be harmful to humans and the environment.

The CEP30 Mosquito Trap uses environmentally friendly methods and is safe to you and your environment.

How do CEP Mosquito Traps Work:

Female biting insects require blood to nourish their eggs. They track down hosts by sensing the carbon dioxide, Ocetanol, moisture and heat from human breath, body odours and colour contrasts. CEP Mosquito traps imitate all of these to attract insects into the trap. Once the insects are close by the fan sucks these inside the trap.

What to expect:

The CEP30 mosquito trap will begin to attract insects immediately; however it may take 6-8 weeks of use to reduce local populations to the point that breeding cycles are interrupted. You may choose to discontinue use of the trap at this point but subsequent re-infestations may occur.

What's in the box

- CEP30 Mosquito & Midge Trap
- Power Adaptor 230V. 25W, IP65
- Escape Free Catch Container
- Triple Attractant
- Hanging Hook
- User Manual

Installing the Attractant Cartridge



ATTENTION

Attention:

- Contains Sharp Objects, Take Care When Opening & In Use
- Contents of this product are non-toxic, however may be harmful if swallowed.
- Wash Hands Carefully After Use.
- Keep Away From Children & Out Of Reach

- **Turn the CEP30 OFF**
- Remove the bottom plate – turn anticlockwise to release
- Install the Triple Attractant Cartridge into the designated holder on the bottom of the plate. DO NOT open the lids, remove the stickers and pierce the lids with the supplied needle.
- Install the bottom plate – turn clockwise to lock
- Position the trap and it is now ready to use

Positioning for the best results

1. Determine the source of insects - they breed in wet and shaded areas.
2. Place the CEP30 between the mosquito source and areas of human activity - as far away from people and as close to the mosquitos as possible. **Attention:** Do not place the trap close to people as it attracts not repels mosquitos.
3. Place the trap in a location protected from direct rain and strong wind.
4. Place the trap away from direct sunlight and hang it close to the ground or position directly on the ground - if hanging do not exceed 40 - 60cm from the ground.

The CEP30 can be used indoors, but we strongly recommend not using the provided attractant as it will attract mosquitos from the outside.

Maintenance

Empty the catch container at least once a week or when necessary. The container can be found inside the CEP30:

- **Turn the CEP30 OFF**
- Remove the bottom plate (fig. 2)
- Turn the catch container anticlockwise to release (fig. 4)
- Empty the contents and make sure the mesh net is clean to maintain sufficient airflow
- Install the catch container back into the trap – turn clockwise to lock
- Install the bottom plate
- Position the trap and it is now ready to use

Important Safety Instructions

1. Always Disconnect the CEP30 from mains power when cleaning or emptying the container.
2. Never submerge or expose the trap to excess water.
3. Never use the trap if you have noticed any damage to the power cord, power supply or connectors.
4. Do not place the trap in direct sunlight or rain.
5. Keep your fingers away from the fan.
6. Always keep the trap away from children.

Troubleshooting

UV light and fan not working - Ensure the CEP30 is connected to the mains correctly and is switched on.

The fan is noisy or is blocked - Clean as recommended in “Maintenance”.

The UV light is not working - replace with new one - replacements can be purchased.

The trap is on, but does not catch mosquitos - move it to another location and test for at least a week.

Pay extra attention to the positioning of the trap in accordance with our recommendations. Also ensure the trap is no higher than 40-60 cm from the ground and away from direct sunlight and rain.

This Is How It Works

The CEP30 Mosquito Trap uses the most environmentally friendly methods and is safe to you and your environment.

It attracts mosquitos and other flying pests using 6 different methods of imitating the human body. Once the insects are in close proximity to the trap, the fan sucks them into the escape free catch container.

We recommend emptying the container once a week or more often if required.

The supplied Bait attractant imitates human body odours to increase the catch rate by up to 4 times. It will last around 30 days with typical usage and additional cartridges can be purchased.

The CEP30 has been designed to reduce mosquito populations. It may take several weeks before the breeding process is broken and the population is under control.

The CEP 30 has not been designed to compete with humans in close proximity e.g. at a barbeque. If you are planning an outdoor event we recommend operating the CEP30 for at least a week before it takes place.

Installing The Attractant And Removing The Catch Container



Fig. 1 Using the supplied needle, pierce each container in the dedicated spots. DO NOT open the containers



Fig. 2 Turn the bottom plate anticlockwise



Fig. 3 Place the attractant cartridges in the dedicated holder on the bottom plate with pierced openings facing up.



Fig. 4 To remove the catch container turn it anti clockwise.

Important Information

1. Please note - All the safety and operating instructions should be read before the appliance is operated.
2. Retain Instructions - The safety and operating instructions should be retained for future reference.
3. Heed Warnings - All warnings on the appliance and in the operating instructions should be adhered to.
4. Follow Instructions - All operating and usage instructions should be followed.
5. Water and Moisture - The appliance should not be used near water, for example, near a bathtub, washbowl, kitchen sink, washing machine, in a wet basement or near a swimming pool.
6. Power Sources - The appliance should be powered only as described in these operating instructions or as marked on the appliance.
7. Do not leave the unit unattended while in use.
8. This electric product is not a toy! To avoid risk of fire, burns, personal injury and electric shock keep out of reach of children.
9. Do not use this product for other than its intended use.
10. Do not close doors or windows on the product or extension cords as this may damage the wire insulation.
11. Electrical ratings of the extension cord must be as high as, or higher than the electrical ratings of the product.
12. Do not cover the product with cloth, paper or any material that is not part of the product when it is in use.
13. CAUTION - to reduce the risk of fire do not deliberately reposition pins on the plug assembly.
14. WARNING: Keep unit and power cord out of reach of children.
15. ALWAYS switch off at the mains socket when not in use.



Attention:

- Contains Sharp Objects, Take Care When Opening & In Use
- Contents of this product are non-toxic, however may be harmful if swallowed.
- Wash Hands Carefully After Use.
- Keep Away From Children & Out Of Reach

Need Help?



Online: www.ConnectedEssentials.co.uk



email: support@connectedessentials.co.uk



1st Edition. February 2014