
Please read the users‘ manual before use it.


Brief Introduction

i.onik® PB-3000 is a high capacity backup power pack which is especially designed for mobiles, tablets and other digital products. It comes with built-in battery, charging adaptors with multi-tips, built-in charging cable and fashionable power indicators. It is convenient to carry and easy to use.
i.onik® PB-3000 could provide extra power whenever your devices need and wherever you may be. This is i.onik® PB-3000, your best friend.




1) 3.5DC USB cable
2) Power switch
3) Main body
4) DC interface
5) Power indicator (each light stands for 25%)
6) Charging adaptors

1. Please charge your device with i.onik® PB-3000 as follows:
1) Connect your device with i.onik® PB 3000, then keep pressing switch button for 1 second till LED lights on (*Notice:* the LED display will keep on for 5 sec, then off automatically to save power). Keep pressing switch button for 1 sec to turn it off.
2) It will be off automatically if your device is charged fully or no devices connected with i.onik® PB-3000.




2. Charge your device and i.onik® PB-3000 by AC power source at the same time
Connect i.onik® PB-3000 with your device, and plug into power source, it charges your device and i.onik® PB-3000 at the same time. Power indicators come on when charging and all lights on when fully charged. Power gives priority to your device when i.onik® PB-3000 and your device are getting charged together.



Notice
1) Please disconnect charging cable after fully charged otherwise it might reduce battery’s life.
2) Please don’t put it into or near fire to avoid explosion.

3) Directly pulling out the USB cable is prohibited for cable might get broken. Please hold the product and get out plug of cable by fingernail.
4) Please don‘t hung your device vertically for your device might get broken, which should be placed horizontally instead.

3. How to check power level of i.onik® PB-3000 built-in battery
Press the switch button to turn on LED power indicators, each light that comes on accounts for 25% power, four lights indicate 100% Power.
To save power, LED screen turns off automatically within 5 sec.



Features:
- AC Plug (Europe).
- Standard USB output interface, compatible with all USB cables.
- Built-in charging cable
- External connector with Multi-tips.
- Built-in high capacity 3000 mAh polymer lithium battery.
- Fashionable design with LED display.
- Easy to carry and use.
- High charging efficiency make it 92% at least.

Specifications

Battery Element:	Li-polymer ion battery
Battery Capacity:	3.7 V/3000 mAh
Input:	AC 100-240 V 50/60 Hz 0.15 A
Output:	DC 5 V 1 A (max)
Dimensions:	65x105x18.5 mm
Weight:	Approx. 128 g
Charging Time:	About 3.5 h
Charging cable	DC3.5 cable
Standby Time:	420 h
Talk Time:	15 h
Wi-Fi:	11 h
Audio Play:	55 h
Video Play:	14 h

Accessories



Europe



Connector:
iPhone/Micro/Mini



Connector:
iPhone

FAQs

While charging i.onik® PB-3000, indicator LED doesn‘t turn on.	Please make sure if the charging cable or power source is connected correctly.
Power indicator does not come on after pressing power switch.	Please charge the built-in battery.
i.onik® PB-3000 can not charge your devices.	Please check whether all parts are connected well.

Care and Maintenance

Your device is a product of superior design and craftsmanship and should be treated with care. The following suggestions will help you protect your warranty

1) Keep the device dry. Rain, humidity and all types of liquids or moisture which contain minerals that will corrode electronic circuits. If the device does get wet, turn it completely dry.
2) Do not use or store the device in dust and wet conditions that would destroy its moving parts and electronic components.
3) Do not store the device in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt.
4) Do not store the device in cold areas. When the device temperature rises to its normal temperature, moisture can form inside and damage the circuit board.

5) Do not drop, knock or shake the device. Rough handling can break its sophisticated structure.
6) Do not use harsh chemicals, cleaning solvents or strong detergents to clean the equipment.
7) Do not paint the device. Paint will block the moving parts, thus will affect the normal operation.
8) If the product does not work, take it to your nearest authorized service facility for service.

Service: +49 (0) 180-5000251*
Email: service@i-onik.de

* € 0,14/min. For calls from mobile phones, the price may vary.

Chips and More GmbH
Gewerbestr. 7 | 79112 Freiburg | Germany
www.i-onik.de

i.onik® mobile

PB-3000 Powerbank


User Manual



Please read the users‘ manual before use it.


Brief Introduction

i.onik® PB-5000 is a high capacity backup power pack which is especially designed for mobiles, tablets and other digital products. With built-in iPod 30 pin and micro charging cable, it’s able to charge two mobiles simultaneously. Fashionable LED power screen shows power level anytime. i.onik® PB-5000 could provide extra power whenever your devices need and wherever you may be. This is i.onik® PB-5000, your best charging assistant, your best friend.




1) Main
2) iPod output
3) Power switch
4) Power indicator
5) Micro output
6) Micro input

Cable disassembling
Please pull out iPhone and micro connector by fingernail.




Instruction

1. How to charge built-in battery of i.onik® PB-5000
Connect micro USB cable with i.onik® PB-5000 and PC (or USB charger), i.onik® PB-5000 gets charged automatically. Power indicators come on when charging and all lights are flashing when fully charged.




Notice:
1) Please use provided micro USB cable or branded cable to charge i.onik® PB-5000.
2) Please disconnect charging cable after fully charged otherwise it might reduce battery’s life.
3) Do not use any defective chargers.
4) Do not put this product into or near fire to avoid explosion.
5) Please hold the product and get out plug of cable by fingernail, please do not pull cable directly.

2. How to check power level of built-in battery
Gently press power switch to turn on power indicator‘s screen, each light accounts for 25% power, 4 lights come on stands for full power. To save power, indicators screen turns off automatically within 5 sec.



3. How to use i.onik® PB-5000 to charge your devices (refer to picture on the right)
Connect your devices to built-in iPod 30 pin or micro cable (available to charge two devices together), keep pressing power switch for 1 sec to turn it on (the same way to turn it off). LED indicator comes on when power switch was pressed and turn off within 5 sec to save power. To avoid over-charge, i.onik® PB-5000 turns off automatically when your devices have been fully charged.



Notice:
1) Not used for a long time or use for first time, you are suggested to use provided cable.
2) Keep i.onik® PB-5000 at a place where air flows while charging.

Product features
- Standard USB input, compatible for all USB chargers.
- Available to charge two devices simultaneously.
- Built-in battery with 5000 mAh high capacity.
- Fashionable LED power screen.
- Multi-functional design makes i.onik® PB-5000 easy to carry and convenient to use.
- High charging efficiency make it 92% at least.

Specifications

Battery type:	Li-thium
Battery Capacity:	3.7 V/5000 mAh
Input:	DC 5 V/1 A
Output:	iPhone: 5 V/1 A Micro: 5 V/1 A
Dimension:	83x50x21 mm
Weight:	Approx 130 g
Charging time:	Approx 6 h (5 V/1 A charger)
Standby Time:	up to 780 h
Talk Time:	3G: 18 h 2G: 36 h
Internet Surfing:	3G: 15 h WLAN: 26 h
Audio Play:	up to 100 h
Video Play:	up to 26 h

Accessories

Optional accessories



QAC Charger

Standard accessories



Micro USB cable

FAQs

Power Indicators don't flash when charging i.onik® PB-5000.	Please make sure if USB charging cable and power source are connected correctly.
i.onik® PB-5000 does not charge devices after connected.	Please make sure if USB cable is connected correctly.
Power Indicators don't flash after being pressed.	i.onik® PB-5000 has probably run out of power, please charge it in time.
It takes too long to fully charge i.onik® PB-5000.	Please use provided or branded 5 V/1 A charger.

Care and Maintenance

Your device is a product of superior design and craftsmanship and should be treated with care. The following suggestions will help you protect your warranty.

1) Keep the device dry. Rain, humidity and all types of liquids or moisture which contain minerals that will corrode electronic circuits. If the device does get wet, turn it completely dry.
2) Do not use or store the device in dust and wet conditions that would destroy its moving parts and electronic components.
3) Do not store the device in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt.
4) Do not store the device in cold areas. When the device temperature rises to its normal temperature, moisture can form inside and damage the circuit board.

5) Do not drop, knock or shake the device. Rough handling can break its sophisticated structure.
6) Do not use harsh chemicals, cleaning solvents or strong detergents to clean the equipment.
7) Do not paint the device. Paint will block the moving parts, thus will affect the normal operation.
8) If the product does not work, take it to your nearest authorized service facility for service.

Service: +49 (0) 180-5000251*
Email: service@i-onik.de

* € 0,14/min. For calls from mobile phones, the price may vary.

Chips and More GmbH
Gewerbestr. 7 | 79112 Freiburg | Germany
www.i-onik.de

i.onik® mobile

PB-5000 Powerbank

User Manual

