

2.7 m / 9 ft Pre-Lit Garland ITM. / ART. 166120 & 30534

**IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.
IMPORTANT SAFETY INSTRUCTIONS
FOR INDOOR USE ONLY**

Size: 210 x 145mm

USER MANUAL FOR LIGHTING CHAIN

Manufacturer: Nixan(Heyuan) Co., Ltd

**Address: Xiantang Industrial Zone, Dongyuan County, Heyuan City
Guangdong, 517000, P.R. China**

Type: NXIL90LC

Rating: 30 V DC, 3.51W, class III, IP20

Bulb specification: replacement: 2.8-3.6V/0.02A



CAUTIONS:

1. Do not connect to the power supply while it is in the packing unless the packing has been adapted for display purposes.
2. For indoor use only.
3. Ensure all lampholders are fitted with a lamp.
4. Do not remove or insert lamps while the chain is connected to the supply.
5. For series-connected lamps, replace failed lamps immediately by lamps of same rated voltage and wattage to prevent overheating.
6. The replacement lamps must be of the same type as delivered or of type specified by the manufacturer.
7. The external flexible cable of cord of this lighting chain cannot be replaced, if the cord is damaged, the product shall be destroyed.
8. To avoid the overheating by an increased current, do not mount or place near gas or electric heaters, fireplaces, candles or other similar sources of heat.
9. Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
10. Unplug the product when leaving the house, when retiring for the night, or if left unattended.
11. This is an electric product-not a toy! To avoid risk of fire, burns, personal injury and electric shock it should not be played with or placed where small children can reach it.
12. Do not use this product for other than its intended use.
13. Do not hang ornaments or other objects from cord, wire or light string.
14. Do not close doors or windows on the product or extension cords as this may damage the wire insulation.
15. Do not cover this product with cloth, paper or any materials not part of the product when in use.
16. When the product is placed on a live tree, the tree should be well maintained and fresh. Do not place on live trees in which the needles are brown or break off easily. Keep the tree holder filled with water.
17. If the product is placed on a tree, the tree should be secured and stable.
18. Before using or reusing, inspect product carefully. Discard any products that have cut, damaged, or frayed wire insulation of cords, cracks in the lamps or enclosures, loose connections, or exposed copper wire.
19. When storing the product, carefully remove the product from whenever it is placed, including Trees, branches, or bushes, to avoid any undue strain or stress on the product conductors, connection and wires.