# **Usage Manual**

### Bluetooth Audio Transmitter

### Introduction

This Bluetooth transmitter is specially used for transmitting audio from your music source (MP3 player, mobile phone, TV etc) to Bluetooth-enabled devices (such as speakers, headsets, or a Bluetooth receiver). Bluetooth V2.1+EDR allows for to 10 meters(33 feet) of distance, and supports A2DP and AVRCP profiles. Up to 8 devices can be paired and stored, with automatic connection to the last used device when powered on.



## **Operating Guidance**

### Charging

- 1.Plug the travel charger into an AC outlet, connect the USB charging cable to the charger.
- 2.Plug the mini USB connector into the power interface on BT00602.
- 3. While it is charging, the red LED indicator light will come on. When BT00602 is charged, the red indicator light will go out.
- 4. While charging the BT00602, please do not use it.

### Power on

When in the powered-off state, press the MFB button for 3 seconds until the blue LED flashes. If the BT00602 hasn't been paired with a Bluetooth device before, it will go into pairing mode with red and blue LEDs flashing alternately for up to 2 minutes.

### Power down

To turn the Bluetooth transmitter off, press the MFB button for 3 seconds. A red LED will flash three times quickly, then goes out. The transmitter is no ready to be charged.

# Pairing with Bluetooth devices

1. Power on the transmitter by pressing the MFB button for 5 seconds until red and blue LEDs flash alternately. If a device is not paired within 2 minutes, the transmitter will go into standby mode.

Note. The BT00602 can pair with Bluetooth devices using passkeys of 0000, 1111, 8888 or 1234.

2.Switch on your Bluetooth device and put it in discovery mode. Choose the BT00602 once it appears. Enter the passkey (see Note above) and the devices should be paired within 1 minute. Once paired, a blue LED will flash once every 10 seconds. If pairing isn't successful within 1 minute, please repeat the steps above.

Note. A Bluetooth device that has already been paired to the BT00602 only needs to be powered on .Connection will occur automatically.

# Delete the paired device list

With the transmitter powered on, double click the MFB button (the paired device list contains information for the Bluetooth devices that have been paired with BT00602).

After this list is deleted, it will be necessary to pair devices according to the steps above. The transmitter will go into pairing mode once turned on.

### LED status

- 1. Pairing mode: red and blue light are flashing alternately.
- 2.Standby mode or disconnected: blue light flash twice quickly each 5 seconds.

# **Usage Manual**

- 3.Device connected and paired: blue light flash once each 10 seconds.
- 4.Low battery status: red light keep on flashing.

Note. When the BT00602 is pairing, and the blue LED flashes once, that means device pairing is successful. If you see the blue light flash twice quickly, that means the pairing is not successful, and pairing will have to be tired again.

### **Specifications**

Bluetooth Frequency	2.4G ~ 2.48G Hz ISM band
Bluetooth Version	V2.1+EDR, class II, CSR chip
Support profiles	A2DP (audio streaming), AVRCP (device remote control)
Distance	10 Meters
Light Indicator	2 Color LED (Red/Blue)
Interface	3.5mm
Battery capacity	160 mAh
Data encryption	128 bits encrypted
Frequency Range	2.402 GHz-2.480 GHz
Listen/stand by time	Up to 8 hours/Up to 160 hours

## **Battery tips**

- \*Fully charge the battery for at least 4 hours prior to first use.
- \*If the BT00602 has not been used for more than 21 days, please charge for at least 4 hours.
- \*When the LED indicator light flashes red during using or while in standby mode, the battery is low and you needs to be recharged as soon as possible.
- \*Please only use the original charger to charge BT00602.

### Attention

- \*Please read this user manual carefully and use BT00602 correctly at all times by following the instructions.
- \*Pls keep the BT00602 away from children as it's size could present a choking hazard...
- \*Clean the Bluetooth transmitter using a soft and dry static-free cleaning cloth.
- \*Please do not use cleaning liquids, solvents, or sprays to clean it.
- \*Do not clean it while it is charging.
- \*Do not dissemble it. If you encounter any problems, contact your retailer immediately.
- \*Recharge it once per month, even if it hasn't been used, to maintain optimum battery life.
- \*Use of a charger other than the manufacturer's originally supplied charger may cause the unit to malfunction or fail. In addition, product damage with non-manufacturer chargers may result in the cancellation of the product warranty.

# **Troubleshooting**

If you can not connect Bluetooth devices according to the above operation, please try these steps:

- 1. Ensure the BT00602 is charged and powered on.
- 2. Ensure the connecting device has Bluetooth reception, supports A2DP, and is on. Please refer to the manual of the Bluetooth reception device for reference.
- 3. Make sure the distance between the BT00602 and Bluetooth device is within 10 meters.

## Storage

- \*Do not disassemble the unit for any reason. This may damage the unit accidentally and void the manufacturer's warranty.
- \*Please store the unit away from dust, heat and areas where it might accidentally fall or other damage may occur.