RF dimmer user manual

This product uses the wireless remote control, can realize the brightness adjustment, on/off, with power and memory function, without frequent set. This product is applicable to various high-pressure LED lamp (constant current) to adjust the brightness control.

I. The related parameters:

Input/output voltage	110V、220V	remote distance	MAX: 50 米
Maximum output current	3A	largest single load	600W

II. Instructions:

- 1. Button A: Increase brightness
- 2. Button B: Decrease brightness
- 3. Button C: Switch off consumer
- 4. According to the wiring label products, Connect the load you want to control to the power terminal (OUTPUT). Connect the power supply source to the terminal (AC).

Ⅲ. The picture



Attention:

- 1. Use in the rated voltage
- 2. Use in rated power
- 3. Do not make a short circuit at the output of the controller.
- 4. The use of this product is hazardous voltage, do not open the shell, touch the conductive body, to prevent electric shock
- 5. Install the lamp strip connecting pin, observe the line between with and without short circuit phenomenon, such as a short circuit is damaged or faulty operation damage the product, not in the warranty scope.