

Product Manual ID-650VDN



Specification

Model	ID-650VDN		
Pick up Element	1/3"SONY		
Effective Picture Elements (HxV)	PAL:752(H)+582(V) NTSC:788(H)+494(V)		
Horizontal Resolution	650TV Line		
Minimum Illumina- tion	0.001Lux		
	0Lux (with IR LED ON)		
S/N Ratio	More than 48dB		
Scanning System	2:1 interface		
Synchronous System	Internal, Negative sync.		
Auto Electronic Shutter	NTSC: 1/60s~1/100,000s, PAL: 1/50s~1/100,000s		
Gama Characteristic	0.45		
IR Distance	30 Meters (with ¢ 5X24PCS Infrared LED)		
IR Status	Under 10Lux by CDS		
IR Power On	CDS AUTO Control		
Video Output	1Vpp, 75Ω		
Auto Gain Control	Auto		
Power/Current	DC12V/500mA		
Lens	3.6mm Lens(6mm/8mm optional)		
Dimension (mm)	¢ 131 x 93(H)		
Weight (g)	800g		
Storage Tempera- ture	-30~+60		
Operating Tempera- ture	-10~+45		

No	Name	Manual	Number
1.	Vandal proof IR Dome Color Camera		1
2.	User Guide	Dome Series	1



USER MANUAL

6923 Narcoossee Rd Orlando, FL 32822 www.genesiscctv.com

Dome Series Color Camera

IR Dome Color Camera



Notes: Before providing power for the camera, please read this User Guide in detail!

Do not attempt to disassemble the camera. If the camera can not work, please contact Genesis CCTV for technical support.

BRIEF OF PRODUCT


- •1/3" Sony Color Super HAD CCD
- High Resolution :420/540/600/680TVLines
- Simple Installation Adjustment
- Cable Managed
- 22pcs IR Led
- Elegant design
- Intelligent LED Power
- 2.8mm 12mm Lens
- •IR Distance 25m
- Day/night function w/ Infrared
- Power supply: DC12V

Notes :

The power supply must through safe attestation. Its output voltage, current, voltage polarity and operating temperature must match the camera's requirement.

When using the camera in the thunderbolt condition, please note to mount Anti-thunder device or put off the power supply plug and cable. In order to capture high quality pictures, the power supply's cable and

■ CONNECTING



■ TROUBLE AND SOLUTION

1. No Picture after providing power

- . May be the power supply voltage abnormity, please check the power supply voltage and pole whether exactitude.
- . Please check all the connecting cable and monitors whether be connected correctly or not.

2. The picture level direction have flowing interference ripples

- . May be caused by the power supply AC ripples, it need filter the wave of the power supply.
- . Check the monitor and peripheral equipments used.

3. The picture background color changes continuously

- . The fluorescent lamp's electromagnetic field cause color roll. This is proper phenomenon of the cameras.
- . Reduce the fluorescent lamp numbers or increase the distance between the camera and the fluorescent lamps can improve it.
- . Use power supply external sync. camera can solve it.

4. The picture smear too mass

- . The power supply's voltage unstable.
- . Connecting cables not connect correctly or have high impedance.

INTRODUCTION

Congratulations on your purchase of this product. This User Guide is for the ID-650VDN. We adopt the latest SONY/SHARP sensors and drivers. The most attractive characteristics are small and easily hidden, in the elevator and corridor. In addition, it owns the characteristics of high definition and stability, strong antijamming, rich and real color. Setup and use of this model is convenient too.Making it a great faddition to your CCTV system.

Please read this instruction manual carefully to ensure proper use of the product.



To prevent fire or shock hazard. Do not expose the unit to rain or moisture



The symbol is intended to alert the user to the presence of important operating and maintenance (servicing)
Instructions in the literature accompanying the appliance.



The symbol is intended to alert the user to the presence of uninsulated 'dangerous voltage' within the product's enclosure that may be of sufficient Magnitude to constitute a risk of electric shock to persons.



SHOCK

CAUTION: TO REDUCE THE RISK OF ELECTRIC

DO NOT REMOVE COVER OR BACK NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING

CAUTION: TO PREVENT ELECTRIC SHOCKS AND RISK OF FIRE HAZARDS, DO NOT USE OTHER THAN SPECIFIED POWER SOURCE.



Note

Please note the camera's operating temperature and its using environment requirement. Avoid using the camera at too high or too low temperatures. The operating temperature is -30-+60°C. (Recommendatory operating temperature is -10-+45°C.)

Never make the camera face the sun or bright object. Otherwise, it will damage the CCD.

Do not mount the camera near by the radiator or heater.