





NovoConnect™ B360

Wireless Presentation & Collaboration System



User Manual Version 0.96



Table of Contents

TABLE OF CONTENTS	2
1. GETTING STARTED	5
1.1 Setting up your NovoConnect B360 device	5
1.1.1 Package Contents	5
1.2 Connecting your NovoConnect B360 Device	5
1.2 Downloading and Installing Software	7
2. WIFI SETUP	9
2.1 Hotspot Mode	9
2.2 Client Mode	10
2.2 Client Mode	
	11
3. MAKING A PRESENTATION	11
3. MAKING A PRESENTATION	11
3. MAKING A PRESENTATION	11
3. MAKING A PRESENTATION 3.1 From Windows and Mac PC	111112
3. MAKING A PRESENTATION 3.1 From Windows and Mac PC	11111213



3.1.3.4 Annotation
3.1.3.5 Reset
3.2 With iOS Tablet
3.2.1 Step 1: Configuration Software Configuration
3.2.2 Step 2: Connect to your B360 device
3.2.3 Step 3: Presentation Management
3.2.3.1 Role Assignment
3.2.3.2 Role Change, Screen Preview, and 4-way Split Screen
3.2.3.3 Annotation
3.2.3.4 Pause, Resume, and Disconnect
3.2.3.5 Reset
3.3 With Android Tablet
3.3.1 Step 1: Presentation Software Configuration
3.3.2 Step 2: Connect to your B360 device
3.3.3 Step 3: Presentation Management
3.3.3.1 Role Assignment
3.3.3.2 Role Change, Screen Preview, and 4-way Split Screen
3.3.3.3 Pause, Resume, and Disconnect
3.3.3.4 Reset
4. REMOTE VIEWER CONFIGURATION43







1. Getting Started

1.1 Setting up your NovoConnect B360 device

1.1.1 Package Contents



1.2 Connecting your NovoConnect B360 Device




Steps to connect your NovoConnect B360 Device:

1. Video/Audio connection: Connect the Micro HDMI port to the TV/projector's HDMI input port using the Micro-HDMI-to-HDMI cable (item (b) in "Package Contents").



2. Power: Connect the Micro-USB port to the power source using the Micro-USB-to-USB power cable and the USB power adapter (items (c) and (d) in "Package Contents").

The NovoConnect B360 device will power up with the below display after properly finished step 1 and 2 above. The display is generated by the presentation software residing in the B360 device, named *remote viewer*. This display is referred to as the "NovoConnect home screen" or just the "home screen" in the document.



The lower right corner of the home screen shows the name of the presentation group, IP address, four-digit PIN, WiFi SSID, and the WiFi Mode Setting. The value of the IP address, the four-digit PIN, and the SSID are machine generated values, and therefore the values on the screen may be different from the numbers pictured above.

The lower left corner of the home screen shows the URL where you can download the presentation software required to make a wireless presentation on Windows PC, Mac PC, iOS tablet, and Android tablet, respectively.

You can also find the presentation software in Delta official website: http://www.deltaww.com/EduSolution



1.2 Downloading and Installing Software

The NovoConnect B360 device supports up to 64 concurrent participants across a mix of PC and Tablet devices. Each participant device will set up a connection with the presentation application, the *remote viewer*, residing on the B360 for it to make a presentation. You'll need the below listed presentation software:

On Windows PC - NovoConnect Desktop Streamer

On Mac PC - NovoConnect Desktop Streamer

On iOS tablet – *NovoPresenter*

On Android tablet - NovoPresenter

Note: Throughout the document, these four presentation application software and the B360 software *Remote Viewer* (no need to download) are highlighted in *Italics* font.

Windows PC and Mac PC

Downloading the Presentation Software

Launch the web browser of your choice and enter the URL displayed on the NovoConnect home screen. In the example display screen shown above, you would enter http://192.168.43.1:8080 into the address line of the browser. You will then see the following screen displayed on your browser.





Select the operating system type in the drop down menu

Select your Operaing System • and then click



to download the NovoConnect Desktop Streamer software to your PC.

Installing the Application Software

Run either <code>Desktop_Streamer_Setup_Windows.exe</code> (for MS Windows based computers) or <code>Desktop_Streamer_Setup_Mac.exe</code> (for Macintosh computers) by double clicking the downloaded file on your computer. Follow installation instructions on the PC to complete the installation. Allow all security permissions for <code>NovoConnect Desktop Streamer</code> and all of its subcomponents.

On Tablet Devices

On iOS tablets, the iOS version of the *NovoPresenter* is required. You can download and install it from the Apple App Store.

On Android tablets, the Android version of the *NovoPresenter* is required. You can download and install it from the Google Playstore.

Once you have downloaded and installed the presentation software, you are ready to make a wireless presentation from your tablet device.



2. WiFi Setup

Depending on where your presentation content located, typically, you may select

- A) Client Mode for content residing in a networked environment or the Internet cloud
- B) Hotspot mode for content residing in your PC or Tablet
- C) Either for content residing in your microSD card (up to 32G)

The NovoConnect device defaults to start up in WiFi Hotspot mode. The quickest way to make a wireless presentation without setting up a WiFi AP is through Hotspot mode, you may skip to next chapter for steps to making a presentation.

If you would like to make your presentation in a WiFi AP networked environment, please refer to the "Client Mode" section in this chapter.

2.1 Hotspot Mode

Right out of the box, NovoConnect's WiFi is set to function as a WiFi Hotspot and will stay in this configuration until you alter it. The default SSID for the WiFi Hotspot is "NVC_XXXXX", where "XXXXXX" is a machine generated string of characters and numbers. A mouse is required for the following steps.

If you alter your settings and choose to revert to Hotspot mode, on the NovoConnect home screen, select **WiFi-> Hotspot Mode->Apply**.

For the Windows PC presenter, click the network icon on task bar from Desktop. Select the SSID of the NovoConnect B360 device shown on the home screen, in the above example - NVC XYZAB, and click **Connect**.

For the MAC presenter, click the network icon on task bar from Desktop. Select the NovoConnect SSID and click **Join**. Ignore any security warnings.

For the tablet presenter, enable WiFi and go to the WiFi AP list. Select the NVC_XYZAB SSID. Ignore any security warnings.



<u>Note</u>: In Hotspot mode operation, all participating presentation devices must be connected to the same WiFi HotSpot.

2.2 Client Mode

In this mode, the NovoConnect device functions as a WiFi client and a WiFi AP router is needed for network connectivity. A mouse is required for the following steps.

On the home screen of the NovoConnect, sequentially select **WiFi->Normal Mode-> Config->Wireless & Networks-> Wi-Fi (ON)**, and select the desired WiFi AP SSID. Enter password if prompted.

On the Windows PC, click the network icon . Select the desired WiFi AP SSID. Enter password if prompted.

On the Mac, click the network icon . Select the desired WiFi AP SSID and click **Join**. Enter password if prompted.

On the tablet, enable WiFi and go to the WiFi AP list. Select the desired WiFi AP SSID. Enter password if prompted.



3. Making a Presentation

The NovoConnect B360 device supports up to 64 concurrent participants across a mix of PC and Tablet devices. Each participant device will connect to the B360 device and forming a presentation group of up to 64 devices in total. The collaboration and coordination between the 64 participants group are achieved by: 1) participant list with role indicated, 2) specific capability sets defined for each role, and 3) tools available for concurrent operation of the participants.

To make a presentation, you must follow the below 3 steps:

Step 1: Configure the presentation software

Step 2: Connect to your B360 device

Step 3: Manage the presentation

3.1 From Windows and Mac PC

Launch Presentation Application


Launch the *NovoConnect Desktop Streamer* Application by double clicking the licon. The *NovoConnect Desktop Streamer* will be launched (pictured in the image below).



3.1.1 Step 1: Presentation Software Configuration

Click the connection tab and access the configuration options below.






3.1.2 Step 2: Connect to your B360 device

Once you are done configuring your Desktop Streamer, click connect button to connect to your NovoConnect B360 device.

Option	Option	Description	
--------	--------	-------------	--





Please note that your PC screen resolutions may be changed to match projector resolution, and when disconnect from the NovoConnect device, the original screen resolution will be restored. The resolution of each PC in the same group will be changed as they start and join the presentation group, and restored when disconnect from the group.

3.1.3 Step 3: Presentation Management

3.1.3.1 Role Assignment

There are three roles in a presentation group, namely the host, the presenter, and the participant.


The first participant of the presentation is assigned the host role. Subsequent joiners are assigned the participant role.

The host is defaulted to assume the presenter role until he handed over the presenter role to other participant.

To show all current participants who have joined the presentation group, please click the tab.







3.1.3.2 Role Change, Screen Preview, and 4-way Split Screen








Copyright © 2014 DELTA Electronics, Inc. All rights reserved.






Screen Preview:

The diagram shows the screen of John's iPad viewing from the host.




To manage a 4-way split screen presentation:

The host clicks 📒 tab to show participant list.



4-way split screen presentation:

- 1. Move curser over to highlight participant Oliver.
- 2. Click on a numbered box to assign a presenter's on-screen display to the corresponding presentation screen #1-#4. Click the center box to assign a presenter's on-screen display to full screen.
- 3. You should observe Oliver is being requested to be a presenter on Oliver's Desktop Streamer.



4-way split screen presentation:


4. Oliver to decide if accepting the presenter role.

After Oliver clicks yes to accept being the presenter, Oliver's screen will be presented on one of the four quarters of the 4-way split screen.

Copyright © 2014 DELTA Electronics, Inc. All rights reserved.



3.1.3.3 Pause, Resume, and Disconnect




3.1.3.4 Annotation

Occasionally, you might want to write, highlight, mark, video recording, or cut and paste portion your presentation material directly on the desktop screen. A simple to use tool, also provided by Delta for free, we recommend is the NovoScreenote. You can download the NovoScreenote from http://www.deltaww.com/EduSolution. It is available for use on both Windows PC and Mac PC.



3.1.3.5 Reset

Occasionally, you might encounter network or computer difficulty, the presentation group hosted by the B360 device might not function properly. In the situation, one of the options is to reset the presentation group.






3.2 With iOS Tablet

The *NovoPresenter* (pictured in the image below) apps enables iOS tablet device to connect to the B360 device to join the presentation group.

Launch Presentation Application


Launch the NovoPresenter application by selecting the NovoPresenter app on your iOS tablet. A sample screen view is provided in the image below.




3.2.1 Step 1: Configuration Software Configuration

To configure the presentation software, you first select the NovoPresenter Apps by tapping on the apps on your iPad touch screen. A sample screen is provided below.












3.2.2 Step 2: Connect to your B360 device

Once you are done configuring your NovoPresenter, pictured in below diagram, you are ready to establish a presentation session with the B360 box.










3.2.3 Step 3: Presentation Management

Once you are done joining a presentation group, you are ready to make a presentation. A sample screen view is provided below.






3.2.3.1 Role Assignment

There are three roles in a presentation group, namely the host, the presenter, and the participant.


The first participant start the presentation session with a specific B360 is assigned the host role. Subsequent joiners are assigned the participant role.

The host is defaulted to assume the presenter role until the host assigned the presenter role to other participant.

To show all current participants who have joined the presentation group with the B360 device, please select the tab.











3.2.3.2 Role Change, Screen Preview, and 4-way Split Screen









To perform Role Change:

When a participant is asked to be a host, a dialog box will appear on the participant's screen.

The participant has to select "Yes" or "No" to acknowledge in 20 seconds.

To perform Screen Preview:


The host clicks tab to show participant list.

The icon indicates that a participant is denying screen preview.

The icon indicates that a participant is allowing screen preview.

Perform screen preview by selecting target participant's entry in participant list.








3.2.3.3 Annotation


The NovoPresenter provides an on screen annotation tool for presenter to annotate directly on

presentation material. The annotation tool in the below picture.












Undo.




3.2.3.4 Pause, Resume, and Disconnect





3.2.3.5 Reset

Occasionally, you might encounter network or computer difficulty, the presentation session between the participants and the B360 device might not function properly. In the situation, one of the options is to reset the presentation session.






3.3 With Android Tablet

Launch Presentation Application


Launch the NovoPresenter application by selecting the NovoPresenter app on your iOS tablet. A wireless presentation and collaboration session can be started, managed, and controlled via functions provided by the *NovoPresenter* (pictured in the image below).




3.3.1 Step 1: Presentation Software Configuration

When you first select the NovoPresenter Apps, you should see the below display.











3.3.2 Step 2: Connect to your B360 device

Once you are done configuring your NovoPresenter, pictured in below diagram, you are ready to start a new presentation or join an existing presentation session.








3.3.3 Step 3: Presentation Management

Once you are done starting or joining a presentation session, you would see a list of participants as pictured below.





3.3.3.1 Role Assignment

There are three roles in each presentation and collaboration session, namely the host, the presenter, and the participant.


The first participant join the presentation session is assigned the host role. Subsequent joiners are assigned the participant role.

The host is defaulted to assume the presenter role until the host assigns the presenter role to other participant.

To show all current participants who have joined the presentation session, please select the



tab.











3.3.3.2 Role Change, Screen Preview, and 4-way Split Screen









To perform Role Change:

When a participant is asked to be a host, a dialog box will appear on the participant's screen.

The participant has to select "Yes" or "No" to acknowledge in 20 seconds.

To perform Screen Preview:


The host clicks tab to show participant list.

The icon indicates that a participant is denying screen preview.

The icon indicates that a participant is allowing screen preview.

Perform screen preview by selecting target participant's entry in participant list.





YES

Do you want to be presenter?


NO

four possible presenters, you would observe John's screen is presented on one of the four

quarters of the 4-way split screen.




3.3.3.3 Pause, Resume, and Disconnect





3.3.3.4 Reset

Occasionally, you might encounter network or computer difficulty, the presentation session between the participants and the B360 device might not function properly. In the situation, one of the options is to reset the presentation session.





4. Remote Viewer Configuration

The *Remote Viewer* is the application software on the NovoConnect B360 device that hosts the presentation group. The *Remote Viewer* manages and controls all presentation sessions between the presentation software of the participant device and the B360. In addition to the presentation management, mentioned in previous chapters, the remote reviewer supports the configuration of the below attributes.

- WiFi
- Display
- Setting
- Reset
- Meeting Room

Please go to the NovoConnect home screen to locate the attributes. You will need a USB based mouse to perform the setting.







	Networks-> Wi-Fi (ON)
Display	To configure the HDMI output quality. Select one of the below values: Auto automatically determines the optimal resolution 1024x768, 1280x800, 720p (1280x720), 1080p (1920x1080)
Settings	To access and change Android system settings.
Reset	To reset the NovoConnect B360 device: Press and hold on the Reset tab 2 seconds. The B360 device will restart.
Presentation Group Name (Defaulted to Meeting Room)	To modify the name of the presentation group shown on the home screen: Click on the name and key in new name on the popup up window with the popup soft keyboard.