









CAUTION: DO NOT REMOVE COVER, NO USER- SERVICEABLE PARTS INSIDE.

Avoid Liquids - Care should be taken so that objects are not placed on, nor liquids spilled on or inside the device. Do not expose this product to water or moisture.

Servicing - The user should not attempt to service the device beyond those means described in these operating instructions. All other servicing should be referred to qualified service personnel. Heat - The device should be situated away from sources of high heat such as radiators or stoves.

Understanding the WhereWolf Locator System

The WhereWolf Locator System consists of unique Locator devices that allow you to easily locate the things with the push of a button that are often misplaced — such as your wallet, keys, purse, remote, tools, etc... These devices create virtual leashes between thems elves and to any item you attach them to. In this way you can find any of the items in the system from any of the other items in the system.

This package includes two WhereWolf Locators that can be used to start a new system or add to an existing one. Use these locators to create a virtual leash between your wallet/purse and your keys — any 2 items you don't want to lose. By purchasing and adding more WhereWolf Locator devices you can add up to 36 total devices to a WhereWolf Locator System.

How does the device locate the intended item?

First, you designate a Device ID code to each Locator that consists of a LETTER(a-f) and a NUMBER(1-6). You may only assign a Locator with the following letters from A to F and numbers from 1 to 6.

a1	a2	a3	a4	a5	_ <mark>a6</mark>
b1	_b2	_b3	_b4	_b5	_ b 6
Cl	<u>c</u> 2	G	_C4	_C5	
d1	_d2	_d3	_d4	_d5	_d6
e1	_e2	_e3	_e4	_e5	_e6
<i>f</i> 1	_ <u>f</u> 2	_f3		_ f 5	_ f 6

The following is a list of the available Device ID codes

Each Locator is capable of "calling" any of these 36 Identification Codes by simply selecting the code any other device, then only the device with the appropriate Identification Codes will respond with an audible alarm.

Follow the instructions on this card to set up your WhereWolf Locators and begin using your system right away.

Setting Up the WhereWolf Locator System for the First Time

Follow the procedures below for each of your Locators

1. Insert Batteries into the Locator

On the first use of your WhereWolf Locator pull the battery tabs or insert the batteries. The unit will automatically go into the set up mode and all 6 LED lights on the unit will blink. Alternately, you can manually enter the set up mode by pressing and holding 💋 and 💋 for 3 seconds until you hear a "peep" (◀).

2. Assign the Locator an Identification Code of your own choosing

Set the first Device ID Letter using 😕 ; press multiple times until the desired LETTER appears above the LED Lights. (example- press 3 times for letter C and the LED light will appear in the C position).

Press ⋟ to confirm.

Next, set the Device ID Number using 📿 ; press multiple times until the desired NUMBER appears on the LED Lights.

Press 🦻 and the locator will confirm your setting and it is now ready to be used.

Remember to record the Identification Code for each item since you need this code to call up that item. We have provided a card to help you keep track of your Identification Codes.

3. Attach each Locator Device to your personal belongings.

The WhereWolf Locators attach easily to your key chain or slip discretely into your wallet or purse. It's flexible design lets you to choose where the Locator Devices go. Simply attach or place the Locator with any item you do not want to loose and that item becomes instantly connected to the system.

4. Use Any Locator Device to find others within the system.

Pick up any Locator Device from within the WhereWolf Locator System.

Press to select Letter of the device you are looking for with 💋 .

Press to select the number of the device you are looking for with 🗸 .

Press 🕨 to locate the item.

WhereWolf Products

6081 Meridian Avenue, Ste. 70-308, San Jose, CA 95120 support@wherewolfproducts.com wherewolfproducts.com Distributed by:

Copyright ©2006 SuMaWah LLC. All rights reserved. Patent Pending The WhereWolf name and logo are registered trademarks of SuMaWah LLC

	1. ID Letter Setting 2. ID Number 3. Go / Find					
Function	Step 1	Step 2	Step 3			
Lock/Unlock	Press+hold 3 sec Lights flash, then 2 € - Lock 1 € - Unlock					
Set Device ID		Press/Repeat to select the first Device ID (a-f)	Press/Repeat to select the second Device ID (1-6) Then press to set audible signal & lights will confirm			
Locate Device	Press/Repeat to select the first Device ID (a-f)	Press/Repeat to select the second Device ID (1-6)	Press to find Alarm will sound from the other device.			
Fine All with the same ID letter	Press/Repeat to select the first Device ID (a-f)	Press+hold 3 sec. All lights flash	Press to find All devices set to the same ID letter will alarm.			
Check Device ID	Press+hold 3 sec. Audible signal & lights will confirm ID No. of low <€ (a-f) No. of high <€ (1-6)					