

WARNING

Improper use of this equipment could cause a fire, damage to property, serious injury or death.

- Always use an outlet protected by a ground-fault circuit interrupter, rated at or above the amperage you intend to charge with. This outlet must be connected to a dedicated branch circuit. If you are unsure about the properties of your outlet, it is highly recommended to contact a certified electrician, who can check and upgrade the circuit.
- Connecting to a properly grounded outlet is mandatory to reduce the risk of electric shock.
- Never use an extension cord or conversion adapter. Many extension cords are underrated, thus causing the probability of fires and injury.
- Never use an outlet that is damaged, worn, cracked, loose or cannot hold the plug in place. Call a certified electrician to fix damaged outlets. Do not use an outlet that cannot be properly plugged into due to debris or deformation.
- Check that the plug is firmly inserted all the way into the outlet before further use.
- Under some circumstances it may be normal for the plug or cable to be warm after some charging. If you feel that the cable or plug become too warm or hot to the touch, immediately disconnect the charging equipment.
- Never remove the plug from the outlet by pulling on the cable. Each plug is designed to allow safe removal from the outlet.
- Never connect nor remove plugs with wet hands. This could cause electrical shock. Also note that a waterproof outlet is recommended. Otherwise, please avoid contact with water when using the equipment.
- To avoid the risk of shock, never attempt to disassemble or remove any parts from the equipment. There are no parts that can be serviced by untrained individuals.

Always refer to this User Manual and/or your vehicle's User Manual for instructions. If you are uncertain about any of the properties, use of or manipulation of the equipment, contact EVSELECT support or your authorized local EVSELECT dealer.

WARRANTY

All EVSELECT products are warranted to be free from defects in materials or workmanship for two years from the date of purchase. Within this period, EVSELECT will, at its sole option, repair or replace any components which fail in normal use. Such repairs or replacement will be made at no charge to the customer for parts or labor, provided that the customer shall be responsible for any transportation cost. This warranty does not cover failures due to abuse, misuse, accident or unauthorized alterations or repairs. THE WARRANTIES AND REMEDIES CONTAINED HEREIN ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, WHETHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING ANY LIABILITY ARISING UNDER ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, STATUTORY OR OTHERWISE. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, WHICH MAY VARY FROM STATE TO STATE. IN NO EVENT SHALL THE MANUFACTURER OF EVSELECT BE LIABLE FOR ANY INCIDENTAL, SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES, WHETHER RESULTING FROM THE USE, MISUSE OR INABILITY TO USE THE PRODUCT OR FROM DEFECTS IN THE PRODUCT. SOME STATES DO NOT ALLOW THE EXCLUSION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

Your product warranty will become void if:

- The equipment is handled in such a way that caused internal or external damage by impact or force.
- The equipment was used in an improper outlet.
- Any parts, internal or external, are removed, disassembled, tampered with or serviced by unauthorized individuals. This includes removal or tampering with the black seals covering any screws.