


BRIK



Input Selector

User Manual

BRIK

Dear User,
Thank you for purchasing BRIK **Input Selector**.
Please read this User Manual before operating the machine to ensure its best performance and your safety.

Instructions:

Connecting Source

▪ Connect D/A Converter, Bluetooth Stage, Internet Radio, Phono Stage, CD Player, or other line level sources through front panel **Input 1 to 6** on the rear panel.


Choosing Source

▪ Use the botton **1 to 6** on the front panel to choose the music source.

BRIK **Input Selector** can be connected with your current devices, or BRIK D/A Converter, Bluetooth Stage, Internet Radio, Phono Stage, Equalizer Stage, to fulfill your varied Hi-Fi requirements.

Please set up your Audio system and have an Audio Carnival with BRIK **Input Selector** now!

* For more BRIK products information, please visit www.brik-audio.com.



Specifications:

INPUT OPTION	RCA Line Input x 6
DIMENSION	W 140 x H 48 x D160 mm
WEIGHT	1000 g


NOTE

- BRIK **Input Selector** operates in accordance with its specifications within environment temperature 40 degrees Celsius.

WARNING

- Never open the case of this item as this will invalidate the guarantee. There are no user adjustments inside. Please refer all service work to an authorized BRIK agent.

- This item shall not be exposed to dripping or splashing liquid, and that no objects filled with liquids, such as vases, shall be placed on the apparatus.



BRIK

WWW.BRIK-AUDIO.COM

CE ~~RoHS~~

The information was correct at the time of going to press. The manufacturer reserves the rights to make changes to the technical specification without prior notice.

The manufacturer accepts no responsibility for damage caused by not adhering to these instructions for use. Modification or change to any part of the product by unauthorized persons releases the manufacturer from any liability over and above the lawful rights of the customer.