

www.lifetime.com

For U.S. and Canada Customers ONLY: IF ASSISTANCE IS NEEDED.

DO NOT CONTACT THE STORE!!!

CALL OUR CUSTOMER SERVICE DEPARTMENT at 1 (800) 225-3865

HOURS: 7:00 a.m. to 5:00 p.m. Monday through Friday (MST)
Call, or visit our Web site for Saturday hours

Customers outside the U.S. or Canada, please contact the store.

BACKBOARD AND RIM COMBO


MODEL #73729



Failure to comply with any of the warnings in these instructions may result in serious personal injuries such as cuts, broken bones, nerve damage, paralysis, brain injury, or death. Failure to comply may also result in property damage. Please heed all warnings and cautions. To ensure your safety, do not attempt to assemble this system without reading and following all instructions carefully. Identify and inventory the parts using the Parts List.

ASSEMBLY INSTRUCTIONS AND OWNER'S MANUAL

> **A MINIMUM OF TWO ADULTS ARE REQUIRED FOR ASSEMBLY**




Save this instruction in the event that the manufacturer has to be contacted for replacement parts.

PARTS LIST Part # Description Qty AA 825619 Rim AB 1030889 Backboard AC 502005 Net AD 502056 Plastic Guard ΑE 800165 Rim Cover Plate 2 AF CB08999 Corner Frame Pad ПАН AG CB09099 Center Frame Pad 804018 Rim Pivot Bracket П 804033 Spring Retainer Plate Rim Hardware (HD9136B) BS01000 #7 x 3/8" Screw RC 300106 5/16" x 2" Carriage Bolt 2 2 RD300114 5/16" Push Nut 2 RE 302011 5/16" x 1 1/4" Carriage Bolt 2 RF 302014 5/16" Flat Washer RG 302061 5/16" x 5" Hex Bolt 6 RH 302090 5/16" Nylock Flange Nut RΙ **Compression Spring** 502060 RJ 510038 3/8" x 5 1/2" Axle Frame Pad Hardware (HH00700) BS00100 #10 x 7/8 Self Drilling Screw 10 🗖

HARDWARE IS ACTUAL SIZE

(Unless otherwise indicated)





1. The Backboard can be mounted to any Lifetime Products® brand pole or most other commercially available poles. If using other than a Lifetime Products® pole, the mounting bracket design must provide adequate support behind the Rim mounting holes as well as the upper Backboard mounting holes. If adequate support is not provided, the Backboard may be damaged and the warranty will be void. Lifetime Products, Inc.® offers a pole system with a height adjusting mechanism that can be used to safely mount this Backboard. Please Call Customer Service at the number on Page One for more information.

(RA

RH

2. If using an existing pole system that does not include extension arms, or if a pole system is not being used, see Page 8.



SAFETY INSTRUCTIONS



Failure to follow these safety instructions may result in serious injury or property damage and will void the warranty. The owner must ensure that all players know and follow these rules for safe operation of the system.

- Proper and complete assembly, use, and supervision is essential for proper operation and to reduce the risk of accident or injury. A high probability of serious injury exists if this system is not installed, maintained, or operated properly.
- If using a ladder during assembly, use extreme caution. Follow all warnings and cautions on the ladder carefully.
- Two people are required for assembly.
- Climate, corrosion, or misuse could result in system failure.
- If technical assistance is required, contact the manufacturer.

Most injuries are caused by misuse and/or failure to follow instructions. Use caution when using the system.

Tools and Materials Required for assembly (Not Included)

- 1. Adjustable Wrench
- 2. 1/2" Wrenches (2)
- 3. Electric Drill
- 4. 1/2" Socket Wrench




STOP!

BEFORE BEGINNING ASSEMBLY



- A. Identify and inventory all parts using the checklist boxes on the Parts List. Keep the hardware bags and their contents separate. If any parts are missing, call our Customer Service Department.
- B. Test fit all Bolts by inserting them into their respective holes. If necessary, carefully scrape away any excess powder coating buildup from inside the holes. Do not scrape away all of the powder coating. Bare metal may rust.

ATTENTION: This Backboard is *not* designed for custom installations. The Backboard is designed for use with a Lifetime Products® Pole Mounting Unit or Universal Mounting Bracket. If a Pole or Mounting Bracket is being used, mount the Backboard and Rim using the hardware included with the Pole system or Mounting kit and according to the directions included with that product. Depending upon which mounting method is used, you will follow either Option 1 or 2 according to indications on the next page. The Pole or Mounting Bracket will include a set of Backboard Brackets. **Note:** A Universal Mounting Bracket will allow you to install the Backboard to a wall, roof, or 3 1/2" Pole.



NOTE: Do not mount the Rim directly to the Backboard. The strike plate on the Backboard is not designed to hold the weight of the Rim, and will not be able to support it. If you need to mount the Rim to the Backboard without using a Pole system or Universal Bracket system, you must place a metal support plate behind the Backboard. Failure to use a support plate will result in damage to the Backboard. Support must also be provided at the top of the Backboard using the Carriage Bolts in the slots as shown on Pages 4 and 5 in these instructions.

Register your product online at www.lifetime.com.

At Lifetime, we are committed to providing innovative and quality products. While registering, you will have the opportunity to give us your feedback. Your input is valuable to us.

You can also opt-in to receive new product notifications or promotions.

In the unlikely event of a product recall or safety modification, your registration provides the information we need to notify you directly.

Registration is fast, easy, and completely voluntary.

Maintaining your privacy is our long-standing policy at Lifetime. And you can rest assured that Lifetime will not sell or provide your personal data to other third parties, or allow them to use your personal data for their own purposes.

We invite you to read our privacy policy at www.lifetime.com

REGISTER today!



WARNING




The Rim and Backboard Combo kit must be mounted and supported properly. Damage will occur if sufficient Rim support is not provided.


Required for this page:

1/2" Wrench

HD9136B



If you have Backboard Brackets that come with a U-Bolt, use Option 1 and the U-Bolt provided with the Brackets. If the Backboard Brackets don't include a U-Bolt, use Option 2 instead.



(2)

OPTION 1 THIS OPTION IS FOR USE WITH BACKBOARD BRACKETS AND A U-BOLT.


ASSEMBLE THE U-BOLT (PROVIDED WITH THE BACKBOARD BRACKETS) TO THE BACKBOARD BRACKETS ACCORDING TO THE INSTRUCTIONS PROVIDED

STEP 1B

IN THE POLE OR MOUNTING BRACKET UNIT. STEP 1A Lay the Backboard (AB) on a table or bench.

The U-Bolt (UB) goes through the upper holes in RC the Backboard.

STEP 1C riage Bolts.




Slide the Carriage Bolt (RE) into


the crimped slot in each Back-

Only hand tighten the Nuts (RH) now.


NOTE: The Backboard Brackets shown are Lifetime Products® models and are for illustration purposes only. If using Brackets other than the Lifetime Products® models shown here, refer to the instructions provided with the Brackets.



To finish the assembly, turn to Page 6



RE



Required For This Page:

1/2" Wrench

1/2" Socket Wrench

Screwdriver


HD9136B








(RD)(2)




Use the 1/2" socket head from the socket head wrench to press one Push Nut (RD) onto one end of the Axle (RJ).




Note: The Push Nut should rest about 1/4" from the end of the Axle. If the Push Nut slips on too far, continue sliding it to the other end of the Axle to remove it and try again.


Turn the Backboard over so it faces up.

Slide the end of the Axle (RJ) through the Rim (AA) and the Rim Pivot Bracket (AH). Press the Push Nut (RD) onto the end of the Axle. Use the 1/2" socket head to secure the Push Nut if needed.







If the unit with the U-Bolt includes Jam Nuts (pictured actual size below) they are to be secured onto the ends of the U-Bolt or Hex Bolts here.




Slide the Compression Springs (RI) onto the legs of the U-Bolt or Hex Bolts.




Tighten the Nylock Flange Nuts (RH) until the Rim is under the desired tension.



Fasten the Rim Cover Plate (AE) to the Rim (AA) using the #7 x 3/8" Screws (RA).







FROM THIS POINT ON FOLLOW THE INSTRUCTIONS PROVIDED WITH THE POLE OR MOUNTING UNIT.

NOTE: FAILURE TO PROVIDE ADEQUATE SUPPORT BEHIND THE BACKBOARD WILL VOID THE PRODUCT WARRANTY. FOLLOW ALL ASSEMBLY INSTRUCTIONS CAREFULLY.

ROOF MOUNT, WALL MOUNT, EXISTING POLE MOUNT

If mounting the Backboard to a roof mount, wall mount or existing pole mount that does not have an extension provided, you must use a Mounting Bracket Kit designed for this purpose. Lifetime Products, Inc.® offers a Universal Extension Bracket, Model #9594, through our Customer Service Department. Figures A, B and C show the Bracket mounted to a roof mount, a wall mount and an existing pole mount. Please see below for ordering information.








FIGURE A, ROOF MOUNT

FIGURE B, WALL MOUNT

ACCESSORIES AVAILABLE FOR MORE BASKETBALL FUN!

PRODUCT DESCRIPTION

MODEL#

Universal Extension Bracket Intermediate Size Basketball 9594


594201

Call the Customer Service Department at the number on Page One for prices and shipping costs.

To place orders, use a Master Card or Visa and call our Customer Service Department or send check or money order to: LIFETIME PRODUCTS, INC. P.O. BOX 160010 BLDG. D-11, FREEPORT CENTER **CLEARFIELD, UT 84016-0010**

Universal Extension Bracket #9594

Ideal for mounting Backboard and Rim sets to a pole, wall or roof. (Backboard and Rim not included.)



LIFETIME BASKETBALL EQUIPMENT 5-YEAR LIMITED FACTORY WARRANTY

THE MANUFACTURER RESERVES THE RIGHT TO MAKE SUBSTITUTIONS TO WARRANTY CLAIMS IF PARTS ARE UNAVAILABLE OR OBSOLETE.

1. Lifetime basketball systems are warranted to the original purchaser to be free from defects in material or workmanship for a period of five years from the date of original retail purchase. The word "defects" is defined as imperfections that impair the use of the product. Defects resulting from misuse, abuse or negligence will void this warranty. This warranty does not cover defects due to improper installation, alteration or accident. This warranty does not cover damage caused by vandalism, rusting, "acts of nature" or any other event beyond the control of the manufacturer.



- 2. This warranty is nontransferable and is expressly limited to the repair or replacement of defective basketball equipment. If the equipment is defective within the terms of this warranty, Lifetime Products, Inc. will repair or replace defective parts at no cost to the purchaser. Shipping charges to and from the factory are not covered and are the responsibility of the purchaser. Labor charges and related expenses for removal, installation or replacement of the basketball system or its components are not covered under this warranty.
- 3. This warranty does not cover scratching or scuffing of the product that may result from normal usage. In addition, defects resulting from intentional damage, negligence, unreasonable use or hanging from the net or rim will void this warranty.
- 4. Liability for incidental or consequential damages is excluded to the extent permitted by law. While every attempt is made to embody the highest degree of safety in all equipment, freedom from injury cannot be guaranteed. The user assumes all risk of injury resulting from the use of this product. All merchandise is sold on this condition, and no representative of the company may waive or change this policy.
- 5. This product is not intended for institutional or commercial use; Lifetime Products, Inc. does not assume any liability for such use. Institutional or commercial use will void the warranty.
- 6. This warranty is expressly in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for use. Neither Lifetime Products, Inc., nor any representative assumes any other liability in connection with this product.

ALL WARRANTY CLAIMS MUST BE ACCOMPANIED BY A SALES RECEIPT. REPORT PRODUCT DEFECTS IN WRITING TO:

Lifetime Products, Inc., PO Box 160010 Clearfield, UT 84016-0010 or call (800) 225-3865 M-F 7 a.m. to 5 p.m. MST.

Please include your dated sales receipt and photographs of damaged parts.

To Register Your Product, Visit Our Website at www.lifetime.com