


SINGER
306K25

Machine No. 306K25

List of Parts—Machine No. 306K25



ATTACHMENT SET 168977

55623	Bobbin (4)
81245	Binder
86742	Ruffler
105248	Presser Foot
105251	Special Purpose Foot
161127	Zipper Foot
161133	Tube of Oil
161294	Screwdriver (LG)
161295	Screwdriver (SM)
161455	All Purpose Foot
173090	Throat Plate
189632	Embroidery Plate
189648	Button Foot
2029(206x13)	Needles 11 (3) 14 (3)
2035(306x1)	Needles (Twin) 14 (3)

List of Parts—Machine No. 306K25

