



LEDBEEIVE USER MANUAL



Please read this manual before your use and keep it for your future reference.

Note:

Please use the to avoid any trouble for the fixture.

The operation temperature is below 40°C , humidity is 0~95%. If you use it out of this range, the fixture will be shorten the lifespan.



Indoor use only

Caution:

Please do not connect the power when the fixture is still in the box.

Please do not connect the power before the installation. The fixture must be linked to the earth wire.

If you met the problem for this fixture, please call the engineer for the repair. Do not open the fixture by yourself.

Please must use the same input voltage as per our instruction.




Specification:

1. Power: 120V, 20W
- 2 Fuse: T1A/250V/T2A/125V
3. LED Quantity: 6pcs of LED(3W red LED 2pcs、 3W green LED 2pcs、 3W blue LED 2pcs)
4. LED Beam Angel: 130°; Luminous Flux: 80LM.
5. Working Mode: Sound, Auto.
6. Net Weight: 3.6 KG
7. Size: 378*316*268MM (L x W x H)

Operation Instruction

SRL-465-RGB uses High Power LED to make the colorful effect. The function are Sound and Auto. If it is at Sound mode, the various effect will be controlled by the Sound Potentiometer. If it is at the Auto mode, this fixture will be running automatically.

Connector instruction:



1. Sound/Auto Switch (You can choose the Sound mode or Auto mode with this switch)
2. Fuse
3. Power Cable
4. Sound Potentiometer (Adjust the sensitivity of the sound)
5. Midi connector

Installation:

For Hanging or Putting in the flat surface

This fixture can be putting in the flat surface or hanging with the clamp. If you want to hang it, please be sure that you will fix it in the clamp as per the below sketch map. For more safety, please use the safety cable to hang the fixture. Please note that the safety cable must be able to hang up to 10 times weight of this fixture.



Trouble Shooting:

1. If the fixture's light does not turn on, please check the power connection and make sure that the switch is connected.
2. If the fixture sometimes light on and sometime shut off. Please check if the power is not connected properly or loosen wire in the cable. If you cannot correct it, please call the certificated engineer for the maintainance and service.
3. If you have any questions for this manual, please contact the certificated engineer.