

**SAMSUNG**



# HEADSET Quick Start Guide

## HM1100

MOBILE ENHANCEMENT

### Headquarters:

1301 East Lookout Drive Richardson,  
TX 75082

### Internet Address:


[www.samsungmobileusa.com/  
accessories](http://www.samsungmobileusa.com/accessories)

### Customer Care Center:

1-800-SAMSUNG

Code No.: GH68-29809J  
NA. 11/2010. Rev.1.1

## Your headset overview



- Make sure you have the following items with your headset: travel adapter, ear pieces, earhook and user manual.
- The items supplied with your headset may vary depending on your region.



- Use only Samsung-approved chargers. Unauthorized chargers may cause an explosion or damage to the headset.
- The battery will gradually wear out while charging or discharging because it is a consumable part.
- When a call comes in while charging, disconnect your headset from the travel adapter and answer the call.

## Checking the battery level

At the same time, press and hold the Volume down and the Talk button. Depending on the battery level, the indicator light flashes 5 times in one of the following colors:

Battery level	Indicator light color
Above 80 %	Blue
80 ~20 %	Violet
Below 20 %	Red

## Charging the headset

- 1 Connect the charger to the headset (see below images).



- 2 Plug the charger in to the wall outlet. During charging, the indicator light will turn red. If charging does not begin, unplug the travel adapter and plug it in again.
- 3 When the headset is fully charged, the indicator light changes to blue. Unplug the travel adapter from the power outlet and the headset.


### When the battery charge gets low

The headset beeps and the indicator light flashes red. Recharge the battery. If the headset powers off during a call, the call will be automatically transferred to the phone.

### Wearing the headset

Place the headset on your ear.

Depending on what ear you are going to wear the headset, simply adjust the ear hook accordingly.



- Your headset supports the Simple Pairing feature which allows the headset to be paired with a phone without requesting a PIN. This feature is available for phones that are compliant with Bluetooth version 2.1 or higher.

### Disconnecting the headset

To disconnect the headset from your phone,

- Turn off the headset.
- Use the Bluetooth menu on your phone.

### Reconnecting the headset

When the headset is paired with a phone, it will attempt to automatically reconnect each time you turn it on.

If the headset does not automatically attempt to reconnect,

- Press the Talk button.
- Use the Bluetooth menu on your phone.

### Using call functions

Available call functions may vary by the phone.

### Turning the headset on or off

- To turn the headset on, slide up the power switch. The blue indicator light flashes 4 times.
- To turn the headset off, slide down the power switch. The indicator light flashes red then turns off.

### Pairing and connecting the headset

#### Pairing and connecting the headset with a phone

- 1 Enter Pairing mode.
  - With the headset turned on, press and hold the Talk button until the blue indicator light stays lit.
  - If you turn on the headset for the first time, it proceeds into Pairing mode immediately.
- 2 Activate the Bluetooth feature on your phone and search for the headset (see your phone's user manual).
- 3 Select the headset (HM1100) from the list of devices found by your phone.
- 4 Enter the Bluetooth PIN (0000, 4 zeros) to pair and connect the headset to your phone.

### Making a call

#### Redialing the latest number

Press and hold the Talk button to redial the latest number of the most recently connected phone.

For some phones, pressing the Talk button opens the call log list. Press the Talk button again to dial the selected number.

#### Dialing a number by voice

Press the Talk button and say a name.

#### Answering a call

Press the Talk button to answer a call when you hear incoming call tones.

#### Ending a call

Press the Talk button to end a call.

#### Rejecting a call

Press and hold the Talk button to reject a call when a call comes in. This function is available only on the Hands-Free profile. For more information, see your phone's user manual.