


#### **Technical SUMMARY**



	Green fixed	ready
1= 11 0X=	Green blinking	Cleaning cycle in progress
	Red blinking	Fault indicator : number of blinks indicates error number (see Ottimo user manual)
	Red fixed	Boiler temperature too low
	Orange fixed	Programming mode
	Red fixed	Water level low
	Blue fixed	Replace Brita filter
	off	Brita water filter OK

### Replacement of cartridges



Right cartridge holder reserved for coffee only

Left cartridge holder can hold coffe, chocolate or cappucinno



Inser cartridge till the bottom

### Filling the water tank



Lift the watertank vertically upwards



Replace watertank until flush with frame



#### **OTTIMO USER GUIDE**


ATTENTION ! ! : switch off power before removing the hood



## Daily maintenance (automatic cleaning of mixing bowls )

In order to assure optimum delivery of your beverages and meet the hygiene standards a daily cleaning of the mixing mechanism is recommended. This will also prevent claughing of the machine by remaining powder residu.

It is not necessary to remove the cartridges...






ensure the opening of the dispensing mechanism is pointing to the bottom

# cleaning the drip tray







# **Remplacement of Brita water filter**





#### Reset the water counter

Switch off the machine

Push expresso button, keep pushed and switch machine on Blue led blinks Push expresso button again to reset

Blue led goes out and procedure terminates .

Version en français disponible chez votre concessionnaire Fountain This card is available in your language . pls contact your local Fountain dealer