

Manual

Baby Merc Q7 Deluxe



The pram is intended for children from the age of 0-3 years and an approved weight to 15 Kg.

The pram meets the EU safety standards
EN 1888: 2002 + A1: 2005 + A2:2005 + A3: 2005

The Baby carrier (car seat) meets the safety standard ECE 44/04

Please read all instructions carefully before using your pram and keep it on for future reference and feedback. If you do not follow these instructions you may impair the safety of your child.

If you do not understand the instructions and need more information, please contact your dealer.

Make sure that other users are aware of the functions of the car and the safety.

Table of Content

Congratulations.....	2
Assembly instructions.....	2
Build up your pram.....	2
The swivel wheels.....	2
Construction and installation of the baby tube.....	3
The Carrycot.....	3
Assembling the pushchair seat.....	4
Adjust the foot rest as required.....	4
Adjusting the seat back.....	4
Assembling the infant car seat.....	4
Dismantling the infant car seat.....	4
Safety belt.....	4
Collapsing the pushchair.....	5
Unlocking the swivel wheels.....	5
Care instructions.....	5
Maintain the fabric pieces.....	5
Maintenance of the chassis.....	5
Loss of air wheels.....	5
For the safety of your Child.....	5
Quality agreement.....	6
2 years warranty.....	6
Warranty in case of complaints.....	6
No warranty.....	6
Use, care and maintenance.....	6

Congratulations

So that the baby feels safe and secure, you have chosen a quality product from the house of lux4kids and therefore you made a very good choice. High quality workmanship and ongoing quality control systems give you the security that you have a stroller for a very long time. The use of textiles tested for harmful substances guarantees you the safety of your baby.

Assembly instructions

Build up your pram

1. Pull the frame upwards on the handlebar until it snaps into the right place.
2. Press the button on the rear wheel and push it on the rear axis until you hear a silent click – now release the button. Now check the wheel if it sits firmly
3. Push the front wheel with the rod into the guide until you hear a silent click.

The swivel wheels

The wheel blockade must be active so the wheel is fixed.
Release the blockade to swivel the wheels again.



WARNING: The maximum load of the basket is 3 KG!

Recommendations: The wheels and axles should be kept clean and a regular use of machine oil (WD40) on wheels and axles is recommended.

Construction and installation of the baby tube

The Carrycot

Picture 1. Unfold the bassinet (by pulling the fabric upward) and lock the metal stays in their catches. Picture 2.



Picture 1:



Picture 2:

Insert the fleece lining. Complete the procedure by joining the hook and loop fastenings.

Please press the 2 buttons on the hood (Picture 3)



Picture 3:

Push the two hood knobs at the same time and set the hood to the required height.

Picture 4



Picture 4:

In order to attach the bassinet to the frame, unlock the guides shown and place the bassinet into them until it locks into place with a click (push the round button downwards and then pull the lever).

Now, using the guide hooks, put the bassinet in place, first inserting the side that cannot be locked.



IMPORTANT: The lock must be adjusted so that you can reach it!

To dismantle the bassinet, loosen the locks by following the arrows. You can now remove the bassinet from the front.

Tip: It is best if you nudge the bassinet out with your knee..

Recommendation: Before using the bassinet, check that all the locks are secure.



Assembling the pushchair seat

Place the seat so that the two rods on the frame are parallel with each

other. Then lock these using the safety closure

Unfold the hood to the required position.



Attach the safety bar.

Adjust the foot rest as required

To adjust the foot rest, press both buttons simultaneously as shown and move the foot rest to the required position.



Adjusting the seat back

Pull the unlocking rod upwards and move the seat to the required position.



IMPORTANT: *the pushchair seat is assembled and dismantled in exactly the same way as the bassinet.*

Assembling the infant car seat

Fit the adapter to the infant car seat. Caution: The adapter only works in one direction – it must be assembled exactly

Dismantling the infant car seat

Pull the two unlocking levers simultaneously and the adapters will release.

Safety belt



Secure your child with the belt. Make sure that the belt is tight, you can adjust that with the slide buckle. Make sure that the belt buckles for secure are attached during closing. Open the belt: Press the RED Dot and both tabs open and you can take your child out of the seat.

Collapsing the pushchair

Pull the two latches simultaneously and the pushchair will collapse. Now push the safety catch to one side, so that the frame can fold.



Unlocking the swivel wheels

To unlock the wheels, please press in the small steel pins above the fixings for the swivel wheels, and the wheel will fall easily from the guide.



Care instructions

All materials are easy to maintain

Maintain the fabric pieces

To clean dirty fabrics use only a clothes brush or clean water (dry with a hair dryer), avoid hard rubbing. Stubborn stains can be removed with a mild detergent. If you ever get in a heavy rain, dry your pram with stretched fabrics in a warm dry room, to avoid moisture in the inner fabric. A guaranteed weather protection is only granted when you use our rain cover. Besides our positive qualities, our fabrics react to intense solar radiations. Therefore we recommend that you park your pram in the shade.

Maintenance of the chassis

The chassis requires a special maintain. The axles must be cleaned up every 4 weeks and then use machine oil (WD40). Moving parts can be kept functional by using silicon spray. A squeaking chassis can so be prevented. Chrome-plated parts and metal parts must be kept clean and can be maintained by using car polish if necessary. Small paint damages on the frame must be wiped immediately with a paint pen to avoid rust. Screws on the frame should be checked every month and maybe re-tightened.

Never use a pressure washer, ball bearings of the wheels and functional parts can be destroyed (Grind- and squeaking noises)

Wheels: Caution to the right pressure on the tires. A sufficient air pressure can damage the rim. The pressure must be between 0,8 and max. 1,2 bar

WARNING! The max pressure filling is quickly reached, an excess can lead to accidents and injuries. The plain-wheel bushes and the springs have to be renewed on time. Avoid a longer parking of pneumatic tires on light PVC or linoleum floors. Because of all rubber tires on the market can cause discolorations. Small pebbles in the rubber wheels can also damage the flooring. Our wheels are under pressure, so direct solar radiation and the stowing in the luggage compartment under pressure at temperatures above 45°C can flatten or crush the filled tire.


Loss of air wheels

To prevent a total loss of air and a wobbling of the wheels. Half fill the wheels and then set up the mature coat until the wheel runs smoothly. Finally pump up the wheels until max.


For the safety of your Child


WARNING: Check that the pram is not damaged and no parts are cracked or broken


 before us it.


 WARNING: Never leave your child alone in the pram.


 WARNING: Before use check that all locks are closed


 WARNING: Driving on stairs or steps, a heavy load can damage your pram and bring your child in danger


 WARNING: Your stroller must be fixed any time you set it up. Be careful in public transporters to secure the footing


 WARNING: pram, pushchair and carrier bags are no bed or cradle replacements and can only be used for traveling and transporting children.


 WARNING: Make sure, that your child is not nearby the pram when you unfolding it.

 WARNING: Don't let your child play with the pram.


 WARNING: Any load attached to the handle affects the stability of the stroller.

 WARNING: This model is suitable for 1 child.


 WARNING: The seat unit, the pram top and the carrying bag can not be used to transport your child in the car.

 WARNING: Use a safety belt as soon your child can sit alone.

 WARNING: Always use the child restraint.

 WARNING: Before use it is necessary to check that the carrycot or the seat unit is correctly engaged.

 WARNING: For safety reasons: Only use original accessories and spare parts

 WARNING: This product is not suitable for jogging and skating.

 WARNING: The seat unit is not for children under the age of 6 month.

Quality agreement

2 years warranty

With this product you have a warranty against your contract partner for 2 years. The warranty period begins with the delivery of the product. Please keep this completed form signed, your sales receipt to prove. The warranty applies to all material and manufacturing defects that are at time of delivery

Warranty in case of complaints

The warranty refers to all material and manufacturing defects existing at time of delivery

No warranty

Damage caused by improper use (see instructions)

Damage caused by faulty installation or commissioning

Damage caused by careless handling or improper maintenance of the purchased goods

Damage due to improper modifications of the purchased item

Use, care and maintenance

The stroller is for transporting children and must be maintained according to the

instructions above.

Have fun with your brand new stroller. Your lux4kids Team!

Your Retailer

Sellex Place
Bövemannstraße 3e
48268 Greven
Tel.: 02571/9195720
Fax: 02571/91957210
lux4kids Store
Hammerstraße 350
48153 Münster
Tel.: 0251/ 87136739