

**Mini Pen Interview Recorder
User Manual**

CATALOG

Notice: 2

Feature: 2

Standard Fitting: 2

Host Interface: 2

Operation manual: 2

FAQ: 3

Especially statement: 3

Mini Pen Interview Recorder User Manual

Thank you for purchasing our mini interview recorder. Please read the user manual before you use it. We think you have read the user manual when you start to use it.

Notice:

1. Please don't use it in the environment of high temperature, dust and humidification.
2. Avoid of using it in the environment of especially dryness to prevent from static.
3. Do not strike with hard thing, otherwise it will induce to damage the crust and hardware.
4. Please do not break off the connection when you are formatting, passing or downloading the document. otherwise it will induce to the system error.
5. When it is as the mobile disk, please save the export document with right file management operation. we are not responsible for your wrong operation result in document lost
6. Please do not take apart it, you can charge the battery with USB, but do not recording while you are charging the battery.
7. If it can not shut down, record or connect to the computer, Please resume the originally setting.

Feature:

1. The special design, well concealment
2. Clear camera, clear image
3. Record the video and audio synchronously
4. Video Dimension: 352*288
5. Internality high Lithium-ion battery
6. Flash memory: 1GB to 8GB

Standard Fitting:

1. Mini interview recorder 1pc
2. CD 1pc (manual, play software, time adjust file)
3. USB 1pc
4. Charger 1pc

Host Interface:



① Camera ② MIC ③ USB ④ Record and Power Light ⑤ Power ON/OFF
⑥ Reset

Operation manual:

OPEN

Press the switch one time, the yellow light turned on, it is in Startup Mode.

RECORD

After the start-up, without any operation, it start to record after five seconds automatically, meanwhile, yellow light turn into blue.

SAVE FILE

In the recording mode, press the key one time briefly, two seconds later, the blue light turns into yellow, video files saved automatically, the yellow light keeps on until it shutdown, Indicating it is in the standby mode (that is, no recording nor shutdown); if you want to record again, press the switch again briefly, it turn into the recording mode after two seconds, then yellow light turns into blue; you can repeat the same operation, until the battery is depleted; and the video file is automatically saved before the device shut down.

CLOSE

In standby mode, press the switch two seconds, then let slip, after the flashing yellow light is off, it is in the shutdown mode. In the recording Mode, press the key two seconds, then let slip, the blue light out, video automatically save and shutdown, no lights indicate when it is in shutdown mode.

PLAYBACK

Connected the USB interface to the computer , find the USB Flash Disk in "My computer", video files are in the VIDEO_RECORD folder of the USB Flash Disk, such as VIDEO_REC_000005.we recommend you watch the video files with "KMPLAYER"(a media software can be downloaded on the internet)

INDICATE RECORDING TIME

The video files has watermark of the time, it can take down the current time when recording the video, and we did not adjusted the time before they leave the factory.if you found the time is inaccurate,you can adjust it yourself,it's easy to operate:Connect it to the computer when DVR PEN is in shutdown mode,copy the file "SysTime.txt" into root directory of USB Flash Disk,pull out it and plug it into computer again with USB interface,it adjusts the time automatically,and the file "systime.txt"was also deleted of itself. The file "systime.txt" is in order by year,month,day,hour,minute,second,such as "20080102235909",that is:23:59:09,Jan 02,2008, you can amend the time with notepad,

CHARGE

The yellow light blink ceaselessly when you are using,it means the battery will be exhaust,Please press the switch key lasting for two seconds to off the host,then charge the battery in time.This device with the standard USB2.0 interface, you can use USB interface connected to the computer to charge, and can also use charger to recharge, when charging with USB interface, the blinking yellow light indicates it is charging, the yellow light stop blinking indicates charging completed,the Charger should Always on the red light, if red light is not on, check if the importation of AC power charger is correct, host yellow light blinking indicates it is charging , While the green light on ,the charger stop flashing yellow light indicates the charging has finished.

Note

When connecting to the computer , USB charging, pulled out after the charge finished, the yellow light will be still on than off, Do not worry, it's normal.

FAQ:**Q:why it is in the state of no response and easy to get in trouble of system halted when I press the switch key continually?**

A:when it act the function of switch ,start /stop record. , it just can be actualize by the time of pressing the key, because it was design as the single key .Please handle the product according to the manipulation of time

waiting.

Q:why the time watermark is not enough nicety after updateing the system time.frequently?

A:Because the battery support the system time's working. Please do not exhaust the battery and charge the battery in time,or keep the battery is full and adjust the time before you use.

Q:why I can hear the voice but can not see the image?

A:Maybe the camera is excursion duing the long-distance transport. it conduced the crust to ward off the visual angle of the camera. Please use the slender batten to revise,but not use the metal object ,otherwise,it will damnify the camera.

Q:why I can not find the mobile disk when connect with the computer?

A:Please confirm your computer's operating system . It can identify and install the correspond drivers automatically.in WINDOWS98SE/ME/2000/XP/MAS OS/LINUX. WINDOWS98 need to install drivers that record in the CD manually.

Q:why it is system halted according to the manipulation? What should I do?

A:It will happen system halted inevitably in the long-time working. Please do not worry,it just use the slender pin to insert in the reset hole one time ,it will reset the originally setting. If it happen frequently ,please contact with your supplier,we will help you to resolve as soon as possible.

Especially statement:

This product just can be used for taking evidence by policeman, lawyer, journalist and gownsman, it is forbidden to use it in illegal way, If violated the law, our company won't be responsible for it.