

SPKR-M2



USER'S MANUAL

Please read manual before initial use

WARRANTY

Subject to the terms and conditions set forth herein, YC Cable (East), Inc. ("YC Cable") provides this Limited Warranty only to the consumer who originally purchased this Grandmax product from YC Cable or its authorized reseller or distributor, and such product from this Grandmax line was purchased and delivered within the fifty states of the United States, the District of Columbia, U.S. Possessions or Protectorates, U.S. Military Installations, or addresses with an APO or FPO.

LIMITED WARRANTY: YC Cable warrants that its Grandmax Mini Tweakers will be free from material defects in workmanship and materials under normal use within 6 months ("Warranty Period") from the date of original retail purchase (all non Grandmax products are excluded from this warranty).

CUSTOMER'S EXCLUSIVE REMEDIES: The customer's sole and exclusive remedy and the entire liability of YC Cable and its suppliers will be, at YC Cable's option, to repair or replace the defective Grandmax product during the Warranty Period at no charge to the original owner. The replacement need not be new or have an identical make, model or part as long as YC Cable at its sole discretion determines that the replacement is materially similar to the defective Grandmax product (all non Grandmax products are excluded from this warranty).

SUBMISSION OF A CLAIM: The customer shall submit a claim to YC Cable as outlined below:

- The customer must obtain a Return Material Authorization ("RMA") number by sending YC Cable an email via support@grandmax.com or call its toll free number at 1-888-276-GMAX (4629). No claim will be processed by YC Cable without an issuance of RMA.

- After an RMA number is issued, the defective Grandmax product (excluding non Grandmax products) must be packaged securely in the original or other suitable shipping package to ensure that it will not be damaged in transit, and the RMA number must be prominently marked on the outside of the package. The customer must also enclose the proof of purchase (such as a copy of the dated purchase invoice for the Grandmax product).

- The customer is responsible for all in-bound shipping charges to YC Cable. No Cash on Delivery ("COD") is allowed. Any Grandmax product (excluding non Grandmax products) sent COD will either be rejected by YC Cable or become the property of YC Cable. Defective Grandmax products (excluding non Grandmax products) shall be fully insured by the customer and shipped to YC Cable at the following address: 121 Ethel Rd W, Ste 5A, Piscataway, NJ 08854. YC Cable will not be held responsible for any package that is lost in transit. The repaired or replaced package will be shipped to the customer via UPS Ground or any common carrier selected by YC Cable. Return shipping charges shall be prepaid by YC Cable if the customer uses an address in the United States, otherwise YC Cable will ship the Grandmax product freight collect.

- YC Cable may reject or return any Grandmax product that is not packaged and shipped in strict compliance with the foregoing requirements, or for which an RMA number is not visible from the outside of the package. The Grandmax product owner agrees to pay YC Cable's reasonable handling and return shipping charges for any Grandmax product (excluding non Grandmax products) that is not packaged and shipped in accordance with the foregoing requirements.

or that is determined by YC Cable not to be defective or non-conforming.

WHAT IS NOT COVERED: The Limited Warranty provided herein by YC Cable does not cover the following:

- Non Grandmax Products
- Grandmax products that, in YC Cable's sole judgment, have been subjected to abuse, accident, alteration, modification, tampering, negligence, misuse, faulty installation, lack of reasonable care, repair or service in any way that is not contemplated in the documentation for the Grandmax product, or if the model or serial number has been altered, tampered with, defaced or removed.
- Damage that occurs in shipment, due to an act of God, failures due to power surges, and cosmetic damage.
- Any hardware, software, firmware or other products or services provided by anyone other than YC Cable.

DISCLAIMER OF OTHER WARRANTIES: Except for the limited warranty specified herein, the grandmax product (excluding non grandmax products) is provided "as-is" without any warranty of any kind whatsoever including, without limitation, any warranty of merchantability, fitness for a particular purpose and non-infringement. If any implied warranty cannot be disclaimed in any territory where the grandmax product (excluding non Grandmax products) is sold, the duration of such implied warranty shall be limited to the duration of the applicable warranty period set forth above. Except as expressly covered under the limited warranty provided herein, the entire risk as to the quality, selection and performance of the grandmax product (excluding non grandmax products) is with the purchaser of the product.

LIMITATION OF LIABILITY: to the maximum extent permitted by law, YC Cable is not liable under any contract, negligence, strict liability or other legal or equitable theory for any loss of use of the grandmax product (excluding non grandmax products), inconvenience or damages of any character, whether direct, special, incidental or consequential (including, but not limited to, damages for loss of goodwill, loss of revenue or profit, work stoppage, computer failure or malfunction, failure of other equipment or computer programs to which YC Cable's grandmax line (excluding non grandmax products) is connected with, loss of information or data contained in, stored on, or integrated with any grandmax product returned to yc cable for warranty service) resulting from the use of the grandmax product (excluding non grandmax products), relating to warranty service, or arising out of any breach of this limited warranty, even if YC Cable has been advised of the possibility of such damages. The sole remedy for a breach of the foregoing limited warranty is repair, replacement, or refund of the defective or non-conforming grandmax product (excluding non Grandmax products). The maximum liability of yc cable under this warranty is limited to the purchase price of the grandmax product (excluding non grandmax products) covered by the warranty. The foregoing express written warranties and remedies are exclusive and are in lieu of any other warranties or remedies, express, implied or statutory.

INTRODUCTION - Congratulations on the purchase of Mini Tweakers, the portable palm speaker. Before initial use, please read this manual fully to obtain the best results to your new product and retain it for future reference.

CAUTION - To prevent the risk of electric shock, do not remove cover or attempt to disassemble product, no user serviceable parts inside. Refer service to qualified service personnel only.

SAFETY INSTRUCTIONS - Please read all the instructions herein. Please retain this manual for future reference. Please read all safety warnings. Please install in accordance with the Manufacturer's instructions.

WARNING!

TO REDUCE THE RISK OF ELECTRIC SHOCK:

Do not expose this apparatus to rain or moisture. Do not use the speakers near water, and do not immerse them in any liquid or pour liquid on them.

Do not block the openings in the speaker cabinets; never push objects into speaker vents or slots to avoid electric shock hazards. Provide sufficient space around the speakers for proper ventilation.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat. Heat - Place the speakers away from all heat sources such as heat registers, stoves, and direct sunlight.

Ventilation - Do not block the openings in the speaker cabinets, never push object into speaker vents or slots because of fire or electric shock hazards, and provide sufficient spaces around the speakers for proper ventilation.

Location - Place the speakers in a stable location so that it will not fall causing damage to the speakers or bodily harm.

Cleaning - Unplug the speakers from the computer and from the electrical outlet before cleaning them with damp cloth.

Lightning - For added protection during lightning storms, unplug the speakers from the USB port and turn off the computer.

Moisture - Unplug speakers and turn off power if liquid or moisture has entered speaker[s].



Please contact customer support before reuse. (888) 276-GMAX(4629)

OPENING THE BOX

Please check the package contents listed below should there be anything missing and or damage with this product please return to place of purchase IMMEDIATELY and or contact Grandmax Customer Support at (888) 276-GMAX (4629) for further assistance.


Packing list:

- 1 x Speaker
- 1 x Carrying Pouch
- 1 x Audio and Charge Cable
- 1 x User Manual



Do not attempt to use the Audio/Charge cable with any product other than Mini Tweakers.


1 DIAGRAM AND FUNCTION DESCRIPTION Speaker Unit



Note: Please charge speaker before initial use.

2 HOW TO CHARGE MINI


- Charge the speaker before initial use.
- To charge the speaker, insert the Mini USB connector into the charge port marked as shown Figure A. Then plug the Standard USB connector to any standard USB port of PC system, Laptop computer or USB power adapter as shown Figure B.




- When the battery is fully charged, the power indicator LED will turn Blue. Typical charge time is 3-5 hours. Charge time may vary depending on the type of USB charging source.
- Battery can be charged while playing. Plug the standard USB connector to USB port (as shown Step 2) at anytime during play. Note: Distortion or alternate noise may be heard if the unit is charging while play.

3 HOW TO CONNECT MINI

- Insert the Mini USB connector to the Audio In/ Charge port marked on speaker then insert the 3.5mm audio plug to the audio jack of music player or electronic device as shown in Figure 1.




- Switch the Off/On button to the On position as marked and it's ready to play



4 HOW TO SET UP MUSIC CHAIN

Music-Chain means to chain with additional Mini Tweakers and play through the same music source simultaneously to pump up the volume and sound. Simply insert 3.5mm audio plug of other chaining unit to the Music Chain/Line Out jack next to the Mini USB connector as shown in Figure 2.



SPECIFICATIONS

Output Power: 2W*1 (RMS) / 6W (PMPO)
 Charge Voltage: 5V DC (USB Power)
 Amplifier Frequency Range: 100Hz~20KHz
 SNR: 80+-3dB

WARNING

- Please do not throw the product into fire because this will cause personal injury.
- Please do not put the product in any damp or high-temperature areas.
- Please do not disassemble by yourselves to avoid electrical shock.
- Please do not put the product within easy reach of children.
- Please do not insert any conductive material into the speaker.

Dimension: D 60 x H 43mm
 Net weight: 65g



Copyright © 2009
 All Rights Reserved
 Manual Edition 1.0 Nov., 2009
 Printed in China