

- Ⓢ Telephone Helpline: 0845 146 2887 (United Kingdom) / 1300 225960 (Australia)
- Ⓢ Klantenondersteuning: 040 – 2628080 (Nederland) / 050 – 609999 (België)
- Ⓢ Standard d'assistance téléphonique: 01 64 89 73 61 (Français) / 050 – 600006 (Belgique)
- Ⓢ Telefonische Helpline: 0800 – 1860806 (Deutschland)
- Ⓢ Línea de asistencia telefónica : 901-100 133 (España)

GJ770 Commercial Grade Aluminium Gazebo

**!! PLEASE ENSURE YOU READ THESE INSTRUCTIONS CAREFULLY BEFORE ATTEMPTING TO
ERECT THE PRODUCT AND RETAIN FOR FUTURE REFERENCE !!**

Precautions:

- **!** Do not use in high winds or adverse weather conditions – if weather deteriorates we strongly advise that the gazebo is dismantled
- **!** The item is not designed to be a permanent fixture, therefore do not leave up for extended periods or unattended, or for continuous periods in direct sun or rain.
- **!** Ensure that the gazebo is securely anchored before use – suitable tie down kits and weights are available for purchase.
- **!** Do not use force when pulling out the locating pins
- **!** Do not use near any source of heat or flame
- **!** Do not erect the gazebo close to overhead power lines
- **!** Do not transport the gazebo in a lying down position if the framework is allowed to move freely as this will cause nips in roof fabric and framework could also become damaged.

Care Instructions:

- **!** Ensure all gazebo parts and accessories are present before erection and are packed away after use in a clean, dry condition.
- **!** Always store the product in dry, warm conditions.
- **!** Clean the covers with warm, soapy water. Do not use abrasive or spirit based cleaning fluids or compounds.



Erecting the Gazebo

These gazebos are manufactured according to the highest standards and from the finest quality materials available

- Erecting the gazebo requires two people minimum. Ensure the gazebo is placed on flat, level ground.
- Avoid pinching your hands or fingers in any of the moving parts as the frame opens and closes. Remove the carry bag and stand the gazebo on it's feet. Place the gazebo in the centre of the area to be sheltered. With partner on the opposite side, grasp two outer legs each, slightly lift the frame off the ground and move backwards until it is opened 50%.
- Add the roof cover to the framework by holding two corners of same side and throwing over framework. Attached the canopy to frame by using the Velcro and straighten out. The step below will enable the canopy to naturally fall into place.
- Each person should grasp the top and bottom of the 'V' Cross bar formed by the side supports on opposite sides **and push hands together** while stepping backwards until the shelter is fully opened. Be careful not to pull backwards too hard as this will result in the supports bending.
- Engage the slider at each corner by pushing up with one hand while holding down the top of the leg with other hand. A snap button will engage in the locating hole.
- Place each foot in the plate at the bottom of each leg and lifting up the leg, slide the inner leg out until the snap button engages in the locating hole. Square up the gazebo. Note: There are 5 possible height settings = please ensure settings on each leg are set at same level.
- Attach the Velcro tabs, located on the underside of the top cover, around the frame struts.
- Use the guy ropes attached to the ring at each corner of the roof cover and stakes, to secure your gazebo to the ground or just use the stakes through the hole in each leg foot.
- Tie the rope (total 4 pces) with the plastic ring on the corner and steel peg (4 pegs), then fix the peg on the ground. Use the other 4 x pegs to fix the gazebo feet on the ground.

Dismantling the Gazebo

- Remove any leg weights / stakes/ guy ropes and undo the Velcro tabs of the top cover from around the frame.
- Each person (Minimum two people) should each lift the outer legs slightly, depress the snap button and push the telescopic inner legs into the outer legs.
- Release the slider at all four corners by a slight upward pressure with one hand depressing the snap button to release the slider with the other. Push slider down the snap button.
- Each partner should grasp the top of the 'V' cross bar and slightly lift up. Whilst shaking the canopy a little, step inwards until the unit is three quarters closed.
- Grasp the four outer legs and slightly lift off the ground pushing together to fully close.
- Finally having made sure the canopy material is completely dry, fold up gazebo to its storage bag.

