


LPL1040BX Owner's Manual

Location of Controls

- 32 Super Bright LEDs
(8 LEDs in each light head - 5 White LEDs & 3 Amber LEDs)
- Pivoting Light Heads
- Quick Release Button: for mounting unit
- ON/OFF Switch with Selectable Dimmer
- Light Mode Switch: Downlight or Uplight + Downlight
- LED Color Selector Switch
- 8 LED Uplights
- Self Adjusting Mounting Brackets
- Battery Compartments



Installation

Light Positioning

This innovative light allows you to mount the light onto an umbrella pole. To do so, simply:

- Press the Quick Release Button to separate the light.
- Place the light around the pole (Fig 1) and re-connect the light. Be sure it clicks closed securely (Fig 2).

NOTE: Each light head can only pivot 30°. To prevent damage to the unit, do NOT force the light heads. Doing so may damage the unit and will void the warranty.

Operating Directions For ON/OFF Switch With Selectable Dimmer

- Press once for full brightness.
- Press and hold for desired brightness.
- Press a third time to turn the light OFF.

Dual-Color Light Output

Each light head contains 5 Super Bright White LEDs and 3 Super Bright Amber LEDs. To select the color you desire simply, switch the Light Color Selector Switch to the desired light color.

NOTE: Both white & amber downlight LEDs cannot be on at the same time.

Light Mode

This light can be used in one of 3 configurations:

- Downlights Only: White LEDs
- Downlights Only: Amber LEDs
- Uplights & Downlights: White LEDs only

Inserting/Replacing the Batteries



If the LEDs appear to be dim this is an indication that your batteries need to be replaced.

To Replace the Batteries

- Remove cover to both battery compartments.
- Remove old batteries (if replacing batteries) from both battery compartments.
- Replace each compartment with three (3) new AA batteries.
- Make sure to follow battery polarity guide when installing new batteries.
- Replace battery compartments.

Battery Precautions:

- Use only the size and type of batteries specified.
- Always purchase the correct size and grade of battery most suitable for the intended use.
- Be sure to follow the correct polarity when installing the batteries as indicated in the battery compartment. Reversed batteries may cause damage to the device.
- Do not mix alkaline, standard (Carbon-Zinc), or rechargeable (Nickel Cadmium) batteries.
- Replace all batteries of a set at the same time. Do not mix old and new batteries.
- Clean the battery contacts and also those of the device prior to battery installation.
- Do not dispose of batteries in fire.
- Remove batteries if consumed or if product is to be left unused for an extended period of time.



FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Modifications to this product not approved by the party responsible for compliance could void the user's authority to operate the product.

Customer Service

Answers to the most commonly asked questions can be found at www.lancerandloader.com

Limited 2 Year Warranty

If you recently purchased the item the quickest option is to return the product to the retailer where the item was purchased. Return policies vary by retailer. If returning the item to the retailer is not possible visit www.lancerandloader.com for warranty details and directions on how to have the product repaired or replaced.