



# PED0180

---

## Digital SNITCH Finger Spy Camera

---

### User's Manual

Thank you for purchasing the PED0180 Digital SNITCH Finger Spy Camera and Recorder. Please first read over this manual for proper use, save this manual and keep it handy.

### Light Key

**Blue Light:** Power on

**Red Light:** Recording

#### HOW TO RECORD VIDEO (Be sure memory card is inserted before recording)

1. Push the power button for approximately 2 seconds. (The blue light will be on.)
2. Hold the stop/record button (on top) for 2 seconds to enter video record mode. (Blue light will remain solid with flashing red light beside it.)
3. Repeat step 2 to stop recording.

#### HOW TO RECORD AUDIO

1. After power on press the mode button found on the left side of the device.
2. Follow the same instructions as above.

#### HOW TO PLAYBACK VIDEOS

1. Use the supplied USB cable to connect the recorder to your computer, with the Pen DVR in the power off state.
2. Go to "My Computer" and double-click on the new "Removable Disk."
3. Double-click on the "DCMI" folder. Videos will be stored in "100MEDIA".

## **HOW TO EDIT TIME AND DATE STAMP**

1. With your device plugged into the computer, go to “My Computer” then the correct “Removable Disk.”
2. You should see a “DCMI” folder, but don’t click on it. Instead, make a file in notepad and save it as “tag.txt” in the same folder as “DCMI.”
3. Inside the text document, you need to type the current date and time. It should follow this format [date] 2014/04/21 11:21:00
4. You must edit the date and time accordingly, then save the document. Restart the device by pressing the power button off, then turn it on.

## **HOW TO TURN UNIT OFF**

1. Hold power button for approximately 3 seconds to turn the device off

**NOTE:** To change time again, simply repeat this process.

**Technical Support: 866-904-8850**

---