

Manual



Strobe LED 400DMX



Table of contents

1. Safe	ety instructions	3
1.1.	Instructions for a safe and efficient operation Be careful with heat and extreme temp	erature
	3	
1.2.	Further safety instructions	4
2. Intro	oduction	8
3. Con	nections	8
3.1.	Electrical connections	8
3.2.	DMX connections	8
3.3.	DMX connection with terminator	8
4. Con	ntrol	9
4.1.	Structure of the menu	9
5. DM	X Table	9
5.1.	Mode 1 (4 channels)	9
5.2.	Mode 2 (6 channels)	9
5.3.	Mode 3 (10 channels	9
6 Tec	hnical data	11



1. Safety instructions



- This Device is suitable for indoor use only.
- All modifications will void the warranty.
- Repairs have to be carried out by skilled personnel only.
- Only use fuses of the same type and original parts as spare parts.
- Protect the Unit from rain and humidity to avoid fire and electric shocks.
- Make sure to unplug the power supply before opening the housing.

1.1. Instructions for a safe and efficient operation

Be careful with heat and extreme temperature

Only use the device in a place where no extreme temperatures will occur. Do not keep it in a temperature bellow 32°F /0°C, or exceeding 104°F /40°C. Avoid exposing it to direct rays of the sun or near a heating appliance.

Keep away from humidity, water and dust

Do not place the set in a location with high humidity or lots of dust. Containers with liquid should not be placed on the set.

Avoid placing it on un-stable location

Select a level and stable location to avoid vibration.

Do not use chemicals or volatile liquids for cleaning

Use a clean dry cloth to wipe off the dust. Metall Parts can be cleaned with a wet soft cloth for stubborn dirt.

If out of work, contact sales agency soon

If any troubles occurs, remove the power plug immediately, and contact with an engineer for repairing, do not open the cabinet by yourself, it might result a danger of electric shock.

Take care with the power cable

Never pull the power cable to remove the plug from the receptacle, be sure to hold the plug. When not using the device for an extended period of time, be sure to disconnect the plug from the receptacle.

IMPORTANT:

Damages caused by the disregard of this user manual are not subject to warranty. The dealer will not accept liability for any resulting defects or problems. Make sure the electrical connection is carried out by qualified personnel. All electrical and mechanical connections have to be carried out according to the European safety standards.



1.2. Further safety instructions

IMPORTANT

Damages caused by the disregard of this user manual are not subject to warranty. The dealer will not accept liability for any resulting defects or problems. Make sure the electrical connection is carried out by qualified personnel. All electrical and mechanical connections have to be carried out according to the European safety standards.



IMPORTANT

Keep away from water and humidity!

Make sure to unplug the power supply before opening the housing!

Please read careful through this manual before the first start-up.

All persons which are entrusted with installation, start-up, operation, maintenance and repair of this device have to:

- Show a corresponding competence.
- Follow the lines of this manual.
- Face this manual as part of the product.
- Keep this manual over the lifetime of the product.
- Pass this manual to new owners of the device.
- Download the latest version of the manual.

Safety-related red flags



IMPORTANT!

Handle with the dangerous electric voltages carefully. With this voltage there is the danger to get a life-threatening electric shock.

Always observe

After taken the device from a cold room to a warm room, it is not allowed to activate the device. It is possible that thereby emerged condensed water damages the device. Do not activate the device until it reached ambient temperature.

Prevent that the power cable has contact with other cables. Handle carefully with power cables and power connections. Don't touch them with clammy hands.

Make sure that the connected voltage which does not exceed the specified values.

Make sure that it isn't possible to squeeze or damage the power cable with sharp edges. Assure yourself with regular checks that there are no damages to the power cable or the device.

Don't switch the device in short time intervals (e.g. in second cycle) on and off.

Keep away children and laymen off the device.





Health risk!

Don't look directly into the light source. At certain circumstances it is possible that some people get epileptic seizures. This is especially true for individuals whose epilepsy was determined by a doctor. Therefore do not install it in danger zones (such as stairs, exit routes ...). Inform the visitors before operating a strobe. Avoid prolonged flash sequences.

Designated use

This device was developed for professional use on stages, in discos, theatres etc. The device is only approved for a connection up to 230V 50/60 Hz AC voltage and only for indoor use.

Regular breaks during operation increase the lifetime of your device.

Avoid convulsions or any form of forceful impact during the installation or the start-up of the device.

Make sure that the device is not exposed to excessive heat, humidity or dust at the place of installation. Take care that no cables are lying around. You would endanger your own safety and also the safety of a third party.

It is not allowed to operate or store the device in an environment in which spray water, rain, humidity or fog is expected. Humidity or very high atmospheric humidity could reduce the isolation of the device and could cause deathly electric shocks. If you use fog devices the device should not be exposed to a direct smoke jet. There has to be a safety distance of at least 0.5m between this device and the fog machine. Make sure that the saturation of the fog has to enable a visibility of at least 10m.

The ambient temperature has to be between 0°C and +40°C. Avoid direct sunlight and close proximity to heaters. You have to attend it during the transport in closed motor vehicles, too.

You have to attend that with an ambient temperature of 40°C it is not allowed that the relative humidity exceeds 50%.

Do not operate the device during thunderstorms. Surge voltages could destroy the device. Unplug the power supply during thunderstorms.

During the installation the use of the mounting bracket is obligatory.

Surrounding objects or surfaces should not be in contact with the device.

Make sure that during the installation and removal of the device the area below the place of installation is basically cordoned off. This also applies to implementation of service.

The device has basically been protected by a suitable safety.

Make yourself familiar with the functions of the device before start-up. People without the experience should not handle with the device. The most cause of functional disorder is inappropriate handling.

Do not use chemicals or volatile liquids for cleaning. Use a clean dry cloth to wipe off the dust, or a wet soft cloth for stubborn dirt.

For transport use the original packing or designated accessory to avoid damages during the transport.

For reasons of safety unauthorized changes are forbidden.



A usage of the device which differs from usages which are described in this manual can cause damages of the device. In that case the warranty expires. Additional you should notice that every differed usage is related with dangers and can cause e.g. an electrical short, fire, electric shock or crash.

Overhead installation



Danger of life!

You have to observe the regulations of BGV C1 (formerly VBG 70) and EN60598-2-17 Installations are to carry out by skilled personnel only.

The suspension devices have to be build and measured so they can withstand for an hour the tenfold of the payload without suffering a permanent detrimental deformation.

Basically installation has to be made by using a second separate suspension. This can be e.g. a suitable net. The second suspension must be designed and attached so no part of the installation can fall down in case of failure.

During construction, reconstruction and deconstruction unnecessary stay in the range of moving areas, on lightning bridges, under elevated work stations or any other danger zones is forbidden.

The operator is obliged to following safety-related and mechanical facilities:

- Before the first start-up or after critical changes before restarting it has to be checked by an expert.
- Review in the frame of the inspection test at least all four years by an expert. .
- Review by a qualified person at least once a year.

How to carry out the overhead installation:

If possible you should install the device out of the area where people could stay.

IMPORTANT! Overhead installation requires a high level of experience. This includes knowledge of calculating the payload, used installation material and safety inspections of the used material and the projector whereas the required experience is not limited to this. Do not try to carry out installation yourself under any circumstances if you are not qualified. Contact a professional installer. An inappropriate installation can lead to injuries and/or damaged properties.

It is not allowed to install the device in the grip area of people.

If the device may hang from the ceiling or from high beams, the use of truss systems is mandatory. The device may not be installed so it can swing freely in the room.

Please note: Crashing down items can cause serious injuries! Do not install the projector, if you doubt the safety of a possible installation form!

Before installation make sure that the mounting surface has the ability to carry the tenfold point load of the own weight of the device.

Mount the device with the mounting-bracket to your trussing system using an appropriate clamp.



During overhead installation the device always has to be secured by a safety rope which is designed to hold the twelvefold weight of device. Only safety ropes with quick-release safety fastener elements may be used. Hang up the safety rope in the hole of the mounting bracket. Direct the rope over the truss or an appropriate fastening point. Hang up the end in the fastening element and tie up the locking nut. A safety rope once exposed to failing load or damaged may not be used furthermore.

The maximum drop exceed must not exceed 20cm.

A safety rope once exposed to failing load or damaged may not be used furthermore. Adjust the desired inclination angle via the mounting bracket and tighten the screw.



2. Introduction

Thank you for buying the **Strobe LED 400DMX**. It is a powerful device. For a successful installation and operation, please read this manual carefully.

3. Connections

3.1. Electrical connections

. Connect the fixture to the mains with the enclosed power cable and plug. The earth has to be connected.


Cable (EU)	Cable (US)	Pin	International
Brown	Black	Live	L
Light blue	White	Neutral	N
Yellow/Green	Green	Earth	lacktriangle

3.2. DMX connections

To make a DMX512 connection go ahead like it is described in the picture. Make sure that you use shielded cable. 3pole or 5pole XLR cables are suitable.

3.3. DMX connection with terminator

Where the DMX cable has to run a long distance or the equipment is operated in an electrically noisy environment like a disco for installations, we recommend using a DMX terminator. This prevents corruption of the digital control signal by electrical noise. The DMX terminator is simply an XLR connector with a 120 Ω resistor between pins 2 and 3, which is then plugged into the XLR output socket of the last device in the series. Please look to the bottom drawings.



If you using a controller with 5 pins DMX output, you need to use a 5 to 3 pin adapter-cable.



4. Control

To get to the menu you have to press MENU. With UP/DOWN you can scroll through the menu. If you have reached the desired point of menu press ENTER. With UP/DOWN you can make your desired settings. Conform your settings with ENTER.

4.1. Structure of the menu

DMX ADD	001-512			Set the DMX address.
Pattern	4/6/10CH			Select the DMX mode
Auto run	00-20	Speed	000-255	Select an automatic program and the required speed.
Sound	000-255			Adjust the microphone sensitivity high-low (available in automatic programs).
Strobe	000-255			Strobe slow-fast
Manual	CH01-CH10	DMX ADD	001-512	Manual settings

5. DMX Table

5.1. Mode 1 (4 channels)

Channel	Value from	Value to	Function
1	0	255	Dimmer
2	0	255	Strobe
3	0	255	Speed
4	0	255	Automatic programs

5.2. Mode 2 (6 channels)

Channel	Value from	Value to	Function
1	0	255	Dimmer lamp line 1
2	0	255	Dimmer lamp line 2
3	0	255	Dimmer lamp line 3
4	0	255	Dimmer lamp line 4
5	0	255	Dimmer lamp line 5
6	0	255	Dimmer lamp line 6

5.3. Mode 3 (10 channels

Channel	Value from	Value to	Function
1	0	255	Dimmer
2	0	255	Strobe
3	0	255	Speed
4	0	255	Automatic programs
5	0	255	Dimmer lamp line 1



6	0	255	Dimmer lamp line 2
7	0	255	Dimmer lamp line 3
8	0	255	Dimmer lamp line 4
9	0	255	Dimmer lamp line 5
10	0	255	Dimmer lamp line 6



6. Technical data

Power supply			
Voltage	AC110-240V, 50/60Hz		
Power consumption max.	450 W		
Battery	No		
Light source			
LM type	SMD LEDs		
Power	388,8 W		
Number/Power	972/0,4 W		
Optics			
Flash rate	0-35 Flashes/s		
Connections			
Current in	P-Con blue		
Current out	P-Con white		
XLR in/out	3Pin		
Controlling			
Sound-to-light	Yes		
Automatic	Yes		
Master-Slave	Yes		
DMX512	4/6/10 Channels		
Hardware			
Protection class	IP20		
Dimensions (L/B/H)	535x216x235mm		
Weight	10,92		



Importeur:

B & K Braun GmbH Industriestraße 2 D-76307 Karlsbad

www.bkbraun.com info@bkbraun.com





