



# ***PARTS MANUAL***

## **V SERIES FOOD HOLDING, TRANSPORT, AND PROOFER CABINET**

**MODEL:**

VP18      ML-138089



For additional information on Vulcan-Hart or to locate an authorized parts and service provider in your area, visit our website at [www.vulcanhart.com](http://www.vulcanhart.com)

VULCAN-HART  
DIVISION OF ITW FOOD EQUIPMENT GROUP, LLC  
[www.vulcanhart.com](http://www.vulcanhart.com)

Vulcan ©2010 All Rights Reserved

3600 NORTH POINT BLVD.  
BALTIMORE, MD 21222  
F-41183 (08-10)

Vulcan-Hart Food Holding and Transportation Cabinets are produced with quality workmanship and material. Proper installation, usage and maintenance will result in many years of satisfactory performance.

Before performing maintenance on the cabinet, thoroughly read the Service Manual and carefully follow all instructions in the order given. Refer to the Installation and Operation Manual for detailed operating instructions.

This manual is applicable only to models listed on the cover page.

To obtain Service and Parts information, contact Vulcan-Hart Service Department at the address listed on the front cover of this manual or refer to our website: [www.vulcanhart.com](http://www.vulcanhart.com).

**Technical Service                      1-800-814-2028**

**Service Parts                              1-866-628-0485**

**When calling for Technical Service or Parts, have the model number and serial number available.**

**VP18  
(PROOFER)**

DESCRIPTION	WITTCO #	VULCAN #	
CASTER, 5" RIGID	WP-114-5R	851800	-38
CASTER, 5" SWIVEL	WP-114-5S	851800	-39
CLIP, ELEMENT	WP-182	851800	-14
CORD, POWER 12/3 120V. 20 AMP	WP-247	851800	-148
DOOR, FULL SIZE	WP-286	851800	-694
ELEMENT, 120V - 1000W	WP-105-1	851800	-151
FAN, COOLING 120V (3 1/8")	WP-248	851800	-655
FAN, COOLING 120V (4 1/2")	WP-013	851800	-793
HINGE, PIVOT	WP-128	851800	-789
HOLDER, CORD	WP-036	851800	-790
HOLDER, PROBE THERMOMETER	WP-093	851800	-29
HOLDER, PROBE THERMOSTAT	WP-089	851800	-32
KNOB, THERMOSTAT	WP-242	851800	-31
LATCH, DOOR MAGNETIC	WP-372	851800	-626
LIGHT, INDICATOR DUAL 240V	WP-106-2	851800	-22
RACK, SIDE	WP-216	851800	-689
SWITCH, DOUBLE POLE/THROW	WP-250	851800	-792
SWITCH, ROCKER	WP-193	851800	-770
THERMOMETER, DIAL	WP-109	851800	-28
THERMOSTAT	WP-110	851800	-30