



**SUCTION BASE**

# **KNIFE SHARPENER**

**Model 95984**

## **OPERATION INSTRUCTIONS**



Due to continuing improvements, actual product may differ slightly from the product described herein.



3491 Mission Oaks Blvd., Camarillo, CA 93011

Visit our website at: <http://www.harborfreight.com>

**TO PREVENT SERIOUS INJURY, READ AND UNDERSTAND  
ALL WARNINGS AND INSTRUCTIONS BEFORE USE.**

Copyright© 2007 by Harbor Freight Tools®. All rights reserved. No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools.

**For technical questions or replacement parts, please call 1-800-444-3353**

---

## SPECIFICATIONS

---

Construction	ABS Thermoplastic Base. Tungsten-Carbide Blades. Suction Lever, Cast-Zinc.
Attachment Method	Suction, Requires Smooth Base. 25 lb. Pull (Holding)
Overall Dimensions	2-3/8" Diameter Base at Suction Cup. 2" Height at Blade Bits. 2-7/8" Wide with Flip Down Lever Applied for Suction.
Net Weight	4.2 OZ.

### Save This Manual

You will need this manual for the safety warnings and precautions, assembly, operating, inspection, maintenance and cleaning procedures, parts list and assembly diagram. Keep your invoice with this manual. Write the invoice number on the inside of the front cover. Write the product's serial number in the back of the manual near the assembly diagram, or write month and year of purchase if product has no serial number. Keep this manual and invoice in a safe and dry place for future reference.

---

## GENERAL AND SPECIFIC SAFETY RULES

---



**READ AND UNDERSTAND ALL INSTRUCTIONS**  
**Failure to follow all instructions may result in serious**  
**injury.**  
**SAVE THESE INSTRUCTIONS**

1. **DO NOT allow children to play with this Knife Sharpener.**
2. **Stay alert. Watch what you are doing, and use common sense when operating this Knife Sharpener. Do not use while tired or under the influence of drugs, alcohol, or medication.** A moment of inattention may result in serious personal injury.
3. **DO NOT use this Knife Sharpener for knives with a serrated edge.**
4. **Expect the Knife Sharpener to eventually work loose from mounting surface.** Always check before using.

---

## UNPACKING

---

When unpacking, check to make sure that the item is intact and undamaged. If any parts are missing or broken, please call Harbor Freight Tools at the number shown on the cover of this manual as soon as possible.

---

## ASSEMBLY INSTRUCTIONS

---

**NOTE:** This Knife Sharpener comes completely assembled, however there is brief information on replacement of sharpening blades on the last page of this manual.

---

## OPERATION INSTRUCTIONS

---

1. Make sure the Knife Sharpener is attached securely to a dry, flat, smooth nonporous surface capable of holding a suction attachment. Check attachment before each use and expect the Knife Sharpener to come loose eventually.
2. Place the Knife Sharpener on the surface, hold base with one hand and move the Handle from the “up” position to the “lower” position.
3. Try to move the Knife Sharpener to check it for hold-down security.
4. Slide your knife/knives in the direction of the arrows located on top of the Knife Sharpener. Slide them, starting at the blade heel closest to the handle. Pull the knife toward your body. The blade of the knife should be held vertical to the Sharpener and not leaning at an angle when sliding through the Sharpener Blades. Run knives through Sharpener twice.

---

## INSPECTION, MAINTENANCE, AND CLEANING

---

**BEFORE EACH USE**, inspect the general condition of the tool. Check for loose screws, cracked or broken parts and any other condition that may affect its safe usage. **Do not use if damaged in any way. Only a professional should sharpen the Blades.**

---

## TROUBLESHOOTING

---

Problem	Possible Causes	Probable Solutions
Will not hold suction	<ol style="list-style-type: none"><li>1. Surface not nonporous enough to hold suction.</li><li>2. Bottom of Knife Sharpener suction cup has foreign matter stuck to it preventing a smooth application.</li></ol>	<ol style="list-style-type: none"><li>1. Try attaching Knife Sharpener to another, smoother surface.</li><li>2. Wipe bottom of Knife Sharpener with clean, soft rag to clear anything that may be attached.</li></ol>
Knife blades get stuck or will not travel smoothly through Sharpener	<ol style="list-style-type: none"><li>1. Screws holding blades may have worked their way loose allowing Blades to separate slightly.</li></ol>	<ol style="list-style-type: none"><li>1. Check and tighten screws. (Screwdriver now included)</li></ol>


## PARTS LIST

Part	Description	Q'ty	Part	Description	Q'ty
1	Knife Sharpener Body	1	4	Handle	1
2	Blades	2	5	Bottom Suction Cup	1
3	Attachment Screws	2			

### PLEASE READ THE FOLLOWING CAREFULLY

THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE PARTS LIST AND ASSEMBLY DIAGRAM IN THIS MANUAL AS A REFERENCE TOOL ONLY. NEITHER THE MANUFACTURER OR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BUYER THAT HE OR SHE IS QUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT, OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT, THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THAT ALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS, AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND

## ASSEMBLY PHOTO



**Record Product's Serial Number Here:** \_\_\_\_\_

**Note:** If product has no serial number, record month and year of purchase instead.

**Note:** Some parts are listed and shown for illustration purposes only, and are not available individually as replacement parts.