

HAIRMAX.COM

For International Translations visit www.hairmax.com/manual



HAIRMAX.COM | 1-866-LASERCOMB (1-866-527-3726)



LIT UM-04 06-12



Advanced 7, Lux 9, Professional 12

USER MANUAL

Introduction1
Who is the best candidate? (Classifications male/female)2
Who is the best candidate? (Fitzpatrick Skin Types)
Warnings and Cautions4
Risks/Testing for sensitivity5
How to Monitor Device Activity6
Device Failure Mode6
Expected Life of the HairMax LaserComb6
Summary of Clinical Study in Men7
Summary of Clinical Study in Women8
HairMax LaserComb Advanced 7

HairMax LaserComb Advanced 7 Parts	9
Getting Started	10
Replacing the Batteries	10
Proper Use	11
Treatment Instructions	12
What your HairMax Advanced 7 comes with	13
Troubleshooting	14
Safety Label	15
Power Supply Specifications	15

© Copyright 2012 Lexington Intl, LLC. All rights reserved.

HairMax LaserComb Lux 9. Professional 12

HairMax LaserComb Lux 9, Professional 12 Parts16
Getting Started17
Charging Methods17
Proper Use18
Treatment Instructions19
What your HairMax Lux 9 or Professional 12 comes with21
Troubleshooting22
Safety Label23
Power Supply Specifications23
Cleaning Your HairMax LaserComb24
Electrical Safety25
Warranty26
Warranty Card27

Mailing Address:

USA

Lexington International

Boca Raton, FL 33431

777 Yamato Rd., Ste 105

HairMax Customer Service: Phone: 1-866-527-3726 +1-561-417-0200 Email: info@hairmax.com HAIRMAX.com

To view videos about usage, quality and safety, visit: www.hairmax.com/videos www.hairmax.com/QualitySafety

Introduction of HairMax LaserComb[®]

The HairMax LaserComb is a home-use laser device that has been Clinically Proven to treat heredity hair loss in men and women. The LaserComb is an over-the-counter (OTC) device that can be sold directly to the public.

Indications

The HairMax LaserComb Advanced 7, Lux9, and the Professional 12 models are indicated to treat Androgenetic Alopecia, and promote hair growth in females who have Ludwig (Savin) I-4, II-1, II-2, or frontal patterns of hair loss and in males who have Norwood Hamilton Classifications of Ila to V and who both have Fitzpatrick Skin Types I to IV.

How the LaserComb works

The LaserComb works by providing laser energy to stimulate hair follicles. For optimal results, the laser must not be blocked by the hair and must have an unobstructed path to the scalp. The LaserComb has teeth that



INTRODUCTION

part the hair and allow the maximum amount of laser energy to reach the scalp.

Treatment with HairMax LaserComb

The LaserComb should be used 3 times per week, spaced out every other day. For example, Monday, Wednesday, Friday. The LaserComb should not be used more than the recommended treatment time per day. Recommended treatment; Advanced 7 = 15 minutes, Lux 9 = 11 minutes, Professional 12 = 8 minutes. Clinical studies demonstrate that most users see benefits in as little as 16 weeks.

HairMax LaserComb Benefits

A clinical study was conducted in men and women over a six month time period. The study showed that 93% of the men and women had an increase in the number of hairs (based on a minimum of 32 new hairs per square inch being observed at follow up).

See pages 7-8 for detailed results of the study.

How do you know if the HairMax LaserComb is right for you?

The LaserComb can be used by men and women with thinning hair or pattern baldness caused by a hereditary condition. Doctors use a system known as the Norwood Hamilton Classification (men) and the Ludwig-Savin Classification (women) to describe the degree of hair loss. Below are the pictures of the scales. The shaded areas show the type of hair loss that can be treated with the LaserComb.

Norwood Hamilton Classification - Males



Ludwig-Savin Classification - Females



The HairMax LaserComb has not been clinically tested for hair loss outside of the shaded areas.

The LaserComb was only studied in light to medium skin tones (Types 1,2,3,4) as described in the Fitzpatrick Scale below. If your hair loss and skin tone fall into these categories, the LaserComb should work for you.

Fitzpatrick Skin Type Classification Guide: A way to describe your skin type based on your complexion and what happens to your skin in sunlight.

ype 1 ס		Very white or freckled skin, alway (very fair; often in people with rea
ype 2 av	tective tor skin types	White skin, usually burns with su and blue, green, or hazel eyes)
ype 3 Vipically Vipe 4	be effe these sk	White or olive skin tone, sometin (fair; seen in people with any hai
ype 4	p t t	Brown skin, rarely burns with sun (common in people of Mediterra
ype 5 adv	ed for e skin ves	Dark brown skin, very rarely burn (common in people of Middle-E
ype 6	Tested for these skin types	Black skin, never burns with sun (Adapted from Fitzpatrick's Dermatology)

WHO IS THE BEST CANDIDATE FOR THE HAIRMAX LASERCOMB?

s burns with sun exposure

d or blond hair and blue eyes)

In exposure (fair; often in people with red or blond hair

mes burns with sun exposure ir or eye color)

exposure

anean descent)

ns with sun exposure Eastern descent)

exposure in General Medicine, McGraw-Hill Professional: 5th edition)

WARNINGS

- A Do not stare directly at the red laser light or its reflection in a mirror because it can temporarily irritate your eyes. If you stare at the light for too long, it could harm your eyes. Also, never use a magnifying glass when using the LaserComb because it can cause temporary irritation to your eyes.
- A Keep the LaserComb out of the reach of children.
- A Do not drop the LaserComb in water because you may get an electrical shock. If the LaserComb gets damaged by water, contact Customer Service toll-free at 1-866-527-3726
- A If the cord is damaged on the LaserComb do not use the device because you could get an electrical shock. If the cord gets damaged, contact Customer Service toll-free at 1-866-527-3726.
- A Do not use the LaserComb near any heated surfaces because this could cause the device not to work properly and may cause an electrical shock. Contact Customer Service toll-free at 1-866-527-3726.
- Laser light avoid direct eye exposure.

CAUTIONS

- A If you are taking any medications or products that make you sensitive to light, you should test the LaserComb to make sure you do not have a reaction. Some of the things that can cause increased sensitivity to the LaserComb could be medicines for colds, allergies, pain medicine and drugs to treat infections. To test the LaserComb for sensitivity, turn the device on, hold the device on one spot, shining the light on your forearm. After two minutes, turn the device off and set aside. Look at the spot where you held the laser light over the next five minutes. If you see any reaction such as redness or rash, do not use the LaserComb and contact our Customer Service toll-free at 1-866-527-3726 to return your product and get a refund.
- A Only use the LaserComb as directed. Do not try to change the way the LaserComb operates. Changes may result in harmful laser exposure. Contact Customer Service toll-free at 1-866-527-3726 for repairs.
- A Never use acetone or other solvents on any part of the LaserComb. Use of solvents on the window can block the laser light from coming through.

Risks

Before beginning treatment, be sure to test the HairMax LaserComb has been clinically tested on both men and women. In the clinical study for men, HairMax LaserComb for sensitivity. Turn the device 5% of the men said they had itching or tingling from on, hold the LaserComb on one spot, shining the using the LaserComb. None of the women in the light on your forearm. After two minutes, turn the clinical study reported any of these side effects from device off and set aside. Look at the spot where using the LaserComb. If you have itching, tingling or you held the laser light over the next five minutes. any other side effect that bothers you, stop using If you see any reaction such as redness or rash, the LaserComb and contact Lexington's Customer do not use the HairMax LaserComb and contact Service toll-free at 1-866-527-3726. Customer Service toll-free at 1-866-527-3726 to return your product and get a refund. If you don't experience any reaction, proceed with the treatment instructions on page 12 for Advanced 7 or page 19 for Lux 9 and Professional 12 models.

NOTICE: If any malfunction occurs, do not attempt to repair the LaserComb yourself. This appliance has no user-serviceable parts Use the LaserComb only for its intended use as described in this manual. Contact Customer Service toll-free at 1-866-527-3726.

RISKS | TESTING FOR SENSITIVITY

Testing the LaserComb for sensitivity

How to Monitor Device Activity

Your HairMax LaserComb is inspected and tested during production. When working properly, both the green and the red light indicators on the power and laser buttons turn on. A red laser light shines through the window at the bottom of the device. Do NOT look directly at the laser light. Shine the laser light onto the palm of your hand to see if the red laser light appears.

If one or both of the light indicators is not lit, or if the laser light does not appear, contact Customer Service toll-free at 1-866-527-3726 for repair or replacement.

Device Failure Mode

The HairMax LaserComb is designed to last for 10-15 years of continuous use. The laser light does not fade or diminish over time. At the end of the laser's life or if it fails for any other reason, the red laser light will no longer shine out of the device.

Expected Life of the HairMax LaserComb

The HairMax LaserComb is a medical device manufactured under strict quality controls and validated through GMP (Good Manufacturing Practices). The HairMax LaserComb contains high quality laser diodes designed to last at least 15,000 hours. Based on that rating and the durability of the components being used, the expected life of the LaserComb is 10-15 years of regular use. Please take time to read this entire instruction manual before operating the HairMax LaserComb.

Clinical studies were conducted at multiple locations in the United States. Participants in the study were males diagnosed with hereditary hair loss, which is called Androgenetic Alopecia, and had light to medium skin tones. Subjects were divided into two groups, LaserComb Group and a Control Group. The Control Device looked and sounded like the LaserComb device but did not include a laser light. The Clinical studies adhered to all GCP (Good Clinical Practice) guidelines, were approved by an IRB (Institutional Review Board) and listed on www.clinicaltrials.gov.

During the 6 month clinical study, subjects treated their hair once per day, 3 times per week on non-consecutive days. The number of thick, normal healthy hairs in the target zone were counted at week 1, week 16 and week 26.

Results at the 26 week visit showed that over 93% of the men saw an increase in hair counts (based on a minimum of 32 new hairs per square inch being observed at the follow up visit).

No subjects in the study experienced any serious adverse events. In fact, the number and types of adverse events were similar in the LaserComb and Control Groups.

Hair Count Change

In the clinical study, after 26 weeks of treatment with the LaserComb devices versus the Control Device, the following increases in hair count were found.

SUMMARY OF CLINICAL STUDY IN MEN





A clinical study was conducted at multiple locations in the United States. All participants in the study were females, diagnosed with hereditary hair loss, which is called Androgenetic Alopecia, and had light to medium skin tones. Subjects were divided into two groups. One group used the LaserComb and the other group used a Control Device. The Control Device looked and sounded like the LaserComb, but did not include a laser light. The Clinical studies adhered to all GCP (Good Clinical Practice) guidelines, were approved by an IRB (Institutional Review Board) and listed on www.clinicaltrials.gov.

During the 6 month study, subjects treated their hair once per day, 3 times per week, on non-consecutive days. The number of thick, normal, healthy hairs in the target area were counted at Week 1, Week 16 and Week 26

Results at 26 weeks showed that over 90% of the women saw some increases in hair counts (based on a minimum of 32 new hairs per square inch being observed at the follow up visit).

No subjects in the study experienced any serious adverse events. In fact, the number and types of adverse events were similar in the HairMax LaserComb and control groups.

Hair Count Change

In the clinical study, after 26 weeks of treatment with the LaserComb and a Control Device, the following increases in hair count were found.

Mean Terminal Hair Count Changes From Baseline in FEMALES 26 Weeks, Observed Hair Count





HAIRMAX LASERCOMB ADVANCED 7 PARTS



Your LaserComb Advanced 7 comes with four AA batteries already installed. To use the LaserComb you must remove the cardboard protective strip located in the battery compartment. Follow these steps:

- Remove the blue label on the bottom of the LaserComb
- 2. Using an ordinary Philips screwdriver, remove the battery compartment screw located on the bottom of the device.
- 3. Open the battery compartment.
- 4. Locate and remove the cardboard protective strip (Figure A). 5. Put the batterv



compartment cover back into place and tighten the screw. Do not over tighten.

6. Your LaserComb is now ready for use.

Replacing Batteries

The LaserComb is designed to provide the optimum laser output even as the batteries age. When the batteries weaken to the point where they will no longer power the lasers to their optimum power level, the green battery indicator will flash from green to red and the lasers will flash.

This is an indication that the batteries need to be replaced. Use the following steps to replace the batteries:

Using an ordinary Phillips screwdriver, remove the battery compartment screw located on the

bottom of the device. The screw will remain attached to the housing.

2. Gently lift battery compartment cover (Figure B).



3. Insert 4 AA batteries.

Be sure to align batteries as shown on bottom of battery compartment (Figure C).

4. Replace cover. Tighten screw. Do not over tighten.



In addition, the LaserComb can be powered directly by the optional power cord. Plug the power cord into the end of the LaserComb. Plug the other end into an electrical wall outlet

(Figure D). Do not use the LaserComb if the device is damaged or defective, instead call Customer Service toll-free at 1-866-527-3726.



GETTING STARTED | PROPER USE - ADVANCED 7 MODEL

Proper Use

Read and follow all directions prior to use. If you're using the power cord (optional-not included), place one end directly into the handle end of the LaserComb and the other end into an electrical wall outlet

(Figure D). Use the LaserComb for 15 minutes per treatment, three treatments per week. The treatments should be spaced



every other day, for example Monday, Wednesday, Friday. Do not use the LaserComb more than 15 minutes per treatment day. Most users see benefits in as little as 16 weeks (based on clinical studies).



Slide the power/laser button to the middle or top position (Figure E). Middle position activates the laser and vibrate feature. **Top position** is laser only. Shine

the LaserComb onto the palm of your hand. You will see that the laser light is on. (Do not look at the laser light directly.) The LaserComb is now ready for use.

Treatment Instructions

Before beginning treatment, be sure to test the HairMax LaserComb for sensitivity (Page 5).



After you have turned on the LaserComb, place it flat on your scalp so that both rows of teeth are touching your scalp (Fiaure F).

You should start at your hairline and move the LaserComb slowly in a combing motion leaving it on one spot for 4 seconds. Once you feel the vibration move the LaserComb about 1/2 inch (1 cm) to the next spot without lifting the device off your head.

IMPORTANT: Do not lift the device off of your scalp when moving every 4 seconds. The LaserComb features a pair of comb teeth that part the hair so the light can more effectively penetrate to the scalp. You will make a few complete passes over your scalp. Next move the LaserComb against the way your hair grows from front to back. Now move the LaserComb side to side (Figure G). Repeat these passes within the required treatment of 15 minutes. If you have long hair, use your fingers to lift your hair out of the way allowing the LaserComb to deliver the laser light to the scalp (Figure H).

Turn off the LaserComb by sliding the power/laser button to the lowest position (Figure I). If using the optional power cord, remove the power cord from

electrical wall outlet and return the device to the cradle/stand for storage.







The LaserComb is most effective when used correctly. In order to help time the movements, the LaserComb will automatically vibrate every 4 seconds. The vibration can be turned off by sliding the power/laser button to the uppermost top position. The LaserComb should be used for 15 minutes. Use a

watch or clock to time your treatment.

3 times





Please Note:



- It is important to move the LaserComb very slowly. Remember, you are bathing the scalp with laser light. If you move it too fast, the treatment will will not achieve the optimal results to promote hair growth.
- Total time required for treatment with the Advanced 7 LaserComb is 15 minutes.

What is included:

Troubleshooting

The LaserComb has advanced electronics to ensure that the device is working like it is supposed to and that the proper amount of laser energy is being delivered. If for some reason you are experiencing difficulties with your device, please try one of the tips below if:

Your LaserComb will not turn on

- Make sure your LaserComb has fresh batteries or it is plugged into an electrical wall outlet.
- Insert power cord into the LaserComb. Slide the power/laser button to the on position.
- Try another electrical wall outlet.

Your LaserComb is turning off during use

- Make sure your LaserComb has fresh batteries or it is plugged into an electrical wall outlet.
- Insert power cord into the LaserComb. Slide

the power/laser button to the on position.

• Try another electrical wall outlet.

Your LaserComb will not turn off

- Slide the power switch to the lowest OFF position.
- If using power cord, unplug the LaserComb.

Your LaserComb vibrates irregularly/doesn't vibrate

• Make sure the Power Switch is in the middle position.

Your LaserComb vibrates, but you do not see the laser

• Make sure your LaserComb has fresh batteries or plugged into an electrical wall outlet.

You have trouble understanding any of these instructions

 Contact Customer Service toll-free at 1-866-527-3726.

SAFETY LABEL | LASER PARAMET

Wavelength:	655nm ⁺ /- 10nm visible red
Laser Power for classification	<5mW CW
Divergence	57 mrad
Number of lasers	7
This Laser Product is designated	as Class 3R during all procedu
Note:	LaserComb Advanced 7 has
Location:	On the underside of the hanc

Power Supply Specifications

Output = 6VDC 1.0A. Plug: 9mm x 3.5mm, center positive.

The power supply for the HairMax LaserComb can be used in the United States and Internationally. This power supply will adapt to all power supplies from 110 volt/60 cycle (US) to 240 volt/50 cycle. If outlets in your country have different plugs than the power supply that comes with the HairMax LaserComb, use an inexpensive plug adapter (not supplied with the device).

SAFETY LABEL | LASER PARAMETERS | POWER SUPPLY SPECIFICATIONS

TERS
light
ures of operation.
s no user-serviceable parts.
dle Model version varies



HAIRMAX LASERCOMB LUX 9, PROFESSIONAL 12 PARTS

LaserComb Lux 9 and Professional 12 are identical models that only vary in number of diodes and treatment time.

POWER BUTTON
LASER BUTTON
BATTERY INDICATOR
INFORMATION DISPLAY
POWER CORD
SAFETY LABEL
TEETH
LASER WINDOW
WARNING LABEL

- U CHARGING CRADLE/STAND
- K CHARGING CRADLE INDICATOR



Your LaserComb Lux 9 and Professional 12 come with a rechargeable battery already installed. Read this manual completely before you start to use your LaserComb.



Use the LaserComb Lux9 for 11 minutes per treatment, and LaserComb Professional 12 for 8 minutes per treatment, three treatments per week. The treatments

should be spaced every other day, for example Monday, Wednesday, Friday. Do not use the LaserComb more than 11 minutes per treatment day. Most users see benefits in as little as 16 weeks (based on clinical studies).

When you receive the LaserComb take all the parts out of the case. Remove the red safety label. The power button and the laser button are located under the red safety label. You must charge your LaserComb before using.

Charging Methods

METHOD 1: Charging the LaserComb using the charging cradle (stand) and power cord. Plug the power cord into the cradle and the other end into an electrical wall outlet. While the device is charging you will see a red light on the charging cradle. After

about 2-3 hours the light on the charging cradle will turn green which means that the LaserComb is fully charged and ready to use. During this charging method the light on the device will not light up.

METHOD 2: Charging the LaserComb by placing the power cord directly into the handle end of the Laser-Comb and the other end into an electrical wall outlet. The battery indicator light on the LaserComb will be yellow and will turn green when fully charged.





ICON

When the LaserComb requires charging, the battery indicator light will flash red and the battery icon on

BATTERY INDICATOR LIGHT

INFORMATION DISPLAY

the information display will appear. Charge your LaserComb with one of the charging methods as described on page 17.



If your device needs to be recharged during your treatment, simply insert the power cord directly into the end of the device and other end into an electrical wall outlet and continue with your treatment. When finished, allow the device to fully charge.

Proper Use

The LaserComb Lux9 should be used for 11 minutes and LaserComb Professional 12 for 8 minutes. Use a watch or clock to time your treatment.

First, press the power button and hold it down for 3 seconds and the power button light will light up green.



Second, press the laser button which will light up red. That means the LaserComb is ready to be used. Shine the LaserComb onto the palm of your hand and you will see that the laser light is on (do not look at the laser light directly). Do not use the LaserComb if the device is damaged or defective, instead call Customer Service toll-free at 1-866-527-3726.

The information display on the top of the LaserComb will show you 3 pieces of information:



Usage Timer 2. Laser Symbol 3. Battery Symbol

1. Usage Timer - how long you have been using the LaserComb during your treatment session so you can be sure to cover all areas of your scalp 2. Battery Symbol - the level of the battery, 3. Laser Symbol - to let you know that the laser is turned on.

Treatment Instructions

Before beginning treatment, be sure to test the HairMax LaserComb for sensitivity (Page 5).

After you have turned on the LaserComb, place it flat on your scalp so that both rows of the teeth are touching your scalp (Figure A).



Next move the LaserComb against the way your hair grows from front to back (Figure B). Move the LaserComb slowly in a combing motion leaving it on one spot for 4 seconds.



Now move the LaserComb from side to side (Figure C). Repeat these passes for the total treatment of 8 minutes for Professional 12 and 11 minutes for Lux 9 models.



When the LaserComb is on it will beep and vibrate every four (4) seconds. This means that it's time to move the LaserComb to the next area of the scalp. If

you have long hair, use your fingers to lift your hair out of the way while using the LaserComb to be sure that the laser energy reaches your scalp (Figure D).



IMPORTANT: Do not lift the LaserComb off your head when moving every 4 seconds (unless you are checking the usage timer on the information display). The LaserComb features a pair of comb teeth that part the hair so the light can more effectively reach the scalp.

When the LaserComb is on it will beep and vibrate every four (4) seconds. This means that it's time to move the LaserComb to the next area of the scalp. When you do this, do not lift the device off of your scalp.

If you wish to **turn off the beep/vibration** during the treatment press the top laser button once (Figure E). Your LaserComb and laser will remain on. To re-activate



beep and vibration, simply press the laser button again.

Turn off the LaserComb by pressing and holding the power button (lower button) down for 3 seconds (Figure F).



Remove the power cord from the electrical wall outlet, rest the device in the charging cradle or return the device and power cord to the case for storage.

Please Note:

- It is important to move the LaserComb very slowly. Remember, you are bathing the scalp with laser light. If you move it too fast, the treatment will not achieve the optimal results to promote hair growth.
- Total time required for treatment with the LaserComb Lux9 is 11 minutes and LaserComb Professional 12 is 8 minutes.



TREATMENT INSTRUCTIONS | WHAT IS INCLUDED - LUX 9, PROFESSIONAL 12 MODELS

What is included:

The LaserComb has advanced electronics to ensure that the device is working like it is supposed to and that the proper amount of laser energy is being delivered. If for some reason you are experiencing difficulties with your device, please try one of the tips below if:

Your LaserComb will not turn on

- Make sure your LaserComb is fully charged.
- Insert the power cord into the LaserComb, then press the power button for 4 seconds and then the laser button.
- Try another electrical wall outlet.

If your LaserComb is turning off during use

- Make sure your LaserComb is fully charged.
- Insert the power cord into the LaserComb then press the power button for 4 seconds and then the laser button.
- Try another electrical wall outlet.

If your LaserComb will not turn off

- Press and hold power button for 5 seconds
- If using power cord, unplug the LaserComb and press power button for 5 seconds

If your LaserComb beeps/vibrates irregularly or doesn't beep/vibrate

• If using power cord, unplug the LaserComb. Plug in power cord again and press the power button then the laser button.

If your LaserComb beeps and vibrates, but you do not see the laser light

- If using power cord, unplug LaserComb. Plug in power cord again and press the power button then the laser button.
- If you have trouble understanding any of these instructions Contact Customer Service toll-free at 1-866-527-3726.

SAFETY LABEL LASER PARAMETERS			
Wavelength:	655nm */- 10nm visible red light		
Laser Power for classification	<5mW CW		
Divergence	57 mrad		
Number of lasers	9 (Lux 9 model), 12 (Professional 12 model)		
This Laser Product is designated	as Class 3R during all procedures of operation.		
Note:	HairMax LaserComb has no user-serviceable parts.		
Location:	On the underside of the handle Model version varies		

Power Supply Specifications

Output = 6VDC 1.0A. Plug: 9mm x 3.5mm, center positive.

The power supply for the HairMax LaserComb can be used in the United States and Internationally. This power supply will adapt to all power supplies from 110 volt/60 cycle (US) to 240 volt/50 cycle. If outlets in your country have different plugs than the power supply that comes with the HairMax LaserComb, use an inexpensive plug adapter not supplied with the device.

SAFETY LABEL | LASER PARAMETERS | POWER SUPPLY SPECIFICATIONS



Cleaning your HairMax LaserComb

- Keep your LaserComb clean.
- Turn off the LaserComb by sliding the power button to the lowest position (Advanced 7) or by pressing and holding the power button (lower button) down for 3 seconds (Lux 9 and Professional 12).
- Unplug the power cord from the device and from the electrical wall outlet.
- Clean the laser window with a soft, slightly moistened cloth
- To clean the comb teeth, gently remove any hairs or dust with a slightly moistened towel.
- Don't use any acetone, soap or detergents, only warm water.
- To clean the teeth more thoroughly, gently pull out the comb teeth from the center. Then you can separately wash them using soap and warm water.

• After you dry the comb teeth, put them back on the device by inserting the top tabs into place and then press the bottom of the



teeth with your thumb until they click into place. If you need to replace the teeth, vou can order online

at hairmax.com or call Customer Service toll-free at 1-866-527-3726.

Electrical Safety

Basic safety precautions should be observed when using this, or any other electrical device, especially when children are present.

A DANGER: Keep away from water. Contact with water may result in an electrical shock.

To reduce the risk of hazard by electric shock:

- Always unplug the LaserComb from the power outlet immediately after using.
- Do not use while bathing
- Do not place or store the LaserComb where it can fall or be pulled into a tub or sink. If the LaserComb falls into water, unplug it immediately from the power outlet.
- If using the LaserComb near water, the use of an electrical outlet protected by a Ground Fault Circuit Interrupter is recommended.

Do not expose the LaserComb to running water, or drop into water or any other liquid.

THE HAIRMAX LASERCOMB IS WARRANTED BY LEXINGTON INTERNATIONAL LLC ("MANUFACTURER") AGAINST DEFECTS IN MATERIALS OR WORKMANSHIP FOR 24 MONTHS FROM DATE OF PURCHASE. IF THIS PRODUCT IS DÉTERMINED TO BE DEFECTIVE, LEXINGTON WILL REPAIR OR REPLACE IT, AT ITS OPTION, AT NO CHARGE DURING THE WARRANTY PERIOD.

AFTER THE WARRANTY PERIOD, THE USER MUST PAY FOR ALL PARTS AND LABOR CHARGES. IF THE PRODUCT IS REPAIRED OR REPLACED, EITHER WITHIN OR OUTSIDE THE WARRANTY PERIOD, LEXINGTON RESERVES THE RIGHT TO PROVIDE EQUIVALENT PARTS IN DIFFERENT COLORS TO YOUR ORIGINAL PRODUCT

THIS WARRANTY DOES NOT COVER DAMAGES CAUSED BY ACTS OF GOD, MISUSE, NEGLIGENCE, ACCIDENT, MODIFICATION OF, OR TO ANY PART OF THE PRODUCT. THIS WARRANTY DOES NOT COVER DAMAGE DUE TO IMPROPER OPERATION OR MAINTENANCE CONNECTION TO IMPROPER VOLTAGE SUPPLY, OR ATTEMPTED REPAIR BY ANYONE OTHER THAN LEXINGTON. THIS WARRANTY IS VOID IF PRODUCT IS TAMPERED WITH.

TO OBTAIN WARRANTY SERVICE, YOU MUST DELIVER THE PRODUCT FREIGHT PREPAID, IN EITHER ITS ORIGINAL PACKAGING OR PACKAGING AFFORDING AN EQUAL DEGREE OF PROTECTION. TOGETHER WITH YOUR NAME AND ADDRESS, TO:

Lexington International LLC , 777 Yamato Road, Suite 105, Boca Raton, FL 33431, USA

LIMITATION OF LIABILITY; INDEMNITY: EXCEPT AS EXPRESSLY SET FORTH ABOVE, LEXINGTON INTERNATIONAL LLC SHALL NOT BE LIABLE FOR ANY SPECIAL. INDIRECT, OR CONSEQUENTIAL DAMAGES THAT ARE DIRECTLY OR INDIRECTLY RELATED TO THE USE OF, OR THE INABILITY TO USE. THE HAIRMAX LASERCOMB, EVEN IF LEXINGTON INTERNATIONAL LLC HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTUOUS ACTION. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

GOVERNING LAW: THE USAGE OF THE HAIRMAX LASERCOMB AND THE INTERPRETATION OF ITS TERMS SHALL BE GOVERNED BY AND CONSTRUED IN ACCORDANCE WITH THE LAWS OF THE STATE OF FLORIDA APPLICABLE TO AGREEMENTS NEGOTIATED. EXECUTED AND PERFORMED WHOLLY AND SOLELY WITHIN THE STATE OF FLORIDA. THE PARTIES AGREE THAT THE STATE OF FLORIDA'S CONFLICTS OF LAWS RULES SHALL NOT APPLY TO THIS AGREEMENT OR ANY TRANSACTION PERFORMED BY OR UNDER THIS AGREEMENT

JURISDICTION AND VENUE: THE PARTIES IRREVOCABLY SUBMIT AND CONSENT TO THE SOLE AND EXCLUSIVE JURISDICTION AND VENUE OF THE FLORIDA STATE COURTS IN AND FOR PALM BEACH COUNTY, FLORIDA, U.S.A. AND THE FEDERAL COURTS IN AND FOR THE SOUTHERN DISTRICT OF FLORIDA. U.S.A. THE PARTIES AGREE NOT TO RAISE THE DEFENSE OF FORUM NON CONVENIENS.

AUTHORIZED REPRESENTATIVE IN EUROPE (REGULATORY AFFAIRS ONLY): EMERGO EUROPE, MOLENSTRAAT 15, 2513 BH THE HAGUE. THE NETHERLANDS. TEL: (31) (0) 70 345-8570 FAX: (31) (0) 70-345-7299

To validate your warranty please register online at www.hairmax.com/warranty or call Customer Service toll-free at 1-866-527-3726

The HairMax LaserComb has a 2 year warranty against defects in materials or workmanship from Lexington International, LLC. Items that are damaged or abused are not covered under the warranty and will be charged at their regular repair rates. Lexington Intl. may extend this warranty period under certain product failures. Please refer to the User Manual for complete warranty terms. We guarantee your satisfaction.

or complete	e and mail this	s warranty c _	ard		
Name:		Serial N	lumber:		
Date of Purchase:				located on yellow safety labe on the bottom of the device	
Address:					
City:	State:		ZIP/Posta	al Code:	
Country:	Email:				
Where did you purchase this product (Reseller	r Name)?				
What factors influenced your purchase of this	product?				

WARRANTY CARD



dress: ō Ø Reti

Place stamp here

#260 Lexington International, LLC re Road 33494 2901 Clint Moore Boca Raton, FL 3



HairMax Customer Service:

Phone: 1-866-527-3726 +1-561-417-0200 Email: info@hairmax.com HAIRMAX.com

> To view videos about usage, quality and safety, visit: www.hairmax.com/videos www.hairmax.com/QualitySafety

> © Copyright 2012 Lexington Intl, LLC. All rights reserved.



Mailing Address:

Lexington International 777 Yamato Rd., Ste 105 Boca Raton, FL 33431 USA