

SPECIFICATIONS

- Memory: 8 GB micro-SD card included. Maximum storage supported: 32 GB.
- Capacity: 3 hours at 30 fps and 10,000 pictures (*with included 8 GB micro-SD card*).
- Video Quality: High Definition 720p true HD.
- Video Ratio: 4:3.
- Video Recording Format: AVI
- Photo Quality: 12 Megapixel digital photos at 4032x3024 pixels.
- High Capacity polymer ion battery.
- Approximately 90 minutes of use on full charge.

GUARDLINE®

www.guardlinesecurity.com
1.888.589.1853

More details about this product's capabilities and uses, as well as Tips and Frequently Asked Questions, can be found on our website.

LIMITATIONS & PRECAUTIONS

Your SpyPen is intended for use in accordance with all applicable local, state, and federal laws and regulations. Neither the manufacturer nor the distributor are liable for any illegal use. User accepts all responsibilities with the operation and use of this device.

Guardline® Professional Spy Pen Camera User's Manual

Thank you for purchasing the Guardline® Professional Spy Pen Camera! We hope you are pleased with this product's design, functionality, and ease of use. If you have questions, please call our Customer Service Department at: info@guardlinesecurity.com.



DEVICE FEATURES

The Guardline® Professional Spy Pen Camera is an 8 megapixel camcorder/camera designed to be covert, functional, stylish, and user-friendly. It comes with 8 GB of memory capacity on a removable and replaceable micro-SD card, and is capable of supporting *up to 32 GB of data!*

This Guardline® product operates seamlessly with any computer which accepts USB devices. When used with the included adapter and USB cable, the Spy Pen Camera can be charged from any standard AC outlet.

The Guardline® Professional Spy Pen Camera is a must-have tool for any individual who requires a simple, quick, and portable way to document in video and in photograph.

CHARGING YOUR SPY PEN

1. Take pen apart by unscrewing at the center Disassembly Point.
2. Insert the USB end into computer's USB port.
 - You may also use the AC adapter and provided USD cable to charge the Spy Pen in a wall outlet.
3. LED will blink ORANGE when charging.
 - If the light does not appear, the pen is inserted incorrectly. Remove pen, flip over, and reinsert into USB port.
4. Solid ORANGE LED indicates full charge.

NOTE: Spy Pen must be FULLY charged the first five uses in order to activate battery's maximum memory. Until then, battery life will be relatively short.